

Preface

Thank you for purchasing CDE360 Vector Control AC Drive developed by **Shenzhen Canworld Electrical Technology Co., Ltd.**

The CDE360 series AC drive is a general-purpose high-performance vector control AC drive, which is widely used for simple fan and pump driving, and automatic controlling in specific industry equipment of Textile, Stone sawing machine, Air compressor, Spindle servo drive, Crane, Veneer peeling machine, line cutting machine, oil-fields and wire drawing machine. It can also provide all-in-one solution for the application of ball crusher, injection molding machine and intelligent motor.

This manual describes the notes and guidance of selection, installation, parameter setting, field debugging, fault diagnostics and daily maintenance. Read and understand the user manual before use and forward the manual to the end user.

Notes
<ul style="list-style-type: none">● The drawings in the user manual are sometimes shown without covers or protective guards. Remember to install the covers and protective guards according to the user manual, then perform operations in accordance with the instructions.● The drawings in the manual are shown for description only and may not match the product that you purchased.● The instructions are subject to change without notice, due to product upgrade and the efforts to increase the accuracy and convenience of the user manual.● Contact our agents or customer service center if you need to purchase this user manual.● Contact our customer service center if you have problems during the use.
Service hot line: +86 4000-888-699 Fax: +86 755-26617646

Introduction

Notes: All the examples below are base on factory setting.

Example 1: Start/stop the AC drive and set frequency by Keypad.

Operating steps:

1.1) Configure the following parameters according to the motor nameplate and actual requirements.


Function Code	Name	Unit	Function Code	Name	Unit
b0.04	Acceleration time 1	Sec	b0.08	Rated motor current	A
b0.05	Deceleration time 1	Sec	b0.09	Rated motor frequency	Hz
b0.06	Rated motor power	KW	b0.10	Rated motor speed	RPM
b0.07	Rated motor voltage	V	b2.01	Digital setting frequency	Hz

1.2) Start/stop the AC drive by pressing the RUN/STOP key on the keypad.

Example 2: Start/stop the AC drive by digital input (X terminals) and set frequency through analog input signals.

Operating steps:

2.1) Terminal X1 controls forward running, X2 controls reverse running, and AI1 signal set the running frequency. Please configure the wiring refer the following diagram.



2.2) Configure the following parameters base on the wiring mode.

Function Code	Name	Value	Meaning
b0.11	Command sources selection	1	Commands from X terminals.
b2.00	Main frequency source A selection	1	Frequency from AI1.
C0.01	The function of terminal X1	3 (default)	Forward run
C0.02	The function of terminal X2	4	Reverse run

2.3) Configure the following parameters according to the motor nameplate and actual requirements.

Function Code	Name	Unit	Function Code	Name	Unit
b0.04	Acceleration time 1	Sec	b0.08	Rated motor current	A
b0.05	Deceleration time 1	Sec	b0.09	Rated motor frequency	Hz
b0.06	Rated motor power	KW	b0.10	Rated motor speed	RPM
b0.07	Rated motor voltage	V			


2.4) Set running frequency by adjusting the signal level of AI1.

2.5) The AC drive will run forward when the switch K1 is closed, and run reverse when the K2 is closed. If the K1 and K2 are both in closed or open status, the AC drive will stop.

Example 3: Start/stop the AC drive and set frequency through communication (Modbus RTU protocol, RS485 interface)

Operating steps:

3.1) Connect the control device to the AC drive directly if it supports RS485 interface. Otherwise, please add an communication adapter box.



3.2) Configure the following communication related parameters.

Function Code	Name	Value	Meaning
b0.11	Command sources selection	2	Commands from the communication.
L0.00	Communication baud rate	1 (default)	9600 bps
L0.01	Data format	1 (default)	No check, 8-N-2 data format
L0.02	Slave address	1 (default)	

3.3) Configure the following parameters according to the motor nameplate and actual requirements..

Function Code	Name	Unit	Function Code	Name	Unit
b0.04	Acceleration time 1	Sec	b0.08	Rated motor current	A
b0.05	Deceleration time 1	Sec	b0.09	Rated motor frequency	Hz
b0.06	Rated motor power	KW	b0.10	Rated motor speed	RPM
b0.07	Rated motor voltage	V			

3.4) Set the running frequency of the AC drive (slave address is 1) to 25 Hz by writing the data to the register 0x6400 with the communication function code 0x06.

Frame	Address	Function Code	Register Address		Register Content		Check Sum	
Request	0x01	0x06	0x64	0x00	0x13	0x88	0x9B	0xAC
Response	0x01	0x06	0x64	0x00	0x13	0x88	0x9B	0xAC

Remarks: 0x1388 corresponds to 5000 in decimal, which means 50 percents as communication setting value. When the communication setting value is used for reference frequency, the base value is **b0.00**(Max frequency, default 50Hz).

3.5) Run the AC drive (slave address is 1) forward by writing the data to the register 0x6401 with the communication function code 0x06.

Frame	Address	Function Code	Register Address		Register Content		Check Sum	
Request	0x01	0x06	0x64	0x01	0x00	0x01	0x06	0xAC
Response	0x01	0x06	0x64	0x01	0x00	0x01	0x06	0xAC


3.6) Stop the AC drive (slave address is 1) by writing the data to the register 0x6401 with the communication function code 0x06.

Frame	Address	Function Code	Register Address		Register Content		Check Sum	
Request	0x01	0x06	0x64	0x01	0x00	0x06	0x47	0x38
Response	0x01	0x06	0x64	0x01	0x00	0x01	0x47	0x38

Remarks: 0x6401 command function

Address	Command Function
6401H (b0.11 = 2)	0001: Forward run
	0002: Reverse run
	0003: Forward JOG
	0004: Reverse JOG
	0005: Coasting stop
	0006: Deceleration stop
	0007: Fault reset

Induction motor flow chart by first using



Index

Preface	
Contents	
Chapter 1 Safety Information and Precautions	2
1.1 Safety Information and Precautions	2
1.2 General Precautions	1
Chapter 2 Product Information	2
2.1 CDE360 Technical Specifications	2
2.3 CDE360 Nameplate	6
2.4 CDE360 Model and Technical Parameters	6
2.4.1 General Series	6
2.5 CDE360 Appearance and Dimensions	9
2.5.1 General Series	9
2.5.1.1 Wall-mounted Type Appearance	9
2.6 CDE360 Keypad Physical Dimensions	14
2.6.1 Keypad A (LED)	14
2.6.2 Keypad A Foundation	14
2.6.3 Keypad B	15
2.6.4 Keypad B Foundation	15
2.6.6 Dust Excluding Plate A	16
2.6.7 Dust Excluding Plate B	16
2.7 Selection Suggestion of AC Drive	17
2.8 Recommendation of Brake Resistance Selection	18
Chapter 3 Mechanical and Electrical Installation	21
3.1 Mechanical Installation	21
3.1.1 Requirements of Installation Environment	21
3.1.2 Installation Direction and Clearance	21
3.1.3 Removal and Installation of the Keypad and Cover	22
3.2 Electrical Installation	26
3.2.1 Instructions of Peripheral Electrical Components	27
3.2.2 Selection Guidance of Peripheral Electrical Components	27
3.2.3 Terminals Wiring Diagram of the AC drive	30
3.2.4 Power Terminals of the Main Circuit	31
3.2.5 Control Terminals and Wiring Description	35
(II)The connection mode of source	40
.....	40
Chapter 4 Operation, Display and Application	41
4.1 Keypad Interface	41
4.2 Keypad Indicators	42
4.3 Function of the Keypad Key	42
4.4 Keypad Display	43
4.4 Menu Introduction	44
4.5 Monitor Parameters	44
4.6 Parameters Upload and Download	45
4.7 Password and Parameter Setting	46
4.8 User Defined Parameters	47
4.9 Non-basic Menu Display	47
Chapter 5 Parameter List Table	48
A0 Monitor	49
A1 Fault & Diagnostics	52
b0 Basic Parameters	54
b1 Run & Stop logic	55
b2 Frequency Source	56
C0 Digital Input	57

CDE360 Vector Control AC Drive	Index
C1 Digital Output	59
C2 Analog Input	61
C3 Analog Output	62
C4 Pulse Input/Output	63
C5 Virtual Digital Input/Output	63
d0 Motor Control	64
d1 Motor Parameters	66
d2 Speed Control	66
d3 Torque Control	68
d5 Motor 2 Parameters	69
d6 Motor 2 Speed Control	70
E0 JOG	72
E1 Skip Frequency	72
E2 Multi-Reference	72
E3 Simple PLC	73
E4 Acc & Dec Time	74
E5 PID	75
E6 Multi-Pump Control	77
E7 Swing Frequency	78
E8 Droop Control	78
E9 Power Loss Ride Through	78
EA External Brake	79
Eb Supervision	79
F0 Protection	81
F1 Auto Reset	83
H0 System Parameters	83
H1 AI/AO Calibration	85
L0 Communication Setting	85
L1 Point-point Communication	86
L2 Encoder Setting	86
P0 User-defined Parameters	87
P1 Debug Parameters	88
P2 Factory Parameters	88
Chapter 6 Parameters Description	89
Group A0: Monitor	89
Group A1: Fault & Diagnostic	96
Group b0: Basic Parameters	98
Group b1: Run & Stop Logic	102
Group b2: Frequency Source	109
Group C0: Digital Input	113
Group C1: Digital Output	126
Group C2: Analog Input	132
Group C3: Analog Output	137
Group C4: Pulse Input/Output	140
Group C5: Virtual Digital Input/Output	142
Group d0: Motor Control	144
Group d1: Motor Parameters	152
Group d2: Speed Control	154
Group d3: Torque Control	159
Group d5: Motor 2 Parameters	164
Group d6: Motor 2 Speed Control	166
Group E0: JOG	169
Group E1: Skip Frequency	170
Group E2: Multi-Reference	171
Group E3: Simple PLC	172
Group E4: Acc & Dec time	174
Group E5: PID	175

Group E6: Multi-Pump Control	186
Group E7: Swing Frequency	195
Group E8: Droop Control	198
Group E9: Power Loss Ride Through	199
Group EA: External Brake	200
Group Eb: Supervision	202
Group F0: Protection	208
Group F1: Auto Reset	214
Group H0: System Parameters	215
Group H1: AI/AO Calibration	220
Group L0: Communication Setting	222
Group L1: Point-point Communication	223
Group L2: Encoder Setting	224
Group P0: User-defined Parameters	226
Group P1: Debug Parameters	227
Chapter 7 Fault Detection and Diagnostics	228
7.1 Faults and Solutions	228
7.2 Common Faults and Solutions	236
Chapter 8 Communication Protocol	237
8.1 Protocol Comment	237
8.2 Networking Mode	237
8.3 Bus Structure	237
8.4 Protocol Format	238
8.5 Functions of Protocol	239
Chapter 9 Maintenance	247
9.1 Routine Repair and Maintenance	247
9.2 The Inspection and Replacement of Vulnerable Components	247
9.3 Storage and Warranty Agreement	248
Chapter 10 Optional Cards	249
10.1 Relay Card (IO1)	249
10.2 Multi-function IO Card (IO2)	250
10.3 Multi-function IO Card (IO3)	251
10.4 Temperature Sample Card (IO4)	252
10.5 Differential Encoder Card (PG1)	253
10.6 OC type Encoder Card (PG2)	254
Appendix: Records of Version Changes	255

Chapter 1 Safety Information and Precautions

Safety definition:

In this user manual, the notices are graded based on the degree of danger:



DANGER indicates that failure to comply with the notice will result in severe personal injury or even death.



WARNING indicates that failure to comply with the notice will result in personal injury or property damage.

Read this user manual carefully so that you can have a thorough understanding of the product. Installation, debugging and maintenance must be performed in accordance with the content of this chapter. There will assume no liability or responsibility for any injury and loss due to improper operation.

1.1 Safety Information and Precautions

Before installation



DANGER

- Do not install the equipment if you find water seepage, component missing or damage upon unpacking.
- Do not install the equipment if the packing list does not conform to the product you received.



DANGER

- Handle the equipment with care during transportation to prevent damage to the equipment.
- Do not use the equipment with damaged or missing components. Failure to comply will result in personal injury.
- Do not touch the components in the equipment. Failure to comply will result in static electricity damage.

During installation



DANGER

- Install the equipment on incombustible objects such as metal and keep it away from combustible materials.
- Do not install the equipment in the environment with combustible gas. Failure to comply will result in a fire.
- Do not loosen the fixed screws of the components, especially the screws with red marks.



WARNING

- ❖ Do not drop wire end or screw into the AC drive. Failure to comply will result in the damage to the AC drive.
- ❖ Install the AC drive in places free of vibration and direct sunlight.
- ❖ When two AC drives are laid in the same cabinet, please arrange the installation positions properly to ensure the cooling effect.

At wiring



DANGER

- Wiring must be performed only by qualified personnel under instructions described in this user manual.
- Failure to comply may result in unexpected accidents.
- A circuit breaker must be used to isolate the power supply and the AC drive. Failure to comply may result in a fire.
- Ensure that the power supply is cut off before wiring. Failure to comply may result in the electric shock.
- Tie the AC drive to ground properly by standard (earthing resistance less than 10 Ohms). Failure to comply may result in the electric shock.
- Do not control the run or stop of the AC drive by turning on or off the input power supply.



DANGER

- Pay attention to marks of the wiring terminals. Never connect the power cables to the output terminals (U,V,W) of the AC drive. Failure to comply will result in damage to the AC drive.
- Ensure that the wiring conforms to EMC requirements and the safety standard of the region. Please refer to proposals of the user manual when considering the diameter of the wire. Failure to comply will result in accidents.
- Never connect the braking resistor between DC bus terminals (+) and (-). Failure to comply will result in a fire.

Before power-on



WARNING

- ❖ Check that following requirements are met:
- ❖ The voltage class of the power supply is consistent with the rated one of the AC drive.
- ❖ The input terminals (R, S, T) and output terminals (U, V, W) are properly connected.
- ❖ No short-circuit exists in the peripheral circuit.
- ❖ The wiring is secured.
- ❖ Failure to comply will result in the damage to the AC drive.
- ❖ Do not perform the voltage resistance test on any part of the AC drive because such test has been done in the factory. Failure to comply will result in accidents.



DANGER

- Cover the AC drive properly before power-on to prevent electric shock.
- The wiring of peripheral devices must be connected properly under instructions described in this user manual. Failure to comply will result in accidents.

After power-on



DANGER

- Do not open the AC drive cover after power-on. Failure to comply will result in electric shock.
- Do not touch the AC drive and circuits of peripherals when use wet hands. Failure to comply will result in electric shock.
- Do not touch any I/O terminal of the AC drive. Failure to comply may result in electric shock.
- Ensure that the motor and mechanical devices can bear high-speed rotating when the run frequency is bigger than the Rated motor frequency.

During operation



DANGER

- Do not touch the fan or the discharging resistor to check the temperature. Failure to comply will result in personal burnt.
- Signal detection must be performed only by qualified personnel during operation. Failure to comply will result in personal injury or damage to the AC drive.
- Avoid objects falling into the AC drive during operation. Failure to comply will result in the damage to the AC drive.

During maintenance



DANGER

- Do not repair or maintain the AC drive at power-on. Failure to comply will result in electric shock.
- After the AC drive is powered off, the basic waiting time must be ten minutes. Then repairing or maintenance the AC drive can be performed when the DC bus voltage (between P+ and P-) is lower than 36V. Failure to comply will result in personal injury due to the residual voltage in the capacitor.
- Repairing or maintenance of the AC drive can be performed only by qualified personnel. Failure to comply will result in personal injury or damage to the AC drive.
- Set and check parameters again after the AC drive is replaced. All plug-in components must be plugged or removed only after power is off.

1.2 General Precautions

◆ Ground Connection

The incorrect earthing may cause personal injury, death or equipment failure, and increase the electromagnetic interference.

The correct earthing the AC drive, motor or other devices can guarantee the safety of the operator in any case and reduce the electromagnetic radiation and interference.

If the leakage current of the AC drive is greater than AC 3.5mA or DC 10mA , connecting a fixed protection earthing cable is needed.

Earthing terminals of several AC drives can not be connected in series.

Only when the conduct interface dimension of the cable shielding layer conforms to safety regulations, the cable can be used for earthing.

◆ Motor insulation test

Perform the insulation test when the motor is used for the first time, or when it is reused after being stored for a long time, or in a regular check-up, in order to prevent the poor insulation of motor winding from damaging the AC drive. During the insulation test, the motor must be disconnected from the AC drive. A 500-V mega-Ohm meter is recommended for the test and the insulation resistance must not be less than 5M Ohms.

◆ Thermal protection of the motor

If the rated capacity of the motor selected does not match that of the AC drive, especially when the rated power of the AC drive is greater than that of the motor, please adjust the motor protection parameters on the operation panel of the AC drive or install a thermal relay in the motor for protection.

◆ Running at over 50 Hz

This series AC drive can provide output frequency of 0~600Hz(0~3000Hz for CDE360B type). If the AC drive needs to run at higher frequency than base frequency(50Hz or 60 Hz), the capability of the mechanical device must be considered.

◆ Vibration of mechanical device

The AC drive may encounter mechanical resonance points at some output frequencies, which can be avoided by setting skip frequencies on the keypad.

◆ The heat and noise of the motor

The output of the AC drive is pulse width modulation (PWM) wave with certain harmonic frequencies, and therefore, the temperature rise of the motor, noise and vibration will be increase slightly compared with power frequency operation.

◆ Voltage-sensitive devices or capacitors for improving power factor on the output side of the AC drive

Because the output of the AC drive is PWM wave, please do not install capacitors for improving power factor or lightning protection voltage-sensitive resistors on the output side of the AC drive. Otherwise, the AC drive may suffer transient fault trip or being damaged.

◆ **Contactors at the I/O terminal of the AC drive**

When one contactor is installed between the input side of the AC drive and the power supply, the AC drive should not be started or stopped by switching the contactor on or off. If the AC drive has to be operated by the contactor, ensure that the time interval between switching is at least one hour for frequent charge and discharge will shorten the service life of the capacitor inside the AC drive. When one contactor is installed between the output side of the AC drive and the motor, do not turn on or off the contactor when the AC drive is active. Otherwise, modules inside the AC drive may be damaged.

◆ **Leakage protector**

Because of the existence of distributed capacitors to ground, when the AC drive runs with high-speed switching action, high frequency leakage current will be generated, which will lead to the malfunction of the leakage current protection circuit. When encounter this problem, in addition to reduce the carrier frequency appropriately and shorten the lead, the leakage protector should be chosen correctly. Please pay attention to the following two points:

- a. The leakage protector should be arranged on the input side of the AC side. It is appropriate for the leakage protector to be arranged after the air switch (no fuse breaker).
- b. The leakage protection devices should choose the types which are not sensitive to high level harmonic or special ones for the AC drive (sensitivity is above 30mA). If common leakage protectors should be chosen, the type that the sensitivity is above 100mA and the action time above 0.1s is preferred.

◆ **When external voltage is out of the range of the rated voltage**

The AC drive must not be used outside the allowable voltage range specified by the user manual. Otherwise, components inside the AC drive may be damaged.

If required, the corresponding voltage step-up or step-down device should be chosen.

◆ **Prohibition three-phase input changed into two-phase input**

When three-phase input changed into two-phase input, the voltage ripple of the DC bus and the current ripple will increase, and the ripple will shorten the service life of capacitors in the main circuit and make the work performance of the AC drive worse. So, the user should not change three-phase input into two-phase input. If it is necessary to use a two-phase power supply, the protection of input phase loss should be canceled, at the same time, the action of derating the AC drive should be considered. Of course, the maximum value of derating the AC drive should not be larger than 60 percent of the rated power.

◆ **Surge suppressor**

The AC drive has a built-in voltage dependent resistor (VDR) for suppressing the surge voltage generated when inductive loads around the AC drive are switched on or off. If inductive loads generate a very high surge voltage, a surge suppressor is used for the inductive load.

◆ **Altitude and derating**

1. In places where the altitude is above 1000 meters and the cooling effect reduces due to thin air, it is necessary to de-rate the AC drive. The ratio of derating the AC drive is 1 percent for every increase of 100 meters.
2. In places where the ambient temperature exceeds 40°C, it is necessary to de-rate the AC drive. The ratio of derating the AC drive is 3 percent for every increase of 1 °C.
3. When the setting carrier frequency is bigger than the fault value, it is necessary to de-rate the AC drive. The ratio of derating the AC drive is 4 percent for every increase of 1K Hz.

◆ **Disposal**

The electrolytic capacitors on main circuits and PCB may explode when they are burnt. Poisonous gas is generated when the plastic parts are burnt. Treat them as ordinary industrial waste.

◆ **Adaptable motor**

1. The standard adaptable motor is the four-pole squirrel-cage asynchronous motor. Please configure related parameter according to the type and the nameplate of the motor.
2. Because the cooling fan and the rotor shaft of the non-variable-frequency motor are coaxial, the cooling effect will reduce when the speed decelerates. If variable speed is required, add a more powerful fan or replace it with variable-frequency motor in applications where the motor overheats easily.
3. Standard motor parameters have been configured inside the AC drive. It is necessary to perform motor auto-tuning or modify fault values based on the actual condition. Otherwise, the running result and protection performance will be affected.
4. The AC drive may alarm or even be damaged when short-circuit exists on cables or inside the motor. Therefore, perform insulation short-circuit test when the motor and cables are newly installed or during routine maintenance. During the test, make sure that the AC drive is disconnected from the tested parts.
5. When the distance between the AC drive and the motor is too long, the insulation withstand voltage must be considered.

◆ **Lubrication of mechanical device**

The mechanical devices such as reduction boxes and gears which need to be lubricated, may cause damage after a long time low speed running due to bad lubrication. Please conform the mechanical devices is OK before starting the AC drive.

◆ **Regenerative load**

For the application which have energy regeneration such as lifting, the AC drive often stops due to over voltage protection and a appropriate brake component needs to be considered.

The specific constant voltage energy saving AC drives (CDE360J type) can save the brake component and avoid over voltage protection for the application with energy regeneration, like sawing machine, oil pumping machines, etc.

Chapter 2 Product Information

2.1 CDE360 Technical Specifications

Table 2- 1 Technical Specifications

Item		Specifications
Basic Performance	Rated Input	Single-phase: 220V; Three-phase : 220V/380V/480V; Frequency: 50/60Hz
	Input voltage range	Voltage fluctuation: -15%~10%; Imbalance factor: less than 3%; Voltage frequency: 47~63Hz
	Control mode	VF control; Open-loop vector control; Close-loop vector control
	Frequency resolution	Digital setting: 0.01Hz; Analog setting: 0.5% × maximum frequency
	Maximum output	V/F control: 3500Hz; Vector control: 300Hz
	Speed range	VF control: 1:60; Vector control: 1:100
	Carrier frequency	0.5~16.0kHz(Model dependent). The carrier frequency can be automatically adjusted based on features of the load.
	Start torque	0.5Hz/150%*rated motor torque
	Overload capacity	G type: 150% rated current for 60s,180% rated current for 3s L type: 120% rated current for 60s
Basic Function	Run mode	Keypad; Control terminals (two-line, three-line); Serial communication (RS485).The user can perform switch-over between these sources in various ways.
	V/F curve	Straight line type; Multiple point type; N-power type
	Ramp curve	Straight line or S curve; Four ramp times (range: 0.1s to 6000.0s)
	Torque boost	Automatic/manual torque boost
	Speed trace	All types have the function of the speed trace.
	Motor braking	DC braking; Energy consumption braking; Magnetic braking
	DC braking	Braking frequency: 0.00Hz to Maximum frequency; Braking time: 0.0s to 100.0s; Braking current: 0.0% to 100.0%*Rated motor current
	Magnetic braking	For occasions which have the request of fast stop or regenerative loads, the function of magnetic braking can be used. The function can avoid frequent protection due to over voltage.
	CBC current limiting	The function of CBC current limiting is to minimize the fault of over current and keep the normal running of the AC drive.
Overcurrent and overvoltage control	The function is to restrict the current and voltage automatically during running and avoid the frequent fault protection of over current and over voltage.	

	Item	Specifications
Special Functions	The delay time of terminals	The user can set the delay time for digital input terminals, digital output terminals and relays. The time range is 0.0s to 3000.0s.
	JOG Control	Control mode: keypad, terminals and serial communication. Frequency: 0.00Hz to Maximum frequency; Ramp time: 0.1 to 6000.0s
	Multiple speed and simple PLC	Based on built-in PLC or digital input terminals, realize the running of sixteen segments speed.
	Two PID inside the parameters	As common PID, the closed-loop system of process control can be realized easily.
	Fixed length and count	The AC drive can count the pulse signal of 0 to 100K Hz and realize the control of count reaching by using digital output terminals. The drive can also convert the count into length for display and control.
	Spinning and swing frequency	The fixed swing magnitude, fixed mutations and fixed periodic output can be achieved at arbitrary frequency.
	Timing control	Time range: 0 to 65000 hours. The timing control can stop the AC drive.
	Power loss ride through	When the power loss ride through happens, by decreasing the running frequency, the feedback energy of the load can compensate the voltage drop of the DC bus. As a result, the AC drive can keep running for a short time.
Peripheral terminals	Reference power	10V/30mA. Usually, it is used for the power supply of analog input signals.
	Control power	24V/200mA. Usually, it is used for the power supply of digital input and output terminals.
	Analog input	Two analog input terminals, which have two types of voltage input and current input. Every input terminal can support three types input signals: 0 to 10V, 0 to 20mA and -10V to 10V. These two analog input terminals are programmable.
	Analog output	Two analog output terminals, which have two types of voltage output and current output. Every output terminal can support two types output signals: 0 to 10V and 0 to 20mA. These two analog output terminals are programmable.
	Digital input	Six multi function digital input terminals are compatible with active PNP or NPN input mode. Among these six input terminals, the X6 terminal can be chosen as high-speed pulse input terminal and the range of the high-speed pulse is 0 to 100KHz. At the same time, the X6 terminal is programmable.
	Digital output	There are two open collect output terminals. Among them, Y2 terminal can be chosen as high-speed pulse output. These two output terminals are programmable. There are two relay output terminals.

Item		Specifications
Protection function	Common types	Input and output phase loss protection, under voltage protection, over voltage protection, over current protection, over heat protection, over load protection, short-circuit protection, module fault, external fault, self-defining fault.
Environment	Installation location	Indoor, free from direct sunlight, dust, drip, salt, oil smoke, water vapor, combustible gas and corrosive gas.
	Altitude	If the altitude is equal or lower than 1000 meters, the AC drive can be used normally. If the altitude is higher than 1000 meters, it is necessary to de-rate the AC drive. The ratio of derating the AC drive is 1 percent for every increase of 100 meters. If the altitude is higher than 3000 meters, please contact our agents.
	Temperature	-10□ to +40□. If the ambient temperature is 40□ to 50□, please keep good ventilation and take the action of derating: The ratio of derating the AC drive is 3 percent for every increase of 1□.
	Humidity	Less than 95%RH, without condensing.
	Vibration	Less than 0.6g
	Storage temperature	-25□~+65□

2.2 CDE360 Designation Rules




Figure 2- 1 Designation Rules

Remarks:

- 1) Designation only has the main specification of the AC drive.
- 2) As for the configuration information of the brake unit and DC reactor, please refer to Sector 2.4 'CDE360 Model and technical parameters'.
- 3) As for the construction size, please refer to Sector 2.5 'CDE360 appearance and dimensions'.

2.3 CDE360 Nameplate




Figure 2- 2 Nameplate

2.4 CDE360 Model and Technical Parameters

2.4.1 General Series

- 1) 2S class (single-phase 220V AC input)

Table 2- 2 CDE360-2S class model and technical parameters

AC drive model CDE360-	Power capacity (KVA)	Input current (A)	Output current (A)	Brake unit	DC reactor	Keypad
2S0R7	1.5	8.2	4	Built-in (Standard)	Not installed	LED (Standard)
2S1R5	3	14	7			
2S2R2	4	23	9.6			

Remarks:

- 1) The models in the table above do not have input phase loss protection.

2) The models in the table above are single and wall-mounted type.

Table 2- 3 CDE360-4T class model and technical parameters

AC drive model CDE360-	Power capacity (KVA)	Input current (A)	Output current (A)	Brake unit	DC reactor	Keypad
4T0R7G/1R5L	2.0/3.0	3.4/5.0	2.6/3.8	Built-in (Standard)	Not installed	
4T1R5G/2R2L	3.0/4.0	5.0/5.8	3.8/5.5			
4T2R2G/3R7L	4.0/5.9	5.8/10.5	5.5/9			
4T3R7G/5R5L	5.9/8.9	10.5/14.6	9/13			
4T5R5G/7R5L	8.9/11	14.6/18	13/17			
4T7R5G/011L	11/16.4	18/25	17/24			
4T011G/015L	16.4/21	25/31.2	24/30			
4T015G/018L	21/24	31.2/39.2	30/38			
4T018G/022L	24/30	39.2/46.5	38/45			
4T022G/030L	30/40	46.5/62	45/60			
4T030G/037L	40/57	62/78	60/76	External (Optional)	External (Optional)	LED (Standard)
4T037G/045L	57/69	78/93	76/91			
4T045G/055L	69/85	93/114.5	91/112			
4T055G/075L	85/114	114.5/153.5	112/150			
4T075G/090L	114/134	153.5/180	150/176			
4T090G/110L	134/160	180/214	176/210			
4T110G/132L	160/192	214/256	210/253			
4T132G/160L	192/231	256/307	253/304			
4T160G/185L	231/240	307/360	304/350			
4T185G/200L	240/250	360/385	350/377			
4T200G/220L	250/276	385/425	377/415			
4T220G/250L	276/335	425/479	415/465			
4T250G/280L	335/375	479/535	465/520			
4T280G/315L	375/420	535/600	520/585			
4T315G/355L	420/475	600/674	585/650			
4T355G/400L	475/535	674/785	650/720			
4T400G/450L	535/600	785/850	720/820			
4T450G/500L	600/670	850/930	820/890			

Remarks:

- 1) The models of 11G/015L and below do not have input phase loss protection.
- 2) The models of 132G/160L and below are single and wall-mounted type.
- 3) 4T class (three-phase 380V AC input)

Table 2- 4 CDE360-5T class model and technical parameters

AC drive model CDE360-	Power capacity (KVA)	Input current (A)	Output current (A)	Brake unit	DC reactor	Keypad
5T0R7G/1R5L	2.0/3.0	3.4/5.0	2.6/3.8	Built-in (Standard)	Not installed	LED (Standard)
5T1R5G/2R2L	3.0/4.0	5.0/5.8	3.8/5.5			
5T2R2G/3R7L	4.0/5.9	5.8/10.5	5.5/9			
5T3R7G/5R5L	5.9/8.9	10.5/14.6	9/13			
5T5R5G/7R5L	8.9/11	14.6/18	13/17			
5T7R5G/011L	11/16.4	18/25	17/24			
5T011G/015L	16.4/21	25/31.2	24/30			
5T015G/018L	21/24	31.2/39.2	30/38			
5T018G/022L	24/30	39.2/46.5	38/45			
5T022G/030L	30/40	46.5/62	45/60			
5T030G/037L	40/57	62/78	60/76	External (Optional)	Optional	
5T037G/045L	57/69	78/93	76/91			
5T045G/055L	69/85	93/114.5	91/112			
5T055G/075L	85/114	114.5/153.5	112/150			
5T075G/090L	114/134	153.5/180	150/176			
5T090G/110L	134/160	180/214	176/210			
5T110G/132L	160/192	214/256	210/253			
5T132G/160L	192/231	256/307	253/304			
5T160G/185L	231/240	307/360	304/350			
5T185G/200L	240/250	360/385	350/377			
5T200G/220L	250/276	385/425	377/415			
5T220G/250L	276/335	425/479	415/465			
5T250G/280L	335/375	479/535	465/520			
5T280G/315L	375/420	535/600	520/585			
5T315G/355L	420/475	600/674	585/650			
5T355G/400L	475/535	674/785	650/720			
5T400G/450L	535/600	785/850	720/820			
5T450G/500L	600/670	850/930	820/890			


Remarks:

- 1) The models of 11G/15L and below do not have input phase loss protection.
- 2) The models of 132G/160L and below are single and wall-mounted type.
- 3) 5T class (three-phase 480V AC input)


2.5 CDE360 Appearance and Dimensions

2.5.1 General Series


2.5.1.1 Wall-mounted Type Appearance




W01 (plastic housing)




W02 (plastic housing)




W03 (sheet metal housing)



W04 (sheet metal housing)




W05 (sheet metal housing)




W06 (sheet metal housing)

2.5.1.2 Wall-mounted Type Dimensional Drawing



C02



C03

Table 2- 5 CDE360 series AC drive dimensions

Appearance	AC drive model	Physical dimension(mm)				Installation dimension (mm)			Dimensional drawing
		H	H1	W	D	A	B	Aperture	
Single phase 220V									
W01	2S0R7	185		100	145	89	173	Φ5	C01
	2S1R5								
	2S2R2	225	200	110	170	80	213	Φ5	
Three phase 380V									
W01	4T0R7G/1R5L	185		100	145	89	173	Φ5	C01
	4T1R5G/2R2L								
	4T2R2G/3R7L								
	4T3R7G/5R5L	225	200	110	170	80	213	Φ5	
	4T5R5G/7R5L	265	240	130	190	91	253	Φ5	
	4T7R5G/011L								
Appearance	AC drive model	Physical dimension(mm)				Installation dimension (mm)			Dimensional drawing
		H	H1	W	D	A	B	Aperture	
W01	4T011G/015L	312	282	155	201	110	298	Φ6	C01

W01	4T011G/015L	312	282	155	201	110	298	Φ6	C01
W02	4T015G/018L	390	360	205	211	150	376	Φ6	
	4T018G/022L								
W03	4T022G/030L	480	450	250	243	180	460	Φ7	C02
	4T030G/037L								
	4T037G/045L								
W05	4T045G/055L	535	500	360	298	240	515	Φ9.5	C03
	4T055G/075L								
	4T075G/090L	587	552	394	310	260	567	Φ9.5	
	4T090G/110L	722	687	394	330	260	698	Φ12	
	4T110G/132L								
	4T132G/160L	800	755	460	360	380	770	Φ12	
	4T160G/185L								
	4T185G/200L								
	4T200G/220L	900	860	520	350	360	871	Φ12	
4T220G/250L									
W06	4T160G/185L	1265	1165	590	350	/	/	/	C04
	4T185G/200L								
	4T200G/220L								
	4T220G/250L								
	4T250G/280L	1405	1305	700	370	/	/	/	
	4T280G/315L								
	4T315G/355L								
	4T355G/400L								
	4T400G/450L					/	/	/	
4T450G/500L									
Three phase 480V									
W01	5T0R7G/1R5L	185		100	145	89	173	Φ5	C01
	5T1R5G/2R2L								
	5T2R2G/3R7L								
	5T3R7G/5R5L	225	200	110	170	80	213	Φ5	
	5T5R5G/7R5L	265	240	130	190	91	253	Φ5	
	5T7R5G/011L								
5T011G/015L	312	282	155	201	110	298	Φ6		
W02	5T015G/018L	390	360	205	211	150	376	Φ6	
	5T018G/022L								
	5T022G/030L	480	450	250	243	180	460	Φ7	C02

W03	5T030G/037L									
	5T037G/045L	530	500	280	243	210	510	Φ7		
W05	5T045G/055L	535	500	360	298	240	515	Φ9.5	C03	
	5T055G/075L									
	5T075G/090L	587	552	394	310	260	567	Φ9.5		
	5T090G/110L	722	687	394	330	260	698	Φ12		
	5T110G/132L									
	5T132G/160L	800	755	460	360	380	770	Φ12		
	5T160G/185L									
	5T185G/200L	900	860	520	350	360	871	Φ12		
	5T200G/220L									
5T220G/250L										
W06	5T160G/185L	1265	1165	590	350	/	/	/	C04	
	5T185G/200L									
	5T200G/220L									
	5T220G/250L									
	5T250G/280L	1405	1305	700	370	/	/	/		
	5T280G/315L									
	5T315G/355L									
	5T355G/400L						/	/		/
	5T400G/450L									
5T450G/500L										

2.6 CDE360 Keypad Physical Dimensions

2.6.1 Keypad A (LED)

Model: KEYA. Pure LED display, four bit. The physical appearance and dimensions are shown in the following figure.




Figure 2-3 KEYA

2.6.2 Keypad A Foundation

The foundation of keypad A is used together with keypad A for sheet metal housing or wall-mounting installation. The physical appearance and dimensions of the foundation are shown in the following figure.



Figure 2-4 The foundation of KEYA

2.6.3 Keypad B

Model: KEYB. Four bit LED and LCD screen display. The physical appearance and dimensions are shown in the following figure.




Figure 2- 5 KEYB

- Remark :** 1) LED keypad built-in all of CDE360 AC drives
2) LED+LCD display keypad optional(≥ 15 KW AC drive)

2.6.4 Keypad B Foundation

The foundation of keypad B is used together with keypad B for sheet metal housing or wall-mounting installation. The physical appearance and dimensions of the foundation are shown in the following figure.




Figure 2- 6 The foundation of KEYB

2.6.6 Dust Excluding Plate A

Used for the AC drive of W01 type appearance. Standard configuration is only one plate. Optional for the requirements of both sides. The physical appearance and dimensions are shown in the following figure.




Figure 2- 7 Dust excluding plate A

2.6.7 Dust Excluding Plate B

Used for the AC drive of W02 type appearance. Standard configuration is only one plate. Optional for the requirements of both sides. The physical appearance and dimensions are shown in the following figure.




Figure 2- 8 Dust excluding plate B

2.7 Selection Suggestion of AC Drive

When select the AC drive, following conditions such as the technical requirements of the AC drive, the application fields of the AC drive and the characteristics of the load should be explicit. At the same time, the adaptable motor, output voltage and rated output current should be considered comprehensively. As a result, the type and the running mode can be selected.

The fundamental principle is that the rated load current of the motor can not exceed the rated current of the AC drive. Generally, the user can select the matching capacity of the motor according to the user manual and compare the Rated motor current with the one of the AC drive. If doing so, the overload capacity of the AC drive is significant for the start and brake process.

If there is transient overload during the running, the load speed will vary according to the transient overload. And if the request for the accuracy of the speed is strict, please consider enlarging the power of the AC drive.

Fans and water pumps: the requirement for overload is not strict. Because the torque of the load is proportional to the square of the speed, the load is light when the speed is low (Here, roots blower is not included); and because these loads have no restrict requirements for the accuracy of the speed, the VF mode of square torque can be selected.

Constant torque loads: most loads have the characteristics of constant torque, but they have not restrict requirements for the accuracy of the speed and the dynamic performance. The application fields are as extruder, blender, conveyor belt, transport vehicle in the plant and the translational mechanism of the crane. In this instance, the V/F running mode of constant torque can be selected.

Controlled objectives which have requirements of certain dynamic and static indexes: these loads have the requirements for hard mechanical characteristics at low speed, so that the specification of dynamic and static indexes can match the productive technology. In this instance, the VF control or vector control can be selected.



2.8 Recommendation of Brake Resistance Selection

Table 2- 6 Brake resistance selection table of CDE360 series

AC drive voltage & power classes	Recommended power (kW)	Recommended resistance (Ω)	Brake Unit
Single phase 220V input			
2S0R7	0.15	100	Built-in
2S1R5	0.2	75	
Three phase 380V input			
4T0R7G/1R5L	0.45	≥ 150	Built-in (Standard)
4T1R5G/2R2L	0.45	≥ 150	
4T2R2G/3R7L	0.6	≥ 120	
4T3R7G/5R5L	0.7	≥ 100	
4T5R5G/7R5L	0.8	≥ 80	
4T7R5G/011L	1	≥ 65	
4T011G/015L	1.5	≥ 43	
4T015G/018L	2.0	≥ 32	
4T018G/022L	2.5	≥ 30	
4T022G/030L	3	≥ 24	
4T030G/037L	3.7	≥ 16	
4T037G/045L	5	≥ 14	External (Optional) 60A
4T045G/055L			
4T055G/075L	7	≥ 10	External (Optional) 80A
4T075G/090L	8.5	≥ 8	External (Optional) 150A
4T090G/110L	14	≥ 5	
4T110G/132L			
4T132G/160L			
4T160G/185L	20	≥ 3.5	External (Optional) 350A (CDBU300-350A-4)
4T185G/200L			
4T200G/220L	28	≥ 2.5	
4T220G/250L			
4T250G/280L	35	≥ 2.2	
4T280G/315L			
4T315G/355L	28 * 2	≥ 2.5 * 2	External (Optional) 350A * 2 (CDBU300-350A-4 * 2)
4T355G/400L			
4T400G/450L			
4T450G/500L			
Three phase 480V input			
5T0R7G/1R5L	0.45	≥ 200	Built-in (Standard)
5T1R5G/2R2L	0.45	≥ 200	
5T2R2G/3R7L	0.6	≥ 150	
5T3R7G/5R5L	0.7	≥ 120	
5T5R5G/7R5L	0.8	≥ 100	

5T7R5G/011L	1	≥ 75	
5T011G/015L	1.5	≥ 51	
5T015G/018L	2.0	≥ 39	
5T018G/022L	2.5	≥ 36	
5T022G/030L	3	≥ 29	
5T030G/037L	3.7	≥ 20	
5T037G/045L	5	≥ 18	External (Optional) 60A
5T045G/055L			
5T055G/075L	7	≥ 12	External (Optional) 80A
5T075G/090L	8.5	≥ 10	External (Optional) 150A
5T090G/110L	14	≥ 6	External (Optional) 150A
5T110G/132L			
5T132G/160L			
5T160G/185L	20	≥ 4.3	External (Optional) 350A (CDBU300-350A-4)
5T185G/200L			
5T200G/220L	28	≥ 2.5	
5T220G/250L			
5T250G/280L			
5T280G/315L	35	≥ 2.2	
5T315G/355L			
5T355G/400L	28 * 2	$\geq 2.5 * 2$	External (Optional) 350A * 2
5T400G/450L			
5T450G/500L			

Remarks:

- 1) Voltage and power classes is the only consideration in brake resistance selection.
- 2) " x " means there needs several groups of braking units and resistance to be used in parallel.
- 3) If external brake unit is needed, please refer to the related user manual of brake unit.

The data in the above table is only for reference. The user can select different resistance and power of the resistor based on actual needs (here, the resistance should not be less than the recommended value in the table, and the power of the resistor can be higher than the recommended value in the table). The brake resistance can be determined by the regenerative power of the motor in the actual system and is also related to the inertia of the system, deceleration time and potential energy load. The user can select the brake resistance based on the actual needs.

For systems with high inertia, rapid deceleration time and frequent braking, the brake resistor with high power and small resistance should be selected.

Selection of the Resistance

The consumption of the regenerative energy of the motor is almost entirely on the braking resistance.

According to the formula $U \times U/R = P_b$, the user can calculate the resistance of the braking resistor.

In the formula, U -----braking voltage of the system during the constant status (different systems have different brake voltage. As for 380VAC system, usually the braking voltage is 700V).

P_b -----braking power.

Selection of the Power

In theory, the power of the braking resistor should be consistent with the braking power. But considering actual conditions, the derating is 70 percent.

The formula is $0.7 \times P_r = P_b \times D$.

P_r refers to the power of the braking resistor.

D refers to the braking frequency (percentage of the regenerative process to the whole process), the selection of the braking frequency can be as follows based on the experience:

Elevator load is 20% to 30%; Winding load is 20% to 30%
Centrifuge load is 50% to 60%; Intermittent braking load is 5%;
Ordinary load is 10% (10% is enough for the ordinary load).



Chapter 3 Mechanical and Electrical Installation

3.1 Mechanical Installation

3.1.1 Requirements of Installation Environment

Item	Requirements	Item	Requirements
1	Good ventilation.	5	Free from direct sunlight.
2	Ambient temperature: $-10^{\circ}\text{C}\sim 40^{\circ}\text{C}$.	6	Free from combustible, corrosive gas and liquid.
3	Free from high temperature, humidity (less than 95%RH), no rainwater or other liquid drip.	7	Free from dust, oil dirt, floating fiber and metal powder.
4	Free from combustible objects, such as woods.	8	The installation base is stable with no vibration.
		9	Free from magnetic interference.

3.1.2 Installation Direction and Clearance

To ensure the heat dissipation of the product, please install the product vertically according to the following figure and never invert the installation.

When the installation is in the cabinet, try to use the mode of side-by-side installation. At the same time, to facilitate the heat dissipation, you should ensure that there is enough space around.




Figure 3- 1 CDE360 installation diagram

Table 3- 1 The dimension size of the installation clearance

AC drive power class (kW)	Installation size (mm)	
	A	B
≤ 15	≥ 30	≥ 100
18.5~30	≥ 50	≥ 200
≥ 37		≥ 300

Remarks during the mechanical installation:

- 1) Please install the AC drive vertically. If there are several AC drives in the cabinet, try to use the mode of side-by-side installation. When the cooling space can be guaranteed, please consider the cooling requirements of other components.
- 2) As for the installation clearance, please refer to Table 3-1.
- 3) For occasions which have upper and lower installation, please refer to Figure 3-1 and install the insulation guidance plate.
- 4) Please use the installation holder which contains incombustible materials.
- 5) For occasions which have metal powder, it is suggested that the heat sink is installed outside the cabinet.

3.1.3 Removal and Installation of the Keypad and Cover

3.1.3.1 Keypad A Removal and Installation

Removal: As shown on the following left figure, please press down the buckle refer to the direction of Arrow 1. Then uplift the keypad refer to the direction of Arrow 2. And the removal is completed.

Installation: As shown on the following right figure, please incline the keypad slightly towards the cover or the joint of the bottom side refer to the direction of Arrow 1. Then press down the keypad refer to the direction of Arrow 2 until hear a snap. And the installation is completed.




Figure 3-2 Keypad A removal & installation

3.1.3.2 Keypad B Removal and Installation

Removal: As shown on the following left figure, please press down the buckle refer to the direction of Arrow 1. Then uplift the keypad refer to the direction of Arrow 2. And the removal is completed.

Installation: As shown on the following right figure, please incline the keypad slightly towards the cover or the joint of the bottom side refer to the direction of Arrow 1. Then press down the keypad refer to the direction of Arrow 2 until hear a snap. And the installation is completed.




Figure 3-3 Keypad B removal & installation

3.1.3.3 The Cover Removal and Installation of W01~02 Type Appearance

Remarks: Keypad A must be removed first, and installed after the installation of the wiring and cover is completed.

Removal: As shown on the following left figure. Hand on the left and right sides of the shell, then follow the direction of the arrow 1 and press down the buckle of the cover. After the cover bounces upwards automatically, press down the bottom side of the cover by the thumb, then uplift the cover towards the direction of the arrow 2. And the removal of the cover is completed.

Installation: As shown on the following right figure. After the wiring is completed, follow the direction of the arrow 1 and press down the upper part of the cover into the two bayonets of the shell. Then follow the direction of the arrow 2 and press down the cover. When the click is heard, it shows that the cover is connected in place and the installation is completed.




Figure 3- 4 Cover removal & installation of the wall-mounted plastic housing AC drive

3.1.3.4 The Cover Removal and Installation of W03~04 Type Appearance

Remarks: Keypad B must be removed first, and installed after the installation of the wiring and cover is completed.

Removal: As shown on the following left figure. Unscrew two mounting screws at the shown position of the arrow 1 under the cover. Raise the cover according to the direction of the arrow 2 and push out the cover according to the direction of the arrow 3. As a result, the removal of the cover is complete.

Installation: As shown on the following right figure. Aim at the AC drive and put the cover into it.

Press the cover down according to the direction of the arrow 1. Then press the cover down according to the direction of the arrow 2, tighten the two mounting screws according to the arrow 3. As a result, the installation of the cover is complete.




Figure 3- 5 Cover removal & installation of the wall-mounted sheet metal housing AC drive

3.1.3.5 The Door Open and Close of W05~06 Type Appearance

Open: As shown on the following left figure. After unlock the key, press down the button of the door key according to the shown position of the arrow 1. Hold the buckle of the door key and turn it to the horizontal position anticlockwise. Pull the door open according to the shown direction of the arrow 2. And the door is open.

Close: As shown on the following right figure. Hold the buckle of the door key and turn it to the horizontal position. Close the door according to the shown direction of the arrow 1. Press the door down. Turn the buckle of the door key to the shown position of the arrow 2 clockwise, then press it down. When the click occurs, the buckle is put into place. Lock the key and draw it out. And the door is closed.




Figure 3- 6 Door open & close of the wall-mounted sheet metal housing AC drive

3.2 Electrical Installation




Figure 3- 7 Connection diagram of peripheral devices

3.2.1 Instructions of Peripheral Electrical Components

Table 3- 2 Instructions of peripheral electrical components of CDE360 AC drive

Name	Installation Position	Function Description
Breaker	The front end of the input circuit	The power system can be protected when the short circuit happens.
Contactors	Between the breaker and the AC drive	Start and stop the AC drive. Neither start and stop the AC drive frequently by switching the contactor on and off (less than twice per minute) nor use it to directly start the AC drive.
Input AC reactor	Input side of the AC drive	1) Improve the power factor of the input side. 2) Eliminate the higher harmonics of the input side effectively and prevent other devices from being damaged due to the distortion of the voltage waveform. 3) Eliminate the input current unbalance due to the unbalance between the power phases.
Input Noise filter	Input side of the AC drive	1) Reduce the external conduction and radiation interference of the AC drive. 2) Decrease the interference flowing from the AC drive to the power system.
DC reactor	Between the terminal P+ and terminal P1 of the AC drive	1) Improve the power factor of the input side. 2) Eliminate the higher harmonics of the input side effectively and decrease the external conduction and radiation interference.
Output AC reactor	Close to the output side of the AC drive	The output sides of the AC drive generally have much higher harmonics. When the motor is far from the AC drive, there is much distributed capacitance in the circuit. Certain harmonics may cause resonance in the circuit and bring about the following two impacts: 1) Degrade the motor insulation performance and damage the motor in the long run. 2) Generate large leakage current and cause frequent AC drive protection trips.

3.2.2 Selection Guidance of Peripheral Electrical Components

Note: Voltage and power classes is the only consideration in peripheral electrical parts selection.

Table 3- 3 Recommended peripheral electrical parts selection guidance of the CDE360 series AC drive

AC drive voltage & power classes	Breaker MCCB (A)	Contactor (A)	Input wire (mm ²)	Output wire (mm ²)	Ground wire (mm ²)	Control wire (mm ²)
Three phase 380V input						
4T0R7G/1R5L	16	10				
4T1R5G/2R2L	16	10	2.5	2.5	≥ 2.5	1
4T2R2G/3R7L	16	10				
4T3R7G/5R5L	25	16				
4T5R5G/7R5L	32	25	4	4	≥ 4	
4T7R5G/011L	40	32				
4T011G/015L	63	40				
4T015G/018L	63	40	6	6	≥ 6	
4T018G/022L	100	63				
4T022G/030L	100	63	10	10	≥ 10	
4T030G/037L	125	100	16	16	≥ 16	
4T037G/045L	160	100				
4T045G/055L	200	125	25	25	≥ 16	1
4T055G/075L	200	160	35	35		
4T075G/090L	250	160	50	50	≥ 25	
4T090G/110L	250	200	70	70	≥ 35	
4T110G/132L	350	350				
4T132G/160L	400	400	95	95	≥ 50	
4T160G/185L	500	400	120	120	≥ 60	
4T185G/200L	600	600	150	150	≥ 75	
4T200G/220L	600	600	185	185	≥ 95	
4T220G/250L	600	600	120*2	120*2	≥ 120	
4T250G/280L	800	600				
4T280G/315L	800	800	150*2	150*2	≥ 150	
4T315G/355L	800	800				
4T355G/400L	1000	1000	185*2	185*2	≥ 185	
4T400G/450L	1000	1000				
4T450G/500L	1250	1250				
Three phase 480V input						
5T0R7G/1R5L	16	10				
5T1R5G/2R2L	16	10	2.5	2.5	≥ 2.5	1
5T2R2G/3R7L	16	10				
5T3R7G/5R5L	25	16				
5T5R5G/7R5L	32	25	4	4	≥ 4	
5T7R5G/011L	40	32				
5T011G/015L	63	40				

5T015G/018L	63	40	6	6	≥ 6
5T018G/022L	100	63			≥ 10
5T022G/030L	100	63	10	10	≥ 16
5T030G/037L	125	100	16	10	
5T037G/045L	160	100	16	16	
5T045G/055L	200	125	25	25	
5T055G/075L	200	125	35	25	≥ 25
5T075G/090L	250	160	50	50	≥ 35
5T090G/110L	250	160	70	70	≥ 35
5T110G/132L	350	350	70	70	≥ 50
5T132G/160L	400	400	95	95	≥ 60
5T160G/185L	500	500	120	120	≥ 150
5T185G/200L	600	600	150*2	150*2	
5T200G/220L	600	600			
5T220G/250L	600	600	185*2	185*2	≥ 185
5T250G/280L	800	600			
5T280G/315L	800	800	150*3	150*3	≥ 200
5T315G/355L	800	800			
5T355G/400L	800	800			
5T400G/450L	1000	1000	185*3	185*3	
5T450G/500L	1000	1000			

3.2.3 Terminals Wiring Diagram of the AC drive




Figure 3- 8 The wiring diagram of CDE360 Vector Control AC drive

Remarks:

- Terminal '⊕' represents terminals of the main circuit and '○' represents terminals of the control loop.
 - The AC drive and the motor should be reliably connected to the ground.
 - If the motor and AC drive can not be connected to the ground. Please connect the ground terminal of the motor to the PE terminal of the AC drive.
 - AI2/AO2 jumper is 'mA', AI1/AO1 jumper is 'V'.
- 485 balance resistor jumper in the off position

3.2.4 Power Terminals of the Main Circuit



- When wiring, ensure that the power switch is off. Otherwise, you may get electric shock.
- The wiring personnel should be one professional. Otherwise, the equipment or personal body may be damaged.
- The connection to the ground should be reliable. Otherwise, it may result in an electric shock or a fire.
- Ensure that the rated value of the power supply is consistent with the one of the AC drive. Otherwise, the AC drive may be damaged.
- Ensure that the rated capacity of the motor matches the one of the AC drive. Otherwise, it may result in the damage to the motor or the protection of the AC drive.
- Do not connect the power supply to U,V,W terminals. Otherwise, it may result in the damage to the AC drive.
- Do not connect the braking resistance to P+ and P- terminals of the DC bus directly. Otherwise, it may result in a fire alarm.



Figure 3-9

CDE360-4T (5T) 0R7G/1R5L~2R2G/3R7L

Figure 3-10

CDE360-2S0R7~1R5




Figure 3- 11

CDE360-2S2R2

CDE360-4T (5T) 3R7G/5R5L




Figure 3-12

CDE360-4T (5T) 5R5G/7R5L~018G/022L




Figure 3-13

CDE360-4T (5T) 022G/030L~037G/045L





Figure 3-14

CDE360-4T (5T) 045G/055L~110G/132L




Figure 3-15

CDE360-4T (5T) 132G/160L~400G(Wall-mounted)





Figure 3-16

CDE360-4T (5T) 160G/185L~500G (Cabinet)

Table 3- 4 Main circuit terminals instruction of the AC drive

Terminal Sign	Name	Description
R,S,T	Three-phase input terminals of the power supply	Connecting points of the three-phase AC input power
P+,P-	The positive and negative terminals of the DC bus	Input point of the common DC bus
P+,PB	Connecting terminals of the braking resistance	Connecting points of the braking resistance
P1,P+	Connecting terminals of the external reactor	Connecting points of external reactor
U,V,W	Output terminals of the AC drive	Connect the three-phase motor
	Earthing terminal	Earthing terminal

Remarks:

A. Input power supply R,S,T

Connect R,S,T to the input sides of the AC drive. The phase sequence is not needed.

B. P+,P- terminals of the DC bus

Terminal (+) and (-) of the DC bus have residual voltage after the power is switched off. After the indicator of the charge goes off and the residual voltage is less than 36V, you can touch the terminals (+) and (-) of the DC bus. Otherwise, it may result in an electric shock. The cable length of the braking unit should not be longer than 10 meters. Use twisted pair wire or pair wires for parallel connection.

C. P+,PB terminals of the braking resistance

As for the types which have braking unit inside the machine, the connecting terminals of the braking resistance can be valid. The selection of the braking resistance should be consistent with the recommended values and the cable length should be less than 5 meters. Otherwise, it may result in the damage to the AC drive. Do not connect the braking resistance to the DC bus directly. Otherwise, it may result in the damage to the AC drive or a fire.

D. P1,P+ Connecting terminals P1,P+ of the external reactor

Before connect the external reactor to the AC drive, the jumper between P1 and P+ terminal should be removed.


E. U,V,W Output U,V,W of the AC drive

Do not connect the capacitor or surge absorber to the output terminals of the AC drive. Otherwise, it may result in the frequent protection or the damage to the AC drive. When the cable length of the motor is too long, it can result in the electric resonance due to the distributed capacity. Thus it will result in the damage to the insulation of the motor or generating big leakage current. As a result, it can trip the over current protection of the AC drive. If the cable length of the motor is longer than 100 meters, the AC output reactor should be installed.

F. Earthing terminals

Connect to the ground reliably. The resistance of the earthing line should be less than 0.1Ω.

Otherwise, it may result in the malfunction of the device or even the damage to the

device. Do not connect the earthing terminal  to the neutral wire of the power supply.

3.2.5 Control Terminals and Wiring Description

3.2.5.1 Terminal Arrangement of the Control Circuit




Figure 3- 14 Pin definition of keypad interface





Figure 3- 15 Terminal arrangement of the control board of CDE360 vector VFD

Noted :A11 and AO1 jumper are 'V'(voltage) ,A12 and AO2 jumper are 'mA'(current) . 485 balance resistor jumper in the off position

Function Description of the Terminals on Control Board

Table 3- 5 Function description of the terminals on control board

Type	Sign	Name	Function Description
Power Supply	+10V (~GND)	10V Reference Power Supply	10V/30mA, usually is used for the power supply of the analog signal.
	24V (~COM)	24V Output Power Supply	24V/200mA, usually is used for the power supply of the digital signal.
Analog Input	AI1 (~GND)	Analog Input Terminal 1	Input range: -10V~10V/0~20mA, decided by the jumper.
	AI2 (~GND)	Analog Input Terminal 2	Input resistance: 120KΩ (voltage input), 250Ω (current input). Jumper CJ1 on the control board is used for AI1 and jumper CJ2 on the control board is used for AI2.
Analog Output	AO1 (~GND)	Analog Output Terminal 1	Voltage Input range: 0~10V; load≤10mA. Current Input range: 0~20mA; load≤500Ω. The output signal can be used for the voltage or current type. Jumper CJ3 on the control board is used for AO1
Digital Input	X1	Digital Input Terminal 1	1) Optical coupling isolation, compatible with dual polarity input. 2) Input resistance: 4.7KΩ. 3) Input voltage range: 9~30V. 4) X6/FI can be used for common digital input terminal and be compatible with high-speed pulse (0~100KHz) input.
	X2	Digital Input Terminal 2	
	X3	Digital Input Terminal 3	
	X4	Digital Input Terminal 4	
	X5	Digital Input Terminal 5	
	X6/FI	Digital Input Terminal 6 & high-speed pulse input terminal	
Digital Output	Y1 (~COM)	Digital output terminal 1	1) Optical coupling isolation, open collector output. 2) Output voltage and current: 24VDC, ≤50mA.
	Y2/FO (~COM)	Digital output terminal 2 & high-speed pulse output	Running frequency: < 500Hz. Y2/FO can be used for common digital output

		terminal	terminal, at the same time, it can also be used for high-speed pulse (0~100KHz) output.
Relay Output	TB1(~TA1)	T1 normally close terminal	1) TA1 is used for the common port the relay T1 and TA2 is used for the common one of the relay T2. 2) Contactor driving ability: AC 250V,3A,COSΦ=0.4; DC 30V,1A.
	TC1(~TA1)	T1 normally open terminal	
	TB2(~TA2)	T2 normally close terminal	
	TC2(~TA2)	T2 normally open terminal	
Communication	485+	The positive terminal of RS485 differential signal	RS485 communication between the upper machine and the AC drive.
	485-	The negative terminal of RS485 differential signal	
Shielding		Shielding earthing	Connect it to shielding earthing of the signal cable.
Auxiliary interface	J4	The interface of the external cards	20 terminals, which are used for connecting the external cards with special functions.

Wiring Description of the Terminals on Control Board

Wiring description of the analog input terminals

The shielded cable is needed cause weak analog voltage signal is easily interfered.

Usually, the length of the cable should be less than 20 meters. For occasions that some analog signals suffer severe interference, filter capacitors or ferrite magnetic core should be installed at the analog signal source. As shown in the following diagrams.




Figure 3- 96 Wiring diagram 1 of analog input




Figure 3- 17 Wiring diagram 2 of analog input

Digital Input Terminal

Generally, the length of the shielding cable should be no longer than 20 m. When the active driving is adopted, necessary filtering measures should be taken to prevent the interference to the power supply. It is recommended to use the contact control mode. The connection is valid for the positive logic and the disconnect is valid for the negative logic.

Wiring of digital input terminals

(I) The stem nodes connection mode of common cathode




Table 3- 18 The stem nodes connection mode of common cathode

(II)The connection mode of source




Table 3- 19 The connection mode of source

Chapter 4 Operation, Display and Application

4.1 Keypad Interface



Figure 4- 1 LED Keypad (Keypad A) Figure 4- 2 LED and LCD display Keypad (Keypad B)

4.2 Keypad Indicators


Table 4- 1 Keypad indicators description of CDE500 series AC drive

Indicator	designation	implication
Units indicators	Hz	Frequency Indicator Current display parameter units is Hertz.
	A	Current Indicator Current display parameter units is Ampere.
	V	Voltage Indicator Current display parameter units is Volt.
	Hz + A	Speed Indicator Current display parameter units is Round Per Minute.
	A + V	Percentage Indicator Current display parameter units is Percentage.
	Hz + V	MPa Indicator Current display parameter units is Mega Pascal.
Status indicators	MON*	Command source Indicator OFF: Keypad control; ON: Terminal control FLASH: Communication control
	RUN	Run/Stop Indicator ON: Run state; OFF: Stop state FLASH: Deceleration state
	DIR*	Direction Indicator OFF: Forward direction ON: Reverse direction
	TRIP*	Fault state Indicator AC drive being alarm or fault state

Note: Mark “*” means for LED keypad (Keypad A) only.

4.3 Function of the Keypad Key

Table 4- 2 Function of the Keypad Key on CDE500 series AC drive

Key	Name	Function
PRG	Programming/ Return	1) Enter level 1 menu. 2) Cancel or exit a certain menu.
ENTER	Enter	1. Enter the menu level by level. 2. Confirm the parameter setting.
JOG	JOG	JOG running control of keypad control source.
>>	Shift	1. Select the displayed parameters in turn. 2. Select the digit to be modified when modifying parameters.
▷ ▷ (IP54 series)		
RUN	RUN	Start the AC drive.
STOP/RST	Stop/Reset	1. Stop the AC drive. 2. Reset the fault state.
	Increase/ Decrease & Enter	1. Increase/decrease the modifying digit. 2. Change the value of the reference decided by parameter C0.18 . 3. The same as Enter key when press.
△▽ (IP54 series)		

4.4 Keypad Display

LED screen can only display 4 digits. If the parameter value is more than 4 digits, the display method is shown in the table below.

Note: If the parameter can be modified, each digit can be switched by **SHIFT** key.

Table 4-3 Five digits shown method of LED screen

Actual value	Display value	After press the SHIFT key
12345	1234.	2345
1234.5	1234	234.5
123.45	123.4	23.45
12.345	12.34	2.345
0.1234	0.123	1234
0.0034	0.003	0034
0.0004	0.000	0004

Common LDE display sign.

Table 4-4 Common LDE display sign

Sign	Meaning
8.8.8.8.	AC drive is in initialization after power on. LCD screen shows non character.
dEFt	Being restoring default settings of the parameters. LCD screen will show 'Restoring default setting'.
Load	Being uploading the parameters. LCD screen will show 'Uploading'. Please wait for a few minutes.
Copy	Being downloading the parameters. LCD screen will show 'Downloading'. Please wait for a few minutes.
TUNE	The motor parameters is being auto-tuning. LCD screen will show 'Motor Auto-tuning'. Please wait for a few minutes.
P.SEt	User password is set successfully.
P.CLr	User password is cleared successfully.

Tips:

The Keypad with LCD screen can display two monitor parameters at the same time.

- LCD screen can display 2 lines of characters.
- Move the cursor to first line on LCD screen, press **SHIFT** key to select the first monitor parameter.
- Press **ENTER** key the move the cursor the second line, press **SHIFT** key to select the second monitor parameter.

4.4 Menu Introduction

Three level menu:

Level 1 : like **—b2—**, function code group, the group name will display on the LCD screen.

Level 2 : like **b2.01**, function code, the function code name will display on the LCD screen.

Level 3 : like **50.00**, function code setting value, the value range will display on the LCD screen.

Enter menu, the blinking digit can be modified by rotating the Rotary knob, and can be switched to another digit by pressing **SHIFT** key

Return to Level 2 menu from Level 3 by pressing **PRG** or **ENTER**.

- Pressing **Enter** key will save the parameter value, and go to the next parameter in Level 2 menu.
- Pressing **PRG** key will not save the parameter value, and just return to current parameter in Level 2 menu.




Figure 4- 3 The three-level menu operation procedure

In Level 3 menu, the digit to be modified change from low digit to high digit when use **SHIFT** key. When the parameter reaches maximum or minimum value, it can't be increased or decreased.

In Level 3 menu, if the parameter has no blinking digit, it means that the parameter cannot be modified. This may cause by:

- 1) This is a read-only parameter, such as the monitor parameters.
- 2) This parameter cannot be modified in the running state, such as the motor related parameters.

4.5 Monitor Parameters

After power on the AC drive, monitor parameters can be displayed through **SHIFT** key. And the parameters H0.01, H0.02, and H0.03 determine which monitor parameter can be displayed. Total of 24 monitor parameters can be displayed in running state. Total of 13 monitor parameters can be displayed in stop state.

Steps of select monitor parameters.

- Choose the parameters to be displayed.
- Sum the value of every parameter bit
- .Set the summation value to the related parameter.

For example, if the Running frequency, Bus voltage, and Pulses Count value need to be displayed, H0.03 shall be set to the summation value of 32773 ($1+4+32768 = 32773$).

The LCD keypad will show the meaning of parameters on LCD screen if the AC drive has no fault. Change to the second line of LCD screen by press **Enter**, and an additional displayed parameter can be chose.

The LCD keypad will show the meaning of fault code on LCD screen. Such as the LCD screen will display "Current detection fault " when LED display "**Er22**".

When observing the monitor parameters, value of the reference determined by **C0.18** can also be changed by adjusting the rotary knob. And the keypad interface will return to show monitor parameters again 3 seconds after the adjustment.

The keypad interface will return to show monitor parameters automatically if there is no key pressing action in 1 minute.

4.6 Parameters Upload and Download

Parameters upload and download is a function of parameters backup and copy. It is convenient for user configuring the parameters among AC drives.

Set H0.04 to 3 will begin uploading the parameters value to the keypad. And the LCD screen will show 'Loading' simultaneously.

Set H0.04 to 4 will begin downloading the parameters value to the control board. And the LCD screen will show 'Downloading' simultaneously.

Keypad will not respond any key press in whole upload or download process. After upload or download is completed, the keypad will automatically return to normal display. And the value of function code H0.04 will be changed to 0.

Download action will be invalid if there is no data in keypad.

4.7 Password and Parameter Setting

The AC drive provides the user password protection function.

When **H0.00** is set to a non-zero value, the value is the user password. Set **H0.00** to the same value for the 2 time in a row, and the password will be set successfully. Meanwhile, the LED will display 'P.SET' and the LCD screen will display 'Setting password succeed'. The user password will be active if there is no keypad operation in 5 minutes.

If a long line '----' displays on the LED screen when you press **PRG**, 'Please enter the password' may show on the LCD screen, and then the correct user password needs to be entered. Otherwise you will see non parameter. The user password will be active again if there is no keypad operation 5 minutes after entering the correct password.

Set **H0.00** to zero for the 2 time in a row, and the password will be cleared. Meanwhile, the LED will display 'P.Clr' and the LCD screen will display 'Clear password succeed'.

Example 1: Set the user password of H0.00 to "0003" (digit with underline means it's in an edit state).




Figure 4-4 Set user password example

Example 2: Set parameter value from "50.00" to "100.00" (digit with underline means it's in an edit state).




Figure 4-5 Parameter edit example 1

Example 3: Set parameter value from "100.00" to "1.00" (digit with underline means it's in an edit state).




Figure 4-6 Parameter edit example 2

4.8 User Defined Parameters

Please refer to the parameters description of group P0.

4.9 Non-basic Menu Display

Two non-basic menu is determined by H0.05, as shown in the table below.

Table 4- 5 Menu display types

H0.05	Menu display type
0	Basic menu. Displayed all parameters.
1	User-defined parameters. Display group P0 only.
2	Non factory setting parameters. Display the parameters which have been modified.

For example

A. Steps of changing menu type from basic to user-defined.

1. Set **H0.05**=1.
2. Return Level 0 menu by pressing **PRG** key.
3. Press **PRG** again, and the keypad will go into user-defined parameters display model.

B. Steps of going back to basic menu form user-defined.

1. Find and set **H0.05**=0.
2. Return Level 0 menu by pressing **PRG** key;
3. Press **PRG** again, and the keypad will go into basic parameters display model.

Chapter 5 Parameter List Table

The symbols in the parameter list table are described as follows:

“0”: The parameter cannot be modified when the AC drive is in the running state.

Classification	Function Code	Description
Group A Monitor and Diagnostics	A0	Monitor
	A1	Fault & Diagnostics
Group b Basic Running Parameters	b0	Basic Parameters
	b1	Run & Stop Logic
	b2	Frequency Source
Group C Input and Output Terminals	C0	Digital Input
	C1	Digital Output
	C2	Analog Input
	C3	Analog Output
	C4	Pulse Input/Output
Group d Motor Control	C5	Virtual Digital Input/Output
	d0	Motor Control
	d1	Motor Parameters
	d2	Speed Control
	d3	Torque Control
	d5	Motor 2 Parameters
Group E Expanding Application Functions	d6	Motor 2 Speed Control
	E0	JOG
	E1	Skip Frequency
	E2	Multi-Reference
	E3	Simple PLC
	E4	Acc & Dec Time
	E5	PID
	E6	Multi-Pump Control
	E7	Swing Frequency
	E8	Droop Control
	E9	Power Loss Ride Through
Group F Protection and Reset	EA	External Brake
	Eb	Supervision
Group H System Parameters and Analog Calibration	F0	Protection
	F1	Auto Reset
Group L Communication Setting	H0	System Parameters
	H1	AI/AO Calibration
	L0	Communication Setting
Group P User-defined and Debug Parameters	L1	Point-point Communication
	L2	Encoder Setting
Group P User-defined and Debug Parameters	P0	User-defined Parameters
	P1	Debug Parameters

Parameter List Table

A0 Monitor

Function Code	Name	Range	Default	Step	Description
A0.00	Running frequency	0.00~b0.00	0.00	0.01Hz	
A0.01	Setting frequency	0.00~b0.00	0.00	0.01Hz	
A0.02	DC bus voltage	0.0~3000.0	0.0	0.1V	
A0.03	Output voltage	0~1500	0	1V	
A0.04	Output current	0.00~655.35	0.00	0.01A	Fraction point decided by AC drive type
A0.05	Output torque	-300.0~300.0	0.0	0.1%	Unit is percentage. Base value is motor rated torque
A0.06	Output power	0.0~2000.0	0.0	0.1kw	AC drive output active power
A0.07	Motor speed	0~65535	0	1RPM	
A0.08	Main frequency A	0.00~b0.00	0.00	0.01Hz	
A0.09	Auxiliary frequency B	0.00~b0.00	0.00	0.01Hz	
A0.10	AC drive status word	0~65535	0	1	
Bit0: ready Bit4: running direction Bit9: frequency reached Bit13: auto tuning Bit1: running Bit6/Bit5: control source Bit11/Bit10: Acc/Dec status Bit14: Zero speed Bit2: fault Bit7: run Enable Bit12: JOG running Bit15: RESERVED Bit3: warning Bit8: bypass					
A0.11	AI1 Voltage	-10.00~10.00	0.00	0.01V	Current signal needs to be changed as voltage signal. 0mA equals to 0V, 20mA equals to 10V.
A0.12	AI2 Voltage	-10.00~10.00	0.00	0.01V	
A0.13	AI3 Voltage	-10.00~10.00	0.00	0.01V	
A0.14	AO1 voltage	0.00~10.00	0.00	0.01V	
A0.15	AO2 voltage	0.00~10.00	0.00	0.01V	
A0.16	X terminals status word	0~1023	0	1	
One bit corresponds one terminal status: 0: inactive 1: active Bit0: X1 (1) Bit2: X3 (4) Bit4: X5 (16) Bit6: X7 (64) Bit8: X9 (256) Bit1: X2 (2) Bit3: X4 (8) Bit5: X6 (32) Bit7: X8 (128) Bit9: X10 (512)					
A0.17	Y terminals status word	0~511	0	1	
One bit corresponds one terminal status: 0: inactive 1: active Bit0: Y1 (1) Bit2: Y3 (4) Bit4: T2 (16) Bit6: T4 (64) Bit8: T6 (256) Bit1: Y2 (2) Bit3: T1 (8) Bit5: T3 (32) Bit7: T5 (128)					

Function Code	Name	Range	Default	Step	Description
A0.18	FI frequency	0.00~100.00	0.00	0.01kHz	Display the X6/FI frequency
A0.19	FO frequency	0.00~100.00	0.00	0.01kHz	Display the Y2/FO high speed pulse output frequency
A0.20	PID reference	0.0~100.0	0.0	0.1%	Its unit and decimal are depended on engineering unit.
A0.21	PID feedback	0.0~100.0	0.0	0.1%	
A0.22	PID deviation	-100.0~100.0	0.0	0.1%	
A0.23	PID output	-100.0~100.0	0.0	0.1%	
A0.24	PLC stage	0~15	0	1	
A0.25	Pulse counter	0~65535	0	1	
A0.26	Actual length	0~65535	0	1m	Dividing the number of pulses by E7.08.
A0.27	Linear speed	0.0~6553.5	0.0	0.1m/Min	This parameter shows the linear speed and its unit is m/Min
A0.28	Remaining time	0.0~6553.5	0.0	0.1Min	This parameters will show the remaining time when the timing function is enabled.
A0.29	Swing center frequency	0.00~b0.00	0.00	0.01Hz	It is decided by the current frequency source. And it shows the center frequency of swing frequency function.
A0.30	Load speed	0~65535	0	1	Output frequency multiplied by H0.08 .
A0.31	Feedback speed	0~b0.00	0.00	0.01Hz	Showing the actual output frequency.
A0.32	Multi pump status word	0000~4444	0000	1	This parameter is used to indicate the status of each motor in multi-pump operation process.
0: in interlock or not used 2: wait for switching 4: connect to AC drive 1: ready 3: connect to power grid Unit's digit:: 1# pump status Hundred's digit:: 3# pump status Ten's digit:: 2# pump status Thousand's digit: 4# pump status					

Function Code	Name	Range	Default	Step	Description
A0.33	Encoder detection speed	-320.00~320.00	0.00	0.01Hz	indicate the motor speed from Encoder detection
A0.34	Z pulse counter	0~65535	0	1	
A0.35	Resolver position	0~4095	0	1	
A0.36	Reference voltage for V/f separation	0~b0.07	0	1V	
A0.37	Output voltage for V/f separation	0~b0.07	0	1V	
A0.38	Target torque	-300.0~300.0	0.0	0.1%	Target torque which is used in torque control mode
A0.39	Upper torque limit	0.0~300.0	0.0	0.1%	The max allowable torque in vector control mode
A0.40	Communication setting	-100.00~100.00	0.00	0.01%	Display the value located in 0x6400 sent by communication.
A0.41	Point-to-point send data	-100.00~100.00	0.00	0.01%	Indicate the data sent from master in point to point control mode
A0.42	Point-to-point receive data	-100.00~100.00	0.00	0.01%	Indicate the data received by slave in point to point control mode
A0.52	Power on time	0~65535	0	1Min	Current power on time, its unit is Min
A0.53	Running time	0.0~6553.5	0.0	0.1Min	Current running time, its unit is 0.1Min
A0.54	Accumulative power-on day	0~9999	0	1Day	
A0.55	Accumulative power-on hour	0.00~23.99	0.00	0.01h	
A0.56	Accumulative running day	0~9999	0	1Day	
A0.57	Accumulative running hour	0.00~23.99	0.00	0.01h	
A0.58	Accumulative power consumption	0~65535	0	1kwh	

Function Code	Name	Range	Default	Step	Description
A0.59	Motor temperature	0.0~300.0	0.0	0.1°C	This value is from PT100/PT1000 optional card.
A0.60	Inverter module temperature	-40.0~125.0	0.0	0.1°C	
A0.61	Rectifier module temperature	-40.0~125.0	0.0	0.1°C	

A1 Fault & Diagnostics

Function Code	Name	Range	Default	Step	Description
A1.00	1st(latest) fault type	0~54	0	1	
<p>0: No fault 1: Hardware over voltage during acceleration 2: Hardware over voltage during deceleration 3: Hardware over voltage during constant speed 4: Software over voltage during acceleration 5: Software over voltage during deceleration 6: Software over voltage during constant speed 7: Under voltage 8: Hardware over current during acceleration 9: Hardware over current during deceleration 10: Hardware over current during constant speed 11: Software over current during acceleration 12: Software over current during deceleration 13: Software over current during constant speed 14: IGBT saturation trip during acceleration 15: IGBT saturation trip during deceleration 16: IGBT saturation trip during constant speed 17: Heatsink of rectifier overheat 18: Heatsink of inverter overheat 19: Input phase loss 20: Output phase loss 21: Soft-startup resistor fault 22: Current detection fault 23: CBC fault 24: AC drive over load 25: Motor overload 26: Motor underload 27: Motor overheat</p> <p>28: Motor shortcircuit to ground fault 29: External fault 30: Keypad communication fault 31: RS485 communication fault 32: Optional card communication fault 33: Optional card connection fault 34: Auto tune fault 35: PID feedback over range 36: EEPROM R/W fault 37: Parameter setting fault 38: Accumulative power-on time reached 39: Accumulative running time reached 40: Motor switchover during running status 41: Too large speed deviation 42: Motor over-speed 43: Flux pole detection fail 44: UVW signal feedback fault 45: Encoder fault 46: User-defined fault 1 47: User-defined fault 2 48: Motor in current stall status 49: Motor in voltage stall status 50: Motor in frequency drop status as DC bus voltage drop 51: System fault 52: Interlock warning during multi-pump operation 53: Soft start current limiting resistor overload 54: Sleep status</p>					

Function Code	Name	Range	Default	Step	Description
A1.01	Output frequency upon 1st(latest) fault	0.00~b0.00	0.00	0.01Hz	Same As A0.00
A1.02	Output current upon 1st(latest) fault	0.00~655.35	0.00	0.01A	Same As A0.04
A1.03	DC bus voltage upon 1st(latest) fault	0.0~6553.5	0.0	0.1V	Same As A0.02
A1.04	X terminals status word upon 1st(latest) fault	0~1023	0	1	Same As A0.16
A1.05	Y terminals status word upon 1st(latest) fault	0~511	0	1	Same As A0.17
A1.06	AC drive status word upon 1st(latest) fault	0~65535	0	1	Same As A0.10
A1.07	Inverter module temperature upon 1st(latest) fault	-40.0~125.0	0.0	0.1°C	Same As A0.60
A1.08	Power-on time upon 1st(latest) fault	0~65535	0	1Min	Same As A0.52
A1.09	Running time upon 1st(latest) fault	0.0~6553.5	0.0	0.1Min	Same As A0.53
A1.10	Accumulative running day upon 1st(latest) fault	0~9999	0	1Day	Same As A0.56
A1.11	Accumulative running hour upon 1st (latest) fault	0.00~23.99	0.00	0.01h	Same As A0.57
A1.12	2nd fault type	0~54	0	1	Same As A1.00~A1.11
A1.13	Output frequency upon 2nd fault	0.00~b0.00	0.00	0.01Hz	
A1.14	Output current upon 2nd fault	0.00~655.35	0.00	0.01A	
A1.15	DC bus voltage upon 2nd fault	0.0~6553.5	0.0	0.1V	
A1.16	X terminals status word upon 2nd fault	0~1023	0	1	
A1.17	Y terminals status word upon 2nd fault	0~511	0	1	
A1.18	AC drive status word upon 2nd fault	0~65535	0	1	
A1.19	Inverter module temperature upon 2nd fault	-40.0~125.0	0.0	0.1°C	
A1.20	Power-on time upon 2nd fault	0~65535	0	1Min	
A1.21	Running time upon 2nd fault	0.0~6553.5	0.0	0.1Min	

Function Code	Name	Range	Default	Step	Description
A1.22	Accumulative running day upon 2nd fault	0~9999	0	1Day	
A1.23	Accumulative running hour upon 2nd fault	0.00~23.99	0.00	0.01h	
A1.24	3rd fault type	0~54	0	1	Same As A1.00~A1.11
A1.25	Output frequency upon 3rd fault	0.00~b0.00	0.00	0.01Hz	
A1.26	Output current upon 3rd fault	0.00~655.35	0.00	0.01A	
A1.27	DC bus voltage upon 3rd fault	0.0~6553.5	0.0	0.1V	
A1.28	X terminals status word upon 3rd fault	0~1023	0	1	
A1.29	Y terminals status word upon 3rd fault	0~511	0	1	
A1.30	AC drive status word upon 3rd fault	0~65535	0	1	
A1.31	Inverter module temperature upon 3rd fault	-40.0~125.0	0.0	0.1°C	
A1.32	Power-on time upon 3rd fault	0~65535	0	1Min	
A1.33	Running time upon 3rd fault	0.0~6553.5	0.0	0.1Min	
A1.34	Accumulative running day upon 3rd fault	0~9999	0	1Day	
A1.35	Accumulative running hour upon 3rd fault	0.00~23.99	0.00	0.01h	

b0 Basic Parameters

Function Code	Name	Range	Default	Step	Description
b0.00 ^①	Max frequency	30.00~600.00	50.00	0.01Hz	This parameter define the Max allowable output frequency.
b2.07=2, The maximum frequency limit is 650Hz; b2.07=1, The maximum frequency limit is 3500Hz					
b0.01 ^①	Source of Upper limit frequency	0~5	0	1	
0: b0.02 1: AI1 2: AI2 3: AI3 4: X6/FI 5: Communication					
b0.02	Digital setting of upper limit frequency	b0.03~b0.00	50.00	0.01Hz	
b0.03	Lower limit frequency	0.00~b0.02	0.00	0.01Hz	
b0.04	Acceleration time 1	0.1~6000.0	Module dependent	0.1Sec	
b0.05	Deceleration time 1	0.1~6000.0	Module dependent	0.1Sec	

Function Code	Name	Range	Default	Step	Description
b0.06 ^①	Motor rated power	0.1~999.9	Module dependent	0.1kw	
b0.07 ^①	Motor rated voltage	1~2000	Module dependent	1V	
b0.08 ^①	Motor rated current	0.01~655.35		0.01A	
b0.09 ^①	Motor rated frequency	10.00~b0.00	50.00	0.01Hz	
b0.10 ^①	Motor rated speed	1~65535	1460	1RPM	
b0.11	Command Source	0~2	0	1	
0: Keypad		1: I/O terminal		2: Communication	
b0.12 ^①	Application setting	0~13	0	1	
0: General 1: PID application 2: Constant pressure water supply of one AC drive with two pumps 3~13: Reserved					

b1 Run & Stop logic

Function Code	Name	Range	Default	Step	Description
b1.00 ^①	Acceleration/Deceleration mode	0~1	0	1	0: Linear 1: S Curve
b1.01 ^①	Time proportion of S-curve start segment	0.0~(100.0-b1.02)	30.0	0.1%	
b1.02 ^①	Time proportion of S-curve end segment	0.0~(100.0-b1.01)	30.0	0.1%	
b1.03	Startup frequency	0.00~50.00	0.00	0.01Hz	
b1.04 ^①	Startup frequency holding time	0.0~100.0	0.0	0.1Sec	
b1.05	Start mode	0~1	0	1	
0: Ramp start from startup frequency		1: Flying start			
b1.06 ^①	Flying start mode	0~2	0	1	
0: From frequency at stop		1: From zero speed		2: From maximum frequency	
b1.07 ^①	Flying start current	50.0~200.0	90.0	0.1%	The current limit value of flying start process
b1.08	flying start speed	1~100	5	1	
b1.09 ^①	V/f coefficient for flying start	30.0~100.0	100.0	0.1%	
b1.10	Stop mode	0~1	0	1	0: Ramp stop 1: Coasting stop
b1.11 ^①	Start DC brake current	0~100	20	1%	
b1.12 ^①	Start DC brake time	0.0~100.0	0.0	0.1Sec	
b1.13	Initial frequency of stop DC brake	0.00~b0.00	0.00	0.01Hz	

Function Code	Name	Range	Default	Step	Description
b1.14	Stop DC brake waiting time	0.0~100.0	0.0	0.1Sec	
b1.15	Stop DC brake current	0~100	20	1%	
b1.16	Stop DC brake time	0.0~100.0	0.0	0.1Sec	
b1.17	Running mode when running frequency lower than frequency lower limit	0~3	0	1	
0: Run at frequency lower limit 2: Stop 1: Run at zero speed 3: Stop, restart when setting frequency higher than lower limit					
b1.18	Running direction	0~1	0	1	0: Same direction 1: Reverse direction
It is used to set the motor direction which is consistent with the reference frequency or not, whatever the control source is.					
b1.19	Forward/Reverse rotation dead-zone time	0.0~3000.0	0.0	0.1Sec	
b1.20	Reverse prohibition	0~1	0	1	0: Reverse enabled 1: Reverse disabled
b1.21	Stop key function	0~1	1	1	
0: STOP/RESET key enabled only in operation keypad control 1: STOP/RESET key enabled in any operation mode					
b1.22	Startup protection	0~1	1	1	0: No 1: Yes
If this parameter is set to 1, even the start command is active, the AC drive will be not response to the start command. Users should cancel the start command firstly, then send the start command again to run the AC drive.					
b1.23	Dynamic brake use ratio	0~100	100	1%	
The larger the value of this parameter is, the larger braking duty will be. 0% means disable dynamic brake function.					
b1.24	Dynamic brake voltage	Module dependent	Module dependent	0.1V	
b1.25 ^①	Multi function of JOG key	0~2	0	1	For function selection of JOG key on Keypad.
0: JOG 1:Forward/Reverse switching 2:Command source switching					

b2 Frequency Source

Function Code	Name	Range	Default	Step	Description
b2.00 ^①	Main frequency source A	0~8	0	1	
0: b2.01+UP/DOWN 2: AI2 4: X6/FI 6: PLC 8: Communication 1: AI1 3: AI3 5: PID 7: Multi-Reference					

Code	Name	Range	Default	Step	Description
b2.01	Preset Frequency	0.00~b0.00	50.00	0.01Hz	
b2.02 ^①	Auxiliary frequency source B	0~8	0	1	Same As b2.00
b2.03	Range of auxiliary frequency source B	0~100	100	1%	
b2.04	Offset frequency for A and B operation	0.00~b0.00	0.00	0.01Hz	
b2.05	Frequency source selection	00~34	00	1	
Unit's digit (Frequency source selection) 0: Main frequency source A 1: A and B operation (operation relationship determined by ten's digit) 2: Switchover between A and B 3: Switchover between A and "A and B operation" 4: Switchover between B and "A and B operation"					
Ten's digit (A and B operation relationship) 0: A+B 1: A-B 2: min{A,B} 3: max{A,B}					
b2.06	Binding command source to frequency source	000~999	000	1	
Unit's digit (Binding the frequency source together with Keypad control source) 0: No binding 1: b2.01+UP/DOWN 2: AI1 3: AI2 4: AI3 5: X6/FI 6: Multi-reference 7: PLC 8: PID 9: Communication					
Ten's digit (Binding the frequency source together with Terminal control source) Hundred's digit (Binding the frequency source together with Communication control source)					
b2.07 ^①	Frequency resolution	1~2	2	1	1: 0.1Hz 2: 0.01Hz
All the parameters with 'Hz' unit will change following b2.07. Such as b0.09(50.00Hz) will change to 500.0Hz when set b2.07 from 1 to 2.					

C0 Digital Input

Function Code	Name	Range	Default	Step	Description
C0.00	X terminals filter time	0.000~1.000	0.010	0.001Sec	
C0.01 ^①	X1 function	0~58	3	1	
0: No function 1: Forward JOG(FJOG) 2: Reverse JOG(RJOG) 3: Forward RUN (FWD) 4: Reverse RUN (REV) 5: Three-line control 6: RUN pause (terminal, operation panel) 7: Coast to stop 8: External STOP terminal 1 9: External STOP terminal 2 10: Emergency Stop 11: Immediate DC braking 12: Deceleration DC braking 13: Terminal UP 14: Terminal DOWN 15: UP and DOWN setting clear 16: Multi-reference terminal 1 17: Multi-reference terminal 2 18: Multi-reference terminal 3 19: Multi-reference terminal 4 20: Terminal 1 for Acceleration /deceleration time selection 21: Terminal 2 for Acceleration /deceleration time selection 22: Acceleration/Deceleration prohibited 23: Fault reset 24: Normally open (NO) input of external fault					

Function Code	Name	Range	Default	Step	Description
C0.17 ^①	I/O command mode	0~3	0	1	
0: Two-line mode 1 1: Two-line mode 2 2: Three-line mode 1 3: Three-line mode 2					
C0.18	UP/DOWN adjustment selection	0~2	0	1	
0: Frequency reference 1: Torque reference 2: PID reference					
C0.19	UP/DOWN adjustment memory	00~11	11	1	
Unit's digit: retentive at stop 0: No 1: Yes					
Ten's digit: retentive at power down 0: No 1: Yes					
C0.20	Terminal UP/DOWN ramp rate	0.01~100.00	20.00	0.01%	

C1 Digital Output

Function Code	Name	Range	Default	Step	Description
C1.00	Y2/FO output mode selection	0~1	0	1	0: Pulse output(FO) 1: Switch signal output(Y2)
C1.01	Y1 function	0~45	3	1	
0: No output 15: Motor overload pre-warning 28: Current 1 reached 1: Under voltage 16: AC drive overload 29: Current 2 reached 2: ready for run pre-warning 30: Under load 3: running 17: inverter module temperature 31: AI1 input limit exceeded 4: Zero-speed running 1 reached 32: Timing reached (no output at stop) 18: Motor Over heat pre-warning 33: PLC cycle complete 5: Zero-speed running 2 19: Zero current status 34: Current limit exceeded (having output at stop) 20: Set count value reached 35: Communication setting 6: Reverse running 21: Designated count value 36: AI1>AI2 7: Frequency reached reached 37: PID feedback Limit exceeded 8: Frequency upper limit reached 22: Length reached 38: PID sleep status indication 9: Frequency lower limit reached 23: Accumulative power-on time 39: Frequency Limited (no output at stop) reached 40: Motor 1# Control output 10: FDT1 detection output 24: Accumulative running time 41: Motor 2# Control output 11: FDT2 detection output reached 42: Motor 3# Control output 12: Torque limited 25: Current running time reached 43: Motor 4# Control output 13: Fault output(AC drive stop) 26: Frequency 1 reached 44: External brake control 14: Warning output 27: Frequency 2 reached 45: Simple brake control (continue running)					

Function Code	Name	Range	Default	Step	Description
C1.02	Y2 function	0~45	7	1	Same As C1.01
C1.03	Y3 function	0~45	0	1	
C1.04	T1 function	0~45	13	1	
C1.05	T2 function	0~45	0	1	
C1.06	T3 function	0~45	0	1	
C1.07	T4 function	0~45	0	1	
C1.08	T5 function	0~45	0	1	
C1.09	T6 function	0~45	0	1	
C1.10	Y terminals active state logic	000~111	000	1	0: positive logic 1: Negative logic
Unit's digit: Y1		Ten's digit: Y2		Hundred's digit: Y3	
C1.11	T1~T4 active state logic	0000~1111	0000	1	0: positive logic 1: Negative logic
Unit's digit: T1		Ten's digit: T2		Hundred's digit: T3	
Thousand's digit: T4					
C1.12	T5~T6 active state logic	00~11	00	1	0: positive logic 1: Negative logic
Unit's digit: T5		Ten's digit: T6			
C1.13	Y1 output delay time	0.0~3000.0	0.0	0.1Sec	
C1.14	Y2 output delay time	0.0~3000.0	0.0	0.1Sec	
C1.15	Y3 output delay time	0.0~3000.0	0.0	0.1Sec	
C1.16	T1 output delay time	0.0~3000.0	0.0	0.1Sec	
C1.17	T2 output delay time	0.0~3000.0	0.0	0.1Sec	
C1.18	T3 output delay time	0.0~3000.0	0.0	0.1Sec	
C1.19	T4 output delay time	0.0~3000.0	0.0	0.1Sec	
C1.20	T5 output delay time	0.0~3000.0	0.0	0.1Sec	
C1.21	T6 output delay time	0.0~3000.0	0.0	0.1Sec	
C1.22	Interval of Y1 output active state	0.0~600.0	0.0	0.1Sec	
C1.23	Interval of Y2 output active state	0.0~600.0	0.0	0.1Sec	
C1.24	Interval of T1 output active state	0.0~600.0	0.0	0.1Sec	
C1.25	Interval of T2 output active state	0.0~600.0	0.0	0.1Sec	

C2 Analog Input

Function Code	Name	Range	Default	Step	Description
C2.00	AI1 filter time	0.00~10.00	0.10	0.01Sec	
C2.01	AI2 filter time	0.00~10.00	0.10	0.01Sec	
C2.02	AI3 filter time	0.00~10.00	0.10	0.01Sec	
C2.03	AI curve selection	111~333	321	1	
1: AI curve 1(C2.04~07)		2: AI curve 2(C2.08~11)		3: AI curve 3(C2.12~15)	
Unit's digit: AI1		Ten's digit: AI2		Hundred's digit: AI3	
C2.04	AI curve 1 minimum input	-10.00~C2.06	0.00	0.01V	
C2.05	Corresponding setting of AI curve 1 minimum input	-100.0~100.0	0.0	0.1%	
C2.06	AI curve 1 maximum input	C2.04~10.00	10.00	0.01V	
C2.07	Corresponding setting of AI curve 1 maximum input	-100.0~100.0	100.0	0.1%	
C2.08	AI curve 2 minimum input	-10.00~C2.10	0.00	0.01V	
C2.09	Corresponding setting of AI curve 2 minimum input	-100.0~100.0	0.0	0.1%	
C2.10	AI curve 2 maximum input	C2.08~10.00	10.00	0.01V	
C2.11	Corresponding setting of AI curve 2 maximum input	-100.0~100.0	100.0	0.1%	
C2.12	AI curve 3 minimum input	-10.00~C2.14	0.00	0.01V	
C2.13	Corresponding setting of AI curve 3 minimum input	-100.0~100.0	0.0	0.1%	
C2.14	AI curve 3 maximum input	C2.12~10.00	10.00	0.01V	
C2.15	Corresponding setting of AI curve 3 maximum input	-100.0~100.0	100.0	0.1%	
C2.16	Jump point of AI1 input corresponding setting	-100.0~100.0	0.0	0.1%	
C2.17	Jump amplitude of AI1 input corresponding setting	0.0~100.0	0.5	0.1%	
C2.18	Jump point of AI2 input corresponding setting	-100.0~100.0	0.0	0.1%	
C2.19	Jump amplitude of AI2 input corresponding setting	0.0~100.0	0.5	0.1%	
C2.20	Jump point of AI3 input corresponding setting	-100.0~100.0	0.0	0.1%	
C2.21	Jump amplitude of AI3 input corresponding setting	0.0~100.0	0.5	0.1%	

Function Code	Name	Range	Default	Step	Description
C2.22	Setting for AI less than minimum input	000~111	000	1	
0: corresponding to minimum setting 1: 0.0%					
Unit's digit: AI1		Ten's digit: AI2		Hundred's digit: AI3	

C3 Analog Output

Function Code	Name	Range	Default	Step	Description
C3.00	AO1 filter time	0.00~10.00	0.00	0.01Sec	
C3.01	AO2 filter time	0.00~10.00	0.00	0.01Sec	
C3.02	AO1 function	0~17	1	1	
0: Set frequency 5: Output torque 9: Pulse input(from X6/FI) 13: PID output 1: Running frequency 6: AI1 10: Target torque 14: Actual length 2: Output current 7: AI2 11: PID setting 15: Count value 3: Output voltage 8: AI3 12: PID feedback 16: Communication setting 4: Output power 17: Feedback speed					
C3.03	AO2 function	0~17	2	1	Same As C3.02
C3.04	AO curve selection	11~22	21	1	
1: AO curve 1 (C3.05~08)		2: AO curve 2 (C3.09~12)		Unit's digit: AO1	Ten's digit: AO2
C3.05	AO curve 1 minimum output	0.00~10.00	0.00	0.01V	
C3.06	Corresponding setting of AO curve 1 minimum output	0.0~C3.08	0.0	0.1%	
C3.07	AO curve 1 maximum output	0.00~10.00	10.00	0.01V	
C3.08	Corresponding setting of AO curve 1 maximum output	C3.06~100.0	100.0	0.1%	
C3.09	AO curve 2 minimum output	0.00~10.00	0.00	0.01V	
C3.10	Corresponding setting of AO curve 2 minimum output	0.0~C3.12	0.0	0.1%	
C3.11	AO curve 2 maximum output	0.00~10.00	10.00	0.01V	
C3.12	Corresponding setting of AO curve 2 maximum output	C3.10~100.0	100.0	0.1%	

C4 Pulse Input/Output

Function Code	Name	Range	Default	Step	Description
C4.00	FI filter time	0.00~10.00	0.10	0.01Sec	
C4.01	FI minimum input	0.00~C4.03	0.00	0.01kHz	
C4.02	Corresponding setting of FI minimum input	-100.0~100.0	0.0	0.1%	
C4.03	FI maximum input	C4.01~100.00	50.00	0.01kHz	
C4.04	Corresponding setting of FI maximum input	-100.0~100.0	100.0	0.1%	
C4.05	FO filter time	0.00~10.00	0.00	0.01Sec	
C4.06	FO function	0~17	1	1	Same As C3.02
C4.07	FO output minimum frequency	0.00~100.00	0.00	0.01kHz	
C4.08	Corresponding setting of FO output minimum frequency	0.0~C4.10	0.0	0.1%	
C4.09	FO output maximum frequency	0.00~100.00	50.00	0.01kHz	
C4.10	Corresponding setting of FO output maximum frequency	C4.08~100.0	100.0	0.1%	

C5 Virtual Digital Input/Output

Function Code	Name	Range	Default	Step	Description
C5.00 ^①	VX1 function	0~58	0	1	Same As C0.01
C5.01 ^①	VX2 function	0~58	0	1	
C5.02 ^①	VX3 function	0~58	0	1	
C5.03 ^①	VX4 function	0~58	0	1	
C5.04	VX active state mode selection	0000~4444	1111	1	
0: Set by VYn 1: Set by C5.05 2: Set by AI1 3: Set by AI2 4: Set by AI3 Unit's digit: VX1 Ten's digit: VX2 Hundred's digit: VX3 Thousand's digit: VX4					
C5.05	Digital setting of VX active state	0000~1111	0000	1	0: Active 1: Inactive
Unit's digit: VX1 Ten's digit: VX2 Hundred's digit: VX3 Thousand's digit: VX4					
C5.06 ^①	Active mode for AI as VX input	000~111	000	1	0: High is active 1: Low is active
Unit's digit: AI1 Ten's digit: AI2 Hundred's digit: AI3					
C5.07 ^①	Active mode for AI as VX input	C5.08~8.00	6.70	0.01V	
C5.08 ^①	Active mode for AI as VX input	1.00~C5.07	3.20	0.01V	

Function Code	Name	Range	Default	Step	Description
C5.09 ^①	VY1 function	0~45	0	1	Same As C1.01
C5.10 ^①	VY2 function	0~45	0	1	Same As C1.01
C5.11 ^①	VY3 function	0~45	0	1	Same As C1.01
C5.12 ^①	VY4 function	0~45	0	1	Same As C1.01
C5.13	VY1 output delay time	0.0~3600.0	0.0	0.1Sec	
C5.14	VY2 output delay time	0.0~3600.0	0.0	0.1Sec	
C5.15	VY3 output delay time	0.0~3600.0	0.0	0.1Sec	
C5.16	VY4 output delay time	0.0~3600.0	0.0	0.1Sec	
C5.17	VY terminal active state logic	0000~1111	0000	1	0: Positive logic 1: Negative logic
Unit's digit: VY1 Ten's digit: VY2 Hundred's digit: VY3 Thousand's digit: VY4					

d0 Motor Control

Function Code	Name	Range	Default	Step	Description
d0.00 ^①	Motor control mode	0~2	0	1	
0: V/f 1: Open loop vector control 2: Close loop vector control					
d0.01	Carrier frequency	Module dependent	Module dependent	0.1kHz	
d0.02	Carrier frequency adjustment with temperature	0~1	1	1	0: Enabled 1: Disabled
d0.03	Random PWM depth	0~10	0	1	
Random PWM can decrease motor noise without increasing carrier frequency. The bigger , the wider spectrum. 0: disable random PWM 1~10: setting the depth of random PWM					
d0.04	DPWM switchover frequency upper limit	0.00~b0.00	10.00	0.01Hz	
If the output frequency is higher than this Value + 3Hz, the DPWM modulation mode is adopted, or else continuous method is adopted.					
d0.05	PWM Modulation mode	0~1	0	1	
0: Asynchronous modulation 1: Synchronous modulation					
d0.06	Torque boost	0.0~20.0	Module dependent	0.1%	0.0%: auto torque boost > 0.0%: customized torque boost
d0.07 ^①	Cut-off frequency of torque boost	0.00~b0.00	37.00	0.01Hz	

Function Code	Name	Range	Default	Step	Description
d0.08	V/f slip compensation gain	0.0~100.0	0.0	0.1%	
d0.09	V/F over-excitation gain	0~250	64	1	
d0.10	V/F oscillation suppression gain	0~500	Module dependent	1	
d0.11	Overcurrent stall gain	0~300	Module dependent	1	
d0.12	Overcurrent stall protective current	30~200	150	1%	
Reference value is the motor rated current. Note: "d0.12 * the motor rated current" generally can not be greater than "d0.32 *the AC drive rated current of G type".					
d0.13	Overvoltage stall gain	0~300	5	1	
d0.14	Overvoltage stall protective voltage	Module dependent	Module dependent	0.1V	
d0.15	Stall control mode	00~11	00	1	
Unit's digit: Under 0: Disabled voltage control enable 1: Enabled Ten's digit: Overvoltage 0:Auto limit of acceleration and deceleration step and overcurrent stall control 1:Operating frequency automatic control					
d0.16 ^①	V/f curve selection	0~9	0	1	
0: Linear V/F 2: 1.2-power V/F 4: 1.6-power V/F 6: Square V/F 8: V/F half separation 1: Multi-point V/F 3: 1.4-power V/F 5: 1.8-power V/F 7: V/F complete separation 9: Flux Optimization					
d0.17 ^①	Multi- point V/f zero frequency voltage	0.0~40.0	1.5	0.1%	
d0.18 ^①	Multi- point V/f frequency 1	0.00~d0.20	3.00	0.01Hz	
d0.19 ^②	Multi- point V/f voltage 1	0.0~100.0	8.0	0.1%	
d0.20 ^②	Multi- point V/f frequency 2	d0.18~d0.22	25.00	0.01Hz	
d0.21 ^②	Multi- point V/f voltage 2	0.0~100.0	55.0	0.1%	
d0.22 ^②	Multi- point V/f frequency 3	d0.20~b0.09	50.00	0.01Hz	
d0.23 ^②	Multi- point V/f voltage 3	0.0~100.0	100.0	0.1%	
d0.24	Voltage source for V/f separation	0~8	0	1	
0: d0.25 1: AI1 2: AI2 3: AI3 4: X6/FI 5: PID 6: PLC 7: Multi-Reference 8: Communication					
d0.25	Voltage digital setting for V/f separation	0~b0.07	0	1V	
d0.26	Voltage ramp time of V/f separation	0.0~1000.0	0.0	0.1Sec	
d0.31	CBC current control	0~1	1	1	
d0.32	CBC current limit	0.50~2.20	2.00	0.01	
d0.33	CBC current control delay time	10~9999	500	1mSec	
d0.34	Energy saving coefficient	50.0~100.0	65.0	0.1%	
Voltage coefficient of the weak magnetic when output torque below 5%.Set too low may lead to motor stall.					

d1 Motor Parameters

Function Code	Name	Range	Default	Step	Description
d1.01 ^①	Motor stator resistance	Module dependent	Module dependent	0.001ohm	
d1.02 ^①	Motor rotor resistance	Module dependent	Module dependent	0.001ohm	
d1.03 ^①	Motor leakage inductance	Module dependent	Module dependent	0.01mH	
d1.04 ^①	Motor mutual inductance	Module dependent	Module dependent	0.1mH	
d1.05 ^①	Motor No-load current	Module dependent	Module dependent	0.01A	
d1.06 ^①	Motor weaken flux coefficient 1	0.000~1.000	0.400	0.001	Flux weakening coefficient at 20% flux current
d1.07 ^①	Motor weaken flux coefficient 2	0.000~1.000	0.700	0.001	Flux weakening coefficient at 50% flux current
d1.08 ^①	Motor weaken flux coefficient 3	0.000~1.000	1.000	0.001	Flux weakening coefficient at 80% flux current
d1.15 ^①	Auto tune	0~2	0	1	
0: No action		1: Static auto tune		2: rotational auto tune	

d2 Speed Control

Function Code	Name	Range	Default	Step	Description
d2.00	ASR proportional gain Kp1	1~100	20	1	
d2.01	ASR integration time Ti1	0.01~10.00	0.30	0.01Sec	
d2.02	ASR proportional gain Kp2	1~100	20	1	
d2.03	ASR integration time Ti2	0.01~10.00	0.50	0.01Sec	
d2.04	Low speed switchover frequency	0.00~d2.05	5.00	0.01Hz	
d2.05	High speed switchover frequency	d2.04~b0.00	10.00	0.01Hz	
d2.06	ASR integration attribute	0~1	0	1	
0: Integral separated inactive		1: Integral separated active			
d2.07	Vector control slip gain	50~120	100	1%	
d2.08	ASR filter time	0~1023	0	1	

Function Code	Name	Range	Default	Step	Description
d2.09	Upper torque limit Source of forward motoring	0~7	0	1	
0: d2.10 2: AI2 4: X6/FI 6: MIN (AI1,AI2) 1: AI1 3: AI3 5: Communication 7: MAX (AI1,AI2)					
d2.10	Preset upper torque limit of forward motoring	0.0~300.0	150.0	0.1%	
d2.11	Upper torque limit Source of reverse motoring	0~7	0	1	
0: d2.12 2: AI2 4: X6/FI 6: MIN (AI1,AI2) 1: AI1 3: AI3 5: Communication 7: MAX (AI1,AI2)					
d2.12	Preset upper torque limit of reverse motoring	0.0~300.0	150.0	0.1%	
d2.13	Upper torque limit Source of forward generating	0~7	0	1	
0: d2.14 2: AI2 4: X6/FI 6: MIN (AI1,AI2) 1: AI1 3: AI3 5: Communication 7: MAX (AI1,AI2)					
d2.14	Preset upper torque limit of forward generating	0.0~300.0	150.0	0.1%	
d2.15	Upper torque limit Source of reverse generating	0~7	0	1	
0: d2.16 2: AI2 4: X6/FI 6: MIN (AI1,AI2) 1: AI1 3: AI3 5: Communication 7: MAX (AI1,AI2)					
d2.16	Preset upper torque limit of reverse generating	0.0~300.0	150.0	0.1%	
d2.17	proportional gain of flux current loop	0~30000	2000	1	
d2.18	integration time of flux current loop	0~30000	800	1	
d2.19	proportional gain of torque current loop	0~30000	2000	1	
d2.20	integration time of torque current loop	0~30000	400	1	
d2.21 ^①	Vector control optimization mode	000~111	110	1	0: Disabled 1: Enabled
Unit's digit : Ten's digit: Hundred's digit:					
Loop control optimization		Angle estimation optimization		Low frequency torque optimization	

d3 Torque Control

Function Code	Name	Range	Default	Step	Description
d3.00 ^①	Speed/Torque control selection	0~1	0	1	0: Speed Control 1: Torque Control
d3.01 ^①	Torque reference source	0~7	0	1	
0: d3.02+UP/DOWN 2: AI2 4: X6/FI 6: MIN (AI1,AI2) 1: AI1 3: AI3 5: Communication 7: MAX (AI1,AI2)					
d3.02	Digital setting of torque reference	-300.0~300.0	150.0	0.1%	
d3.03 ^①	N/G				
0: d3.04 2: AI2 4: X6/FI 6: MIN (AI1,AI2) 1: AI1 3: AI3 5: Communication 7: MAX (AI1,AI2)					
d3.04	Coefficient of rigidity	10.0~300.0	0.0	0.1%	
d3.05 ^①	N/G				
0: Minimum frequency to maximum frequency 3: Running frequency to maximum frequency 1: Minimum frequency to running frequency 4: Running frequency + windows 2: Negative running frequency to positive running frequency 5: 0Hz to output frequency					
d3.06 ^①	maximum frequency source	0~7	0	1	
0: d3.07 2: AI2 4: X6/FI 6: MIN (AI1,AI2) 1: AI1 3: AI3 5: Communication 7: MAX (AI1,AI2)					
d3.07	Digital setting of Maximum frequency	-b0.00~b0.00	50.00	0.01Hz	
d3.08 ^①	Minimum frequency source	0~7	0	1	
0: d3.09 2: AI2 4: X6/FI 6: MIN (AI1,AI2) 1: AI1 3: AI3 5: Communication 7: MAX (AI1,AI2)					
d3.09	Digital setting of minimum frequency	-b0.00~b0.00	-50.00	0.01Hz	
d3.10	N/G				
d3.11	N/G				
d3.12	Static torque compensation	0.0~100.0	0.0	0.1%	

Function Code	Name	Range	Default	Step	Description
d3.13	N/G				
d3.14	N/G				
d3.15	Torque acceleration time	0.00~650.00	2.00	0.01Sec	
d3.16	Torque deceleration time	0.00~650.00	2.00	0.01Sec	
d3.17	N/G				
d3.18	N/G				

d3.17~d3.18 is the limit of torque reference under torque control mode, and is also the maximum setting value when AI, FI and Communication input.

d5 Motor 2 Parameters

Function Code	Name	Range	Default	Step	Description
d5.00 ^①	Motor 1/2 selection	0~1	0	1	0: Motor 1 1: Motor 2
d5.01 ^①	Motor 2 control mode	0~2	0	1	
		0: V/f	1: Open loop vector control	2: Close loop vector control	
d5.03 ^①	Motor 2 rated power	0.1~999.9	Module dependent	0.1kw	
d5.04 ^①	Motor 2 rated voltage	1~2000		1V	
d5.05 ^①	Motor 2 rated current	0.01~655.35		0.01A	
d5.06 ^①	Motor 2 rated frequency	10.00~b0.00		0.01Hz	
d5.07 ^①	Motor 2 rated speed	1~65535		1RPM	
d5.08 ^①	Motor 2 stator resistance	Module dependent	Module dependent	0.001ohm	
d5.09 ^①	Motor 2 rotor resistance			0.001ohm	
d5.10 ^①	Motor 2 leakage inductance			0.01mH	
d5.11 ^①	Motor 2 mutual inductance			0.1mH	
d5.12 ^①	Motor 2 No-load current			0.01A	
d5.13 ^①	Motor 2 weaken flux coefficient 1	0.000~1.000	1.000	0.001	Flux weakening coefficient at 20% flux current

Function Code	Name	Range	Default	Step	Description
d6.11	Motor 2 Upper torque limit Source of reverse motoring	0~7	0	1	
0: d6.12 2: AI2 4: X6/FI 6: MIN (AI1,AI2) 1: AI1 3: AI3 5: Communication 7: MAX (AI1,AI2)					
d6.12	Motor 2 Preset upper torque limit of reverse motoring	0.0~300.0	150.0	0.1%	
d6.13	Motor 2 Upper torque limit Source of forward generating	0~7	0	1	
0: d6.14 2: AI2 4: X6/FI 6: MIN (AI1,AI2) 1: AI1 3: AI3 5: Communication 7: MAX (AI1,AI2)					
d6.14	Motor 2 Preset upper torque limit of forward generating	0.0~300.0	150.0	0.1%	
d6.15	Motor 2 Upper torque limit Source of reverse generating	0~7	0	1	
0: d6.16 2: AI2 4: X6/FI 6: MIN (AI1,AI2) 1: AI1 3: AI3 5: Communication 7: MAX (AI1,AI2)					
d6.16	Motor 2 Preset upper torque limit of reverse generating	0.0~300.0	150.0	0.1%	
d6.17	Motor 2 proportional gain of flux current loop	0~30000	2000	1	
d6.18	Motor 2 integration time of flux current loop	0~30000	800	1	
d6.19	Motor 2 proportional gain of torque current loop	0~30000	2000	1	
d6.20	Motor 2 integration time of torque current loop	0~30000	400	1	

E0 JOG

Function Code	Name	Range	Default	Step	Description
E0.00	JOG frequency	0.00~b0.00	5.00	0.01Hz	
E0.01	JOG acceleration time	0.1~6000.0	10.0	0.1Sec	
E0.02	JOG deceleration time	0.1~6000.0	10.0	0.1Sec	
E0.03	JOG stop mode	0~1	0	1	0: Ramp stop 1: Coasting stop
E0.04	JOG preferred	0~1	0	1	
When set E0.04 to 1, the AC drive will response the JOG command of current control source immediately even if in running state. And the JOG command from other control source will be ignored. 0: Inactive 1: Active					

E1 Skip Frequency

Function Code	Name	Range	Default	Step	Description
E1.00	Skip frequency 1 High limit	E1.01~b0.00	0.00	0.01Hz	
E1.01	Skip frequency 1 Low limit	0.00~ E1.00	0.00	0.01Hz	
E1.02	Skip frequency 2 High limit	E1.03~b0.00	0.00	0.01Hz	
E1.03	Skip frequency 2 Low limit	0.00~ E1.02	0.00	0.01Hz	

E2 Multi-Reference

Function Code	Name	Range	Default	Step	Description
E2.00	Reference 0 source	0~6	0	1	
0: E2.01 1: b2.01+UP/DOWN 2: AI1 3: AI2 4: AI3 5: X6/FI 6: PID					
E2.01	Reference 0	-b0.00~b0.00	0.00	0.01Hz	
E2.02	Reference 1	-b0.00~b0.00	0.00	0.01Hz	
E2.03	Reference 2	-b0.00~b0.00	0.00	0.01Hz	
E2.04	Reference 3	-b0.00~b0.00	0.00	0.01Hz	
E2.05	Reference 4	-b0.00~b0.00	0.00	0.01Hz	
E2.06	Reference 5	-b0.00~b0.00	0.00	0.01Hz	
E2.07	Reference 6	-b0.00~b0.00	0.00	0.01Hz	
E2.08	Reference 7	-b0.00~b0.00	0.00	0.01Hz	
E2.09	Reference 8	-b0.00~b0.00	0.00	0.01Hz	
E2.10	Reference 9	-b0.00~b0.00	0.00	0.01Hz	
E2.11	Reference 10	-b0.00~b0.00	0.00	0.01Hz	
E2.12	Reference 11	-b0.00~b0.00	0.00	0.01Hz	
E2.13	Reference 12	-b0.00~b0.00	0.00	0.01Hz	
E2.14	Reference 13	-b0.00~b0.00	0.00	0.01Hz	
E2.15	Reference 14	-b0.00~b0.00	0.00	0.01Hz	
E2.16	Reference 15	-b0.00~b0.00	0.00	0.01Hz	

E3 Simple PLC

Function Code	Name	Range	Default	Step	Description
E3.00	Simple PLC running mode	0~2	0	1	
0: Stop after the AC drive running one cycle 1: Keep final values after the AC drive running one cycle 2: Repeat after the AC drive running one cycle					
E3.01	Simple PLC retentive selection	00~11	00	1	
Unit's digit (Retentive upon power failure) 0: No 1: Yes Ten's digit (Retentive upon stop) 0: No 1: Yes					
E3.02	Time unit of simple PLC running	0~1	0	1	0: Sec (second) 1: h (hour)
E3.03	Running time of simple PLC reference 0	0.0~6553.5	0.0	0.1Sec	
E3.04	Acc/dec time of simple PLC reference 0	0~3	0	1	
0: Acceleration/deceleration time 1 1: Acceleration/deceleration time 2 2: Acceleration/deceleration time 3 3: Acceleration/deceleration time 4					
E3.05	Running time of simple PLC reference 1	0.0~6553.5	0.0	0.1Sec	
E3.06	Acc/dec time of simple PLC reference 1	0~3	0	1	Same As E3.04
E3.07	Running time of simple PLC reference 2	0.0~6553.5	0.0	0.1Sec	
E3.08	Acc/dec time of simple PLC reference 2	0~3	0	1	Same As E3.04
E3.09	Running time of simple PLC reference 3	0.0~6553.5	0.0	0.1Sec	
E3.10	Acc/dec time of simple PLC reference 3	0~3	0	1	Same As E3.04
E3.11	Running time of simple PLC reference 4	0.0~6553.5	0.0	0.1Sec	
E3.12	Acc/dec time of simple PLC reference 4	0~3	0	1	Same As E3.04
E3.13	Running time of simple PLC reference 5	0.0~6553.5	0.0	0.1Sec	
E3.14	Acc/dec time of simple PLC reference 5	0~3	0	1	Same As E3.04
E3.15	Running time of simple PLC reference 6	0.0~6553.5	0.0	0.1Sec	
E3.16	Acc/dec time of simple PLC reference 6	0~3	0	1	Same As E3.04
E3.17	Running time of simple PLC reference 7	0.0~6553.5	0.0	0.1Sec	
E3.18	Acc/dec time of simple PLC reference 7	0~3	0	1	Same As E3.04
E3.19	Running time of simple PLC reference 8	0.0~6553.5	0.0	0.1Sec	
E3.20	Acc/dec time of simple PLC reference 8	0~3	0	1	Same As E3.04
E3.21	Running time of simple PLC reference 9	0.0~6553.5	0.0	0.1Sec	
E3.22	Acc/dec time of simple PLC reference 9	0~3	0	1	Same As E3.04
E3.23	Running time of simple PLC reference 10	0.0~6553.5	0.0	0.1Sec	
E3.24	Acc/dec time of simple PLC reference 10	0~3	0	1	Same As E3.04
E3.25	Running time of simple PLC reference 11	0.0~6553.5	0.0	0.1Sec	
E3.26	Acc/dec time of simple PLC reference 11	0~3	0	1	Same As E3.04

Function Code	Name	Range	Default	Step	Description
E3.27	Running time of simple PLC reference 12	0.0~6553.5	0.0	0.1Sec	
E3.28	Acc/dec time of simple PLC reference 12	0~3	0	1	Same As E3.04
E3.29	Running time of simple PLC reference 13	0.0~6553.5	0.0	0.1Sec	
E3.30	Acc/dec time of simple PLC reference 13	0~3	0	1	Same As E3.04
E3.31	Running time of simple PLC reference 14	0.0~6553.5	0.0	0.1Sec	
E3.32	Acc/dec time of simple PLC reference 14	0~3	0	1	Same As E3.04
E3.33	Running time of simple PLC reference 15	0.0~6553.5	0.0	0.1Sec	
E3.34	Acc/dec time of simple PLC reference 15	0~3	0	1	Same As E3.04

E4 Acc & Dec Time

Function Code	Name	Range	Default	Step	Description
E4.00	acceleration time 2	0.1~6000.0	Module dependent	0.1Sec	
E4.01	deceleration time 2	0.1~6000.0		0.1Sec	
E4.02	acceleration time 3	0.1~6000.0	Module dependent	0.1Sec	
E4.03	deceleration time 3	0.1~6000.0	Module dependent	0.1Sec	
E4.04	acceleration time 4	0.1~6000.0	Module dependent	0.1Sec	
E4.05	deceleration time 4	0.1~6000.0	Module dependent	0.1Sec	
E4.06	Frequency switchover point between acceleration time 1&2	0.00~b0.00	0.00	0.01Hz	
E4.07	Frequency switchover point between deceleration time 1&2	0.00~b0.00	0.00	0.01Hz	
E4.08 ^①	Acceleration/ Deceleration time unit	0~2	1	1	0: 1 Sec 1: 0.1 Sec 2: 0.01 Sec
E4.09 ^①	Reference frequency of Acceleration/ Deceleration time	0~2	0	1	Acceleration/ Deceleration time is defined as the time between 0Hz to E4.09
0: Max frequency(b0.00)		1: Current setting frequency		2: 100Hz	

E5 PID

Function Code	Name	Range	Default	Step	Description
E5.00 ^①	PID engineering unit	0~5	0	1	
0:Percentage(%) 1:Pressure(MPa) 2:Centigrade(°C) 3:Kilowatt(kW) 4:Kilowatt hour(kWh) 5:Flow(m³/h)					
E5.01	PID engineering unit resolution	0~3	1	1	
0: No decimal 1: One decimal 2: Two decimals 3: Three decimals					
E5.02	Maximum setting of PID engineering unit	E5.03 ~6553.5	100.0	0.1%	Unit/Decimal depends on E5.00/E5.01 . First set E5.02 , then set E5.03 .
E5.03	Minimum setting of PID engineering unit	0.0~ E5.02	0.0	0.1%	
E5.04	PID setting source	0~6	0	1	
0: E5.05 +UP/DOWN 1: AI1 2: AI2 3: AI3 4: X6/FI 5: Multi-Reference 6: Communication					
E5.05	PID digital setting	E5.03~E5.02	50.0	0.1%	Unit/Decimal depends on E5.00/E5.01 .
E5.06	PID setting changing time	0.00~99.99	0.00	0.01Sec	
E5.07	PID feedback source	0~8	0	1	
0: AI1 2: AI3 4: X6/FI 6: MAX(AI1 , AI2) 8: Communication 1: AI2 3: AI1-AI2 5: AI1+AI2 7: MIN(AI1 , AI2)					
E5.08	PID feedback filter time	0.00~60.00	0.00	0.01Sec	
E5.09	PID proportion gain Kp1	0.0~999.9	2.0	0.1%	
E5.10	PID integral time Ti1	0.01~99.99	0.50	0.01Sec	
E5.11	PID differential time Td1	0.000~9.999	0.000	0.001Sec	
E5.12	PID proportion gain Kp2	0.0~999.9	50.0	0.1	
E5.13	PID integral time Ti2	0.01~99.99	2.00	0.01	
E5.14	PID differential time Td2	0.000~9.999	0.000	0.001	
E5.15	PID parameter switchover condition	0~2	0	1	
0: No switchover 1: Switchover via X terminals 2: Automatic switchover based on deviation					
E5.16	PID parameter switchover deviation 1	E5.03~E5.17	20.0	0.1%	Unit/Decimal depends on E5.00/E5.01 .
E5.17	PID parameter switchover deviation 2	E5.16~E5.02	80.0	0.1%	
E5.18	PID output initial value	0.0~100.0	0.0	0.1%	
E5.19	PID output initial value holding time	0.00~600.00	0.00	0.01Sec	
E5.20	PID output filter time	0.00~60.00	0.00	0.01Sec	
E5.21 ^①	PID action direction	0~1	0	1	0:Positive 1:Negative
E5.22	PID differential limit	0.0~100.0	0.5	0.1%	
E5.23	Maximum deviation between two PID outputs in forward direction	0.00~99.99	1.00	0.01%	
E5.24	Maximum deviation between two PID outputs in reverse direction	0.00~99.99	1.00	0.01%	

Function Code	Name	Range	Default	Step	Description
E5.25	Cut-off frequency of PID reverse rotation	0.00~b0.00	0.00	0.01Hz	
E5.26	PID deviation limit	0.0~100.0	0.00	0.1%	Base on PID setting value
E5.27	PID deviation limit delay time	0.0~320.0	0.0	0.1Sec	
E5.28	PID integral property	00~11	00	1	
Unit's digit (Integral separated) 0: Inactive 1: Active Ten's digit (Whether to stop integral operation when the output reaches the limit) 0: Continue integral operation 1: Stop integral operation					
E5.29	PID operation at stop	0~1	1	1	
0: No PID operation at stop 1: PID operation at stop					
E5.30	PID feedback detection enable	0~1	0	1	0: Disabled 1: Enabled
E5.31	Minimum frequency of PID feedback detection	0.00~b0.00	5.00	0.01Hz	
E5.32	Waiting time of PID feedback detection	0.0~600.0	0.0	0.1Sec	
E5.33	Upper limit of PID feedback detection	E5.03~E5.02	100.0	0.1%	Unit/Decimal depends on E5.00/E5.01 .
E5.34	Lower limit of PID feedback detection	E5.03~E5.02	0.0	0.1%	
E5.35	Detection time of PID feedback detection	0.0~600.0	0.0	0.1Sec	
E5.36	wake up level	0.0~200.0	0.0	0.1	Unit/Range depends on E5.44 .
E5.37	wake up delay time	0.0~6500.0	0.0	0.1Sec	
E5.38	Sleep mode	0~1	0	1	
0: Based on output frequency 1: Based on PID feedback					
E5.39	Sleep level	0.0~200	0.0	0.1	Unit/Range depends on E5.44 .
E5.40	Sleep frequency	0.00~b0.00	0.00	0.01Hz	
E5.41	Sleep delay time	0.0~6500.0	0.0	0.1Sec	0 means no sleep function.
E5.42	PID setting high limit	0.0~100.0	100.0	0.1%	PID setting value limit of internal operation.
E5.43	PID setting low limit	0.0~100.0	0.0	0.1%	
E5.44 ^①	Base value selection of PID sleep and wake up threshold	0~1	0	1	
The Unit/Range of E5.36 and E5.39 is determined by E5.44 . 0:Unit is Percentage (%),base value is PID setting and range is 0.0~200.0%. 1:Unit is the same as PID engineering unit(E5.04),range is E5.03~E5.02 .					

E6 Multi-Pump Control

Function Code	Name	Range	Default	Step	Description
E6.00 ^①	Multi-pump control mode	0~4	0	1	
This series AC drive support multi pump control modes. Each of them is apply to different application area with specific configuration and operation logic.					
0: Inactive 1: Frequency pump fixed, No auto change 2: Frequency pump fixed, Support auto change 3: Frequency pump circulation, No auto change 4: Frequency pump circulation, Support auto change					
E6.01	Number of motors	1~4	1	1	
E6.02	Reference step 1	0.0~100.0	0.0	0.1%	
Active if one auxiliary motor at lease is running.Its base value is current PID reference.					
E6.03	Reference step 2	0.0~100.0	0.0	0.1%	
Active if two auxiliary motors at lease are running.Its base value is current PID reference.					
E6.04	Reference step 3	0.0~100.0	0.0	0.1%	
Active if Three auxiliary motors at lease are running.Its base value is current PID reference.					
E6.05	interlock functions	00~11	00	1	
Interlock function is used to indicate whether each motor is connected to multi pump control logic or not. Unit's digit: interlock enable 0: disabled 1: enabled Ten's digit: interlock mode 0: decided by X terminals 1: decided by E6.06					
E6.06	Digital setting of motor interlock	0000~1111	0000	1	
0: Not connected to multi-pump system 1: Connected to multi-pump system Unit's digit: Motor 1# Ten's digit: Motor 2# Hundred's digit: Motor 3# Thousand's digit: Motor 4#					
E6.07	Auto-change interval	0.1~6000.0	48.0	0.1h	
E6.08	Auto-change frequency limit	0.00~b0.00	45.00	0.01Hz	
E6.09	Auto-change motor limit	1~3	1	1	
E6.10	Add pump frequency 1	0.00~b0.00	48.00	0.01Hz	
E6.11	Reduce pump frequency 1	0.00~E6.10	25.00	0.01Hz	
E6.12	Add pump frequency 2	0.00~b0.00	48.00	0.01Hz	
E6.13	Reduce pump frequency 2	0.00~E6.12	25.00	0.01Hz	
E6.14	Add pump frequency 3	0.00~b0.00	48.00	0.01Hz	
E6.15	Reduce pump frequency 3	0.00~E6.14	25.00	0.01Hz	
E6.16	Add pump delay time	0.0~3600.0	5.0	0.1Sec	
E6.17	Dec pump delay time	0.0~3600.0	3.0	0.1Sec	
E6.18	Electromagnetic switch delay time	0.00~10.00	0.20	0.01Sec	
E6.19	Switch over frequency from AC drive to grid	0.00~b0.00	50.00	0.01Hz	

E7 Swing Frequency

Function Code	Name	Range	Default	Step	Description
E7.00	Swing frequency setting mode	0~1	0	1	0: reference to setting frequency 1: reference to max frequency
E7.01	Swing frequency amplitude	0.0~100.0	0.0	0.1%	
E7.02	Skip frequency amplitude	0.0~50.0	0.0	0.1%	
E7.03	Swing frequency cycle	0.1~3000.0	10.0	0.1Sec	
E7.04	Triangular wave rising time coefficient	0.1~99.9	50.0	0.1%	
E7.05	Set count value	E7.06~65535	1000	1	
E7.06	Designated count value	1~E7.05	1000	1	
E7.07	Set length	0~65535	1000	1m	
E7.08	Number of pulses per meter	0.1~6553.5	100.0	0.1	

E8 Droop Control

Function Code	Name	Range	Default	Step	Description
E8.00	Droop control	0.00~10.00	0.00	0.01Hz	
E8.01	Droop control filter time	0.00~60.00	0.00	0.01Sec	

E9 Power Loss Ride Through

Function Code	Name	Range	Default	Step	Description
E9.00	Action selection at power loss ride through	0~1	0	1	0: Disabled 1: Enabled
E9.01	Action judging voltage at power loss ride through	40.0~150.0	80.0	0.1%	
E9.02	Action pause judging voltage at power loss ride through	60.0~150.0	100.0	0.1%	
E9.03	Voltage rally judging time at power loss ride through	0.00~50.00	0.50	0.01 Sec	

EA External Brake

Function Code	Name	Range	Default	Step	Description
EA.00 ^①	External brake control enable	0~1	0	1	0: Inactive 1: active
EA.01 ^①	External brake off frequency limit	0.00~10.00	2.50	0.01Hz	
EA.02 ^①	External brake off current limit	0.0~180.0	110.0	0.1%	
EA.03 ^①	External brake off delay time	0.00~10.00	0.50	0.01Sec	
EA.04 ^①	Acceleration pause time for external brake off	0.00~10.00	1.00	0.01Sec	
EA.05 ^①	External brake on frequency limit	0.00~10.00	2.00	0.01Hz	
EA.06 ^①	External brake on waiting time	0.00~10.00	0.00	0.01Sec	
EA.07 ^①	Stop delay time after external brake on	0.00~10.00	2.50	0.01Sec	

Eb Supervision

Function Code	Name	Range	Default	Step	Description
Eb.00 ^①	Timing function	0~1	0	1	0: Inactive 1: Active
Eb.01 ^①	Timing duration source	0~3	0	1	
0: Eb.02	1: AI1	2: AI2	3: AI3		
Eb.02 ^①	Timing duration	0.0~6500.0	0.0	0.1Min	
Eb.03 ^①	Current running time reached threshold	0.0~6500.0	0.0	0.1Min	
Eb.04	Accumulative power-on time(day) threshold	0~9999	0	1Day	
Eb.05	Accumulative power-on time(hour) threshold	0.00~23.99	0.00	0.01h	
Eb.06	Accumulative running time(day) threshold	0~9999	0	1Day	
Eb.07	Accumulative running time(hour) threshold	0.00~23.99	0.00	0.01h	
Eb.08	Detection range of frequency reached	0.0~100.0	0.2	0.1%	
Eb.09	Any frequency reaching detection value 1	0.00~b0.00	50.00	0.01Hz	
Eb.10	Any frequency reaching detection amplitude 1	0.0~100.0	0.0	0.1%	

Function Code	Name	Range	Default	Step	Description
Eb.11	Any frequency reaching detection value 2	0.00~b0.00	50.00	0.01Hz	
Eb.12	Any frequency reaching detection amplitude 2	0.0~100.0	0.0	0.1%	
Eb.13	frequency detection threshold 1 (FDT1)	0.00~b0.00	50.00	0.01Hz	
Eb.14	Frequency detection hysteresis 1 (FDT hysteresis 1)	0.0~100.0	5.0	0.1%	
Eb.15	frequency detection threshold 2 (FDT2)	0.00~b0.00	50.00	0.01Hz	
Eb.16	Frequency detection hysteresis 2 (FDT hysteresis 2)	0.0~100.0	5.0	0.1%	
Eb.17	Zero current detection level	0.0~300.0	5.0	0.1%	100% is motor rated current
Eb.18	Zero current detection delay time	0.01~600.0 0	0.10	0.01Sec	
Eb.19	Output overcurrent threshold	0.0~300.0	200.0	0.1%	100% is motor rated current
Eb.20	Output overcurrent detection delay time	0.00~600.0 0	0.00	0.01Sec	
Eb.21	Any current reaching 1	0.0~300.0	100.0	0.1%	100% is motor rated current
Eb.22	Any current reaching 1 amplitude	0.0~300.0	0.0	0.1%	
Eb.23	Any current reaching 2	0.0~300.0	100.0	0.1%	100% is motor rated current
Eb.24	Any current reaching 2 amplitude	0.0~300.0	0.0	0.1%	
Eb.25	AI1 input voltage lower limit	0.00~Eb.26	3.70	0.01V	
Eb.26	AI1 input voltage upper limit	Eb.25~10.0 0	7.20	0.01V	
Eb.27	Module temperature threshold	-40.0~125.0	100.0	0.1°C	
Eb.28	Simple brake frequency	0.00~b0.00	2.00	0.01Hz	
Eb.29	Simple brake time	0.0~3000.0	0.0	0.1Sec	
Set Eb.29 to a nonzero value will enable simple brake function.					

F0 Protection

Function Code	Name	Range	Default	Step	Description
F0.00	Under voltage threshold	Module dependent	Module dependent	0.1V	
F0.01 ^①	Over voltage threshold	Module dependent	Module dependent	0.1V	
F0.02	Input phase loss protection	0~1	1	1	0: Disabled 1: Enabled
F0.03	Output phase loss protection	0~1	1	1	0: Disabled 1: Enabled
F0.04	Short-circuit to ground upon power-on	0~1	0	1	0: Disabled 1: Enabled
F0.05	AC drive over load protection gain	0.30~3.00	1.00	0.01	
F0.06	Motor overload protection	0~1	1	1	0: Disabled 1: Enabled
F0.07	Motor overload protection gain	0.20~10.00	1.00	0.01	
F0.08	Motor overload warning coefficient	50~100	80	1%	
F0.09	Under load protection	0~1	0	1	0: Disabled 1: Enabled
F0.10	Detection level of Under load	0.0~100.0	40.0	0.1%	
F0.11	Detection time of Under load	0.0~60.0	1.0	0.1Sec	
F0.12	Motor temperature sensor type	0~2	0	1	0: No sensor 1: PT100 2: PT1000
F0.13	Motor overheat protection threshold	0.0~200.0	120.0	0.1°C	
F0.14	Motor overheat warning threshold	0.0~200.0	100.0	0.1°C	
F0.15	Over-speed detection value	0.0~50.0	20.0	0.1%	
F0.16	Over-speed detection time	0.0~60.0	5.0	0.1Sec	
F0.17	Detection value of too large speed deviation	0.0~50.0	20.0	0.1%	
F0.18	Detection time of too large speed deviation	0.0~60.0	1.0	0.1Sec	
F0.19	Fault protection action selection 1	0000~2222	0000	1	
<p>Unit's digit: input phase loss 0: Coasting stop 1: stop by stop mode 2: continue running Ten's digit: output phase loss (same as unit's digit) Hundred's digit: AC drive overload (same as unit's digit) Thousand's digit: Motor overload (same as unit's digit)</p>					

Function Code	Name	Range	Default	Step	Description
F0.20	Fault protection action selection 2	0000~2222	0000	1	
<p>Unit's digit: motor underload 0: Coasting stop 1: Stop by stop mode 2: Jump to 8% motor rated frequency, resume to setting frequency when underload is inactive. Ten's digit: Motor overheat (same as F0.19 unit's digit) Hundred's digit: external fault (same as F0.19 unit's digit) Thousand's digit: RS485 communication fault (same as F0.19 unit's digit)</p>					
F0.21	Fault protection action selection 3	0000~2222	0000	1	
<p>Unit's digit: Optional card communication fault (same as F0.19 unit's digit) Ten's digit: PID feedback over limit (same as F0.19 unit's digit) Hundred's digit: Accumulated power on time reached fault (same as F0.19 unit's digit) Thousand's digit: Accumulated running time reached fault (same as F0.19 unit's digit)</p>					
F0.22	Fault protection action selection 4	0000~2222	0000	1	
<p>Unit's digit: Too large speed deviation (same as unit's digit) Ten's digit: motor over speed (same as unit's digit) Hundred's digit: flux position detection fault (same as unit's digit) Thousand's digit: UVW signals feedback fault (same as unit's digit)</p>					
F0.23	Fault protection action selection 5	0000~2222	0000	1	
<p>Unit's digit: Encoder fault 0: Coasting stop 1: Swtichover to V/f, and stop by stop mode 2: Swtichover to V/f, and continue running Ten's digit: User-defined fault 1 (same as unit's digit) Hundred's digit: User-defined fault 2 (same as unit's digit) Thousand's digit: Multi pump interlock fault (same as unit's digit)</p>					
F0.24	Frequency selection for continuing to run upon fault	0~4	0	1	
<p>0: Current running frequency 1: Setting frequency 2: Upper limit frequency 3: Lower limit frequency 4: Backup frequency upon abnormality</p>					
F0.25	Backup frequency upon abnormality	0.0~100.0	100.0	0.1%	
F0.26	Fire mode enable	0~1	0	1	0: Disabled 1: Enabled
F0.27	Fire mode frequency	0.00~b0.00	50.00	0.01Hz	
F0.28	Fire mode PID setting increase	0.0~200.0	10.0	0.1%	

F1 Auto Reset

Code	Name	Range	Default	Step	Description
F1.00	Fault auto reset times	0~30	0	1	
F1.01	Time interval of fault auto reset	0.1~100.0	1.0	0.1Sec	
F1.02	DO action during fault auto reset	00~11	00	1	
Unit's digit: Fault indication terminals 0: No action during fault reset process 1: Action during fault reset Ten's digit: restart after automatic fault reset 0: Not auto restart 1: having auto restart					

H0 System Parameters

Code	Name	Range	Default	Step	Description
H0.00	User password	0000~9999	0000	1	
H0.01	LED display running parameters 1	0~65535	31	1	
Bit0: Running frequency(1) Bit6: Output power(64) Bit11: Y terminals status(2048) Bit1: Setting frequency(2) Bit7: AI1 voltage(128) Bit12: PLC stage(4096) Bit2: Dc-link voltage(4) Bit8: AI2 voltage(256) Bit13: PID setting(8192) Bit3: Output current(8) Bit9: AI3 voltage(512) Bit14: PID feedback(16384) Bit4: Output voltage(16) Bit10: X terminals status(1024) Bit15: Count value(32768) Bit5: Output torque(32)					
H0.02	LED display running parameters 2	0~2047	0	1	
Bit0: Fl input frequency(1) Bit4: remaining running time(16) Bit8: Feedback speed(256) Bit1: Linear speed(2) Bit5: Main frequency A (32) Bit9: motor speed(512) Bit2: Load speed(4) Bit7: FO output frequency(128) Bit10: Multi-Pump Control status words(1024) Bit3: Actual length(8)					
H0.03	LED display stop parameters	1~65535	3	1	
Bit0: Setting frequency(1) Bit5: AI2 voltage(32) Bit10: PLC stage(1024) Bit1: Dc-link voltage(2) Bit6: AI3 voltage(64) Bit11: Pulse input frequency(2048) Bit2: X terminals status(4) Bit7: Fl input frequency(128) Bit12: actual length(4096) Bit3: Y terminals status(8) Bit8: PID setting(256) Bit13~Bit15: reserve Bit4: AI1 voltage(16) Bit9: PID feedback(512)					
H0.04 ^①	Parameter initial option	0~4	0	1	
0: No Operation 1: Restore to factory default value, not include motor parameters 2: Restore to factory default value, including motor parameters 3: Parameter upload to keypad 4: Parameter download from keypad					
H0.05	Menu display selection	0~2	0	1	
0: Display all parameters 1: Display user-defined parameters 2: Display non factory setting parameters					

Code	Name	Range	Default	Step	Description
H0.06	Function code lock	0~1	0	1	0:Disabled 1:Enabled
H0.07	Accumulative power on time lock password	0~9999	0	1	
H0.08	Load speed display coefficient	0.001~9.999	0.300	0.001	
H0.09	Load speed display decimal digits	0~3	1	1	
H0.10 ^①	G/L setting	0~1	0	1	0: G type 1: L type
H0.11 ^①	Fan control	0~2	0	1	
0: Automatic run		1: Run after power on		2: Temperature control	
H0.12	Dead zone compensation mode selection	0~3	1	1	
0: No compensation		2: Trapezoid compensation			
1: Rectangle compensation		3: Trapezoid at Low frequency and rectangle at high frequency			
H0.13 ^①	Dead zone compensation size	1~2048	1024	1	
H0.14 ^①	Angle size when current across zero	1~3640	Module dependent	1	
H0.15 ^①	Dead zone compensation filter cut off frequency 1	0.10~300.00	50.00	0.01Hz	
H0.16 ^①	Dead zone compensation filter cut off frequency 2	0.10~300.00	200.00	0.01Hz	
H0.17 ^①	Dead zone compensation switchover frequency 1	0.10~H0.18	5.00	0.01Hz	
H0.18 ^①	Dead zone compensation switchover frequency 2	H0.17~b0.00	50.00	0.01Hz	
H0.19 ^①	Optional card selection	0~11	0	1	
0: no optional card		4: IO4(PT100, PT1000)		8: COM2(Profibus)	
1: IO1(Y3,T3~T6 of normally open)		5: PG1(ABZ differential type,optional 5V/12V)		9: COM3(CANopen)	
2: IO2(AI3,Y3, X7~X10)		6: PG2(ABZ OC & Push-pull type,optional 5V/12V/24V)		10: COM4(GPRS)	
3: IO3(X7~X10,T3~T4 of normally open)		7: COM1(RS485+Modbus RTU,AI3,Y3,X7~X8)		11: COM5(Modbus TCP)	
H0.20	Product series	0~999	Module dependent Factory setting	1	
H0.21	Function firmware version	0.00~99.99		0.01	
H0.22	Algorithm firmware version	0.00~99.99		0.01	
H0.23	Keypad firmware version	0.00~99.99		0.01	
H0.24	Product series number higher bits	0~65535			
H0.25	Product series number lower bits	0~65535			
H0.26	OTP version	0.00~99.99			

H1 AI/AO Calibration

Function Code	Name	Range	Default	Step	Description
H1.00	AI1 actual voltage 1	0.500~4.000	Factory setting	0.001V	
H1.01	AI1 display voltage 1	0.500~4.000	Factory setting	0.001V	
H1.02	AI1 actual voltage 2	6.000~9.999	Factory setting	0.001V	
H1.03	AI1 display voltage 2	6.000~9.999	Factory setting	0.001V	
H1.04	AI2 actual voltage 1	0.500~4.000	Factory setting	0.001V	
H1.05	AI2 display voltage 1	0.500~4.000	Factory setting	0.001V	
H1.06	AI2 actual voltage 2	6.000~9.999	Factory setting	0.001V	
H1.07	AI2 display voltage 2	6.000~9.999	Factory setting	0.001V	
H1.08	AI3 actual voltage 1	0.500~4.000	Factory setting	0.001V	
H1.09	AI3 display voltage 1	0.500~4.000	Factory setting	0.001V	
H1.10	AI3 actual voltage 2	6.000~9.999	Factory setting	0.001V	
H1.11	AI3 display voltage 2	6.000~9.999	Factory setting	0.001V	
H1.12	AO1 display voltage 1	0.500~4.000	Factory setting	0.001V	
H1.13	AO1 actual voltage 1	0.500~4.000	Factory setting	0.001V	
H1.14	AO1 display voltage 2	6.000~9.999	Factory setting	0.001V	
H1.15	AO1 actual voltage 2	6.000~9.999	Factory setting	0.001V	
H1.16	AO2 display voltage 1	0.500~4.000	Factory setting	0.001V	
H1.17	AO2 actual voltage 1	0.500~4.000	Factory setting	0.001V	
H1.18	AO2 display voltage 2	6.000~9.999	Factory setting	0.001V	
H1.19	AO2 actual voltage 2	6.000~9.999	Factory setting	0.001V	

L0 Communication Setting

Function Code	Name	Range	Default	Step	Description
L0.00	Baud rate	0~4	1	1	
0: 4800 bps 1: 9600 bps 2: 19200 bps 3: 38400 bps 4: 57600 bps					
L0.01	Data format	0~3	0	1	
0: No check, data format <8,N,1> 2: Even parity check, data format <8,E,1> 1: No check, data format <8,N,2> 3: Odd parity check, data format <8,O,1>					
L0.02	Slave address	1~247	1	1	
L0.03	Response delay	0~20	2	1mSec	
L0.04	Communication timeout detection time	0.0~60.0	0.0	0.1Sec	Zero means no timeout detection.

L1 Point-point Communication

Function Code	Name	Range	Default	Step	Description
L1.00 ^①	Master and slave selection	0~1	1	1	0: Master 1: Slave
L1.01 ^①	Send data selection of master	0~3	1	1	0: Torque reference 1: Running frequency 2: Setting frequency 3: Feedback frequency
L1.02 ^①	Point-point communication enable	0~1	0	1	0: Disabled 1: Enabled
L1.03 ^①	Usage of data received by slave	00~11	01	1	
Unit's digit: Data usage of slave 0: as torque reference 1: as frequency reference Ten's digit: Whether to follow the master commands 0: No 1: Yes					
L1.04	Gain of received data	-9.99~10.00	1.00	0.01	
L1.05	Zero offset of received data	-99.9~100.0	0.0	0.1%	

L2 Encoder Setting

Function Code	Name	Range	Default	Step	Description
L2.00 ^①	Encoder type	0~4	0	1	
0: ABZ incremental Encoder 2: Rotational resolver 4: Wire-saving UVW Encoder 1: UVW incremental Encoder 3: Sine and cosine Encoder					
L2.01 ^①	Encoder pulse per revolution	1~65535	1024	1	
L2.02 ^①	A/B phase sequence of ABC incremental Encoder	0~1	0	1	0: Positive 1: Negative
L2.03 ^①	Z pulse initial angle of ABZ incremental Encoder	0.0~359.9	0.0	0.1deg	
L2.04 ^①	Encoder installation angle	0.0~359.9	0.0	0.1deg	
L2.05 ^①	UVW phase sequence of UVW Encoder	0~1	0	1	0: Positive 1: Negative
L2.06 ^①	UVW Encoder angle offset	0.0~359.9	0.0	0.1deg	
L2.07 ^①	poles of resolver	1~65535	1	1	
L2.08 ^①	Encoder wire-break fault detection time	0.0~10.0	0.0	0.1Sec	
L2.09 ^①	Motor 2 Encoder type	0~4	0	1	Same As L2.00

Function Code	Name	Range	Default	Step	Description
L2.10 ^①	Motor 2 Encoder pulse per revolution	1~65535	1024	1	
L2.11 ^①	Motor 2 A/B phase sequence of ABC incremental Encoder	0~1	0	1	Same As L2.02
L2.12 ^①	Motor 2 Z pulse initial angle of ABZ incremental Encoder	0.0~359.9	0.0	0.1deg	
L2.13 ^①	Motor 2 Encoder installation angle	0.0~359.9	0.0	0.1deg	
L2.14 ^①	Motor 2 UVW phase sequence of UVW Encoder	0~1	0	1	Same As L2.05
L2.15 ^①	Motor 2 UVW Encoder angle offset	0.0~359.9	0.0	0.1deg	
L2.16 ^①	Motor 2 poles of resolver	1~65535	1	1	
L2.17 ^①	Motor 2 Encoder wire-break fault detection time	0.0~10.0	0.0	0.1Sec	

P0 User-defined Parameters

Users can add the frequently used parameters into user-defined group to access them quickly

H0.05 (Menu display type) = 1 (User-defined parameters), keypad only show P0 group defined parameters.

Example: P0.00 ~P0.14 defined **A0.00~A0.14**, set **H0.05** = 1, press "PRG", then you can see **A0.00~A0.14** and **H0.05**.

P0.00	User-defined Parameter 0	A0.00~P1.15 【A0.20】
P0.01	User-defined Parameter 1	A0.00~P1.15 【A0.21】
P0.02	User-defined Parameter 2	A0.00~P1.15 【A0.11】
P0.03	User-defined Parameter 3	A0.00~P1.15 【A0.04】
P0.04	User-defined Parameter 4	A0.00~P1.15 【A0.05】
P0.05	User-defined Parameter 5	A0.00~P1.15 【A0.06】
P0.06	User-defined Parameter 6	A0.00~P1.15 【A0.07】
P0.07	User-defined Parameter 7	A0.00~P1.15 【A0.08】
P0.08	User-defined Parameter 8	A0.00~P1.15 【A0.09】
P0.09	User-defined Parameter 9	A0.00~P1.15 【A0.10】
P0.10	User-defined Parameter 10	A0.00~P1.15 【A0.11】
P0.11	User-defined Parameter 11	A0.00~P1.15 【A0.12】
P0.12	User-defined Parameter 12	A0.00~P1.15 【A0.13】

P0.13	User-defined Parameter 13	A0.00~P1.15 【A0.14】
P0.14	User-defined Parameter 14	A0.00~P1.15 【A0.15】

P0.00 ~P0.14 default value is different. When **P0.00 ~P0.03** default value is special for H0.05 = 3, it is fitting for PID application.

P0.15	User-defined Parameter 15	H0.05~H0.05 【H0.05】
--------------	----------------------------------	----------------------------

P0.15 can not be revised.

P1 Debug Parameters

Function Code	Name	Range	Default	Step	Description
P1.00~P1.15	Debug parameter i (i=0,1,2,3,.....,15)	0~65535	0	1	Reserved for factory debug, user don't change them unless receive guidance from factory engineers suggestions.

P2 Factory Parameters

Function Code	Name	Range	Default	Step	Description
P2.00	Factory password	0~9999	0	1	

Chapter 6 Parameters Description

Group A0: Monitor

Parameters in A0 group are used to facilitate the user to view the drive state, all of these parameters are read only, users can't modify them. When using the keypad to view these parameters, the keypad will refresh these values.

A0.00	Range: 0.00~ b0.00	Default: 0.00
Running frequency	Unit: Hz It displays the absolute value of running frequency.	
A0.01	Range: 0.00~ b0.00	Default: 0.00
Setting frequency	Unit: Hz It displays the absolute value of set frequency.	
A0.02	Range: 0.0~3000.0	Default: 0.0
DC bus voltage	Unit: V It displays the drive's bus voltage.	
A0.03	Range: 0~1500	Default: 0
Output voltage	Unit: V It displays the drive's output voltage in the running state.	
A0.04	Range: 0.00~655.35	Default: 0.00
Output current	Unit: A It displays the drive's output current in the running state. 0.01A(drive Power ≤ 55kW) 0.1A(drive Power ≥ 75kW)	
A0.05	Range: -300.0~300.0	Default: 0.0
Output torque	Unit: % It displays the drive's output torque in the running state, the reference item is rated motor torque.	
A0.06	Range: 0.1~2000.0	Default: 0.0
Output power	Unit: kW It displays the drive's output power in the running state.	
A0.07	Range: 0~65535	Default: 0
Motor speed	Unit: RPM It displays the motor's rotate speed in the running state.	

A0.08 Range: 0.00~**b0.00** Default: 0.00
Main frequency A Unit: Hz
 It displays the setting of main frequency A.

A0.09 Range: 0.00~**b0.00** Default: 0.00
Auxiliary frequency B Unit: Hz
 It displays the setting of auxiliary frequency B.

A0.10 Range: 0~65535 Default: 0
AC drive status word It displays the drive status. The means of every bit is below:

Bits	0	1
Bit 0	No ready	Ready
Bit 1	Stop	Running
Bit 2	No fault	Fault
Bit 3	No warning	Warning
Bit 4	Forward	Reverse
Bit 5	00: Keypad control	01: Terminal control
Bit 6	10: Communication control	11: Invalid value
Bit 7	No signal of run enable	Received a signal of run enable
Bit 8	Drive control	Bypass control
Bit 9	Running frequency have not reached setting frequency	Running frequency have reached setting frequency
Bit 10	00: Constant speed	01: Accelerate speed
Bit 11	10: Decelerate speed	11: Invalid value
Bit 12	Common mode	JOG mode
Bit 13	Not in tuning	In tuning
Bit 14	No zero-speed output	Zero-speed output
Bit 15	Reserve	

A0.11 Range: -10.00~10.00 Default: 0.00
AI1 voltage Unit: V
 It display AI1 voltage. If the AI1 is analog current input mode then system will convert current value to voltage value.
 0mA equal to 0V, 20mA equal to 10V.




Figure 6- 1 Analog current mode convert to analog voltage mode

A0.12 AI2 voltage	Range: -10.00~10.00 Unit: V It display AI2 voltage, the covert mode same as A0.11 .	Default: 0.00
A0.13 AI3 voltage	Range: -10.00~10.00 Unit: V It display AI3 voltage, the covert mode same as A0.11 .	Default: 0.00
A0.14 AO1 voltage	Range: 0.00~10.00 Unit: V It display AO1 voltage, the covert mode same as A0.11 .	Default: 0.00
A0.15 AO2 voltage	Range: 0.00~10.00 Unit: V It display AO2 voltage, the covert mode same as A0.11 .	Default: 0.00
A0.16 X terminals status word	Range: 0~1023 Each bit corresponds to a X terminal status. 0: Disable 1: Enable Bit0: X1 (1) Bit1: X2 (2) Bit2: X3 (4) Bit3: X4 (8) Bit4: X5 (16) Bit5: X6 (32) Bit6: X7 (64) Bit7: X8 (128) Bit8: X9 (256) Bit9: X10 (512) For example: A0.16 = 55, The number of 55 is consist of (32+16+4+2+1), So the status of X6,X5,X3,X2 and X1 are validated.	Default: 0
A0.17 Y terminals status word	Range: 0~511 Each bit corresponds to a Y terminal status. 0: Disable 1: Enable Bit0: Y1 (1) Bit1: Y2 (2) Bit2: Y3 (4) Bit3: T1 (8) Bit4: T2 (16) Bit5: T3 (32) Bit6: T4 (64) Bit7: T5 (128) Bit8: T6 (256) For example: A0.17 = 29, The number of 29 is consist of (16+8+4+1), So the status of T2,T1,Y3 and Y1 are validated.	Default: 0
A0.18 FI frequency	Range: 0.00~100.00 Unit: kHz It displays X6/FI high speed pulse input frequency.	Default: 0.00
A0.19 FO frequency	Range: 0.00~100.00 Unit: kHz It displays Y2/FO high speed pulse output frequency.	Default: 0.00

A0.20 Range: 0.0~100.0 Default: 0.0
PID setting Unit: %, the unit is equal to engineering unit.
 They display the PID setting value. System use the unit of percent in PID internal calculation. For better of display the PID setting value, system will convert the value to engineering unit value. The decimal place will decided by **E5.01**.
 For example:
 E5.01(decimal place of engineering unit) = 1(1 decimal place)
 E5.00(engineering unit) = 1(select MPa)
 E5.03(Minimum setting of PID engineering unit) = 0.0
 E5.02(Maximum setting of PID engineering unit) = 6.0
 When setting target value is 60% in PID internal calculation, then
 $A0.20 = (E5.02 - E5.03) * 60.0\% + E5.03 = 3.6 \text{ Mpa}$




Figure 6- 2 The relationship of PID setting and engineering unit

A0.21 Range: 0.0~100.0 Default: 0.0
PID feedback Unit: %, the unit is equal to engineering unit.
 It displays PID feedback value, the method of get PID feedback value is same as **A0.20**.

A0.22 Range: -100.0~100.0 Default: 0.0
PID deviation Unit: %
 It displays the value of PID setting decrease PID feedback.

A0.23 Range: -100.0~100.0 Default: 0.0
PID output Unit: %
 It displays PID actual output value.

A0.24 Range: 0~15 Default: 0
PLC stage It displays PLC current run stage.

A0.25 Range: 0~65535 Default: 0
Pulse counter It displays the pulse counter of X terminal. When the function of X terminal is set to 42(set counter value) or 44(length counter value), the sample counter value is displayed by this parameter. If the input pulse frequency is very fast, please select the X6/FI terminal.

A0.26 Actual length	Range: 0~65535 Unit: m It display value of A0.25 divide to E7.08 , it is used for fixed length control.	Default: 0
A0.27 Linear speed	Range: 0.0~6553.5 Unit: m/Min It displays value of sample number at every minute divide to E7.08 .	Default: 0.0
A0.28 Remaining running time	Range: 0.0~6553.5 Unit: Min It displays the remaining running time when the timing operation is enabled. For details on timing operation, refer to Eb.00 to Eb.02 .	Default: 0.0
A0.29 Swing center frequency	Range: 0.00~ b0.00 Unit: Hz For details on timing operation, refer to parameters in group E7.	Default: 0.00
A0.30 Load speed	Range: 0~65535 It display the output frequency multiply by H0.08, the min unit is decided by H0.09. For example, in place of machine tool, the drive is not trail the equipment indirectly, it connect with a variable machine at first. Set the value of H0.08 suitably, customs could use keypad to watch the actual rotational speed of the machine.	Default: 0
A0.31 Feedback speed	Range: -b0.00~b0.00 Unit: Hz It displays the actual output frequency of the drive.	Default: 0.00
A0.32 Multi-pump status word	Range: 0000~4444 It displays the status of each in Multi-pump control mode. 0: in interlock or not used 1: ready 2: wait for change 3: connect to power grid 4: connect to AC drive Unit's digit: 1# pump status Ten's digit: 2# pump status Hundred's digit: 3# pump status Thousand's digit: 4# pump status	Default: 0000
A0.33 Encoder detection speed	Range: -320.00~320.00 Unit: Hz It displays the motor running frequency measured by the encoder.	Default: 0.00

A0.34	Range: 0~65535	Default: 0
Phase z counting	It displays the phase Z counting of the current ABZ or UVW encoder. The value increases or decreases by 1 every time the encoder rotates one revolution forwardly or reversely.	
A0.35	Range: 0~4095	Default: 0
Resolver position	It displays the current resolver position.	
A0.36	Range: 0~ b0.07	Default: 0
Reference voltage for V/F separation	Unit: V	
	They display the Reference output voltage in the V/F separation state.	
A0.37	Range: 0~ b0.07	Default: 0
Output voltage for V/F separation	Unit: V	
	They display the actual output voltage in the V/F separation state.	
A0.38	Range: -300.0~300.0	Default: 0.0
Target torque	Unit: %	
	It displays the current torque upper limit.	
A0.39	Range: 0.0~300.0	Default: 0.0
Upper torque limit	Unit: %	
	It displays the current setting torque upper limit	
A0.40	Range: -100.00~100.00	Default: 0.00
Communication setting	Unit: %	
	It displays the data written by means of the communication address 0x6400.	
A0.41	Range: -100.0~100.0	Default: 0.0
Point-to-point send data	Unit: %	
	It displays the data send by master in master-slave communication mode.	
A0.42	Range: -100.0~100.0	Default: 0.0
Point-to-point receive data	Unit: %	
	It displays the data received by slave in master-slave communication mode.	
A0.52	Range: 0~65535	Default: 0
Power-on time	Unit: Min	
	It is used to display the current power-on time of the drive, the unit is 1 minute.	

A0.53	Range: 0.0~6553.5	Default: 0.0
Running time	Unit: Min It is used to display the current running time of the drive, the unit is 0.1 minute.	
A0.54	Range: 0~9999	Default: 0
Accumulative power-on day	Unit: Day It is used to display the accumulative power-on day of the drive since the delivery. It add A0.55 is equal to the total accumulative power-on time.	
A0.55	Range: 0.00~23.99	Default: 0.00
Accumulative power-on hour	Unit: h It is used to display the accumulative power-on hour of the drive since the delivery. It add A0.54 is equal to the total accumulative power-on time.	
A0.56	Range: 0~9999	Default: 0
Accumulative running day	Unit: Day It is used to display the accumulative running day of the drive. It add A0.57 is equal to the total accumulative running time.	
A0.57	Range: 0.00~23.99	Default: 0.00
Accumulative running hour	Unit: h It is used to display the accumulative running hour of the drive. It add A0.56 is equal to the total accumulative running time.	
A0.58	Range: 0~65535	Default: 0
Accumulative power consumption	Unit: kWh It is used to display the accumulative power consumption of the drive until now.	
A0.59	Range: 0.0~300.0	Default: 0.0
Motor temperature	Unit: <input type="checkbox"/> The signal of the motor temperature can be sampled by PT100/PT1000 optional card. If the PT100/PT1000 optional card not be inserted, motor temperature will be display the default value(0.0 <input type="checkbox"/>).	
A0.60	Range: -40.0~125.0	Default: 0.0
Inverter module temperature	Unit: <input type="checkbox"/> It is used to display the IGBT temperature of the inverter module.	
A0.61	Range: -40.0~125.0	Default: 0.0
Rectifier module temperature	Unit: <input type="checkbox"/> It is used to display the rectifier bridge temperature.	

Group A1: Fault & Diagnostic

A1.00 Range: 0~54 Default: 0

Latest fault type It display the fault type upon latest fault.
 The characters of "Er" and fault code are displayed in LED.
 The relationship of fault code and fault type are described in the following table, the detail about the alarm and run mode are in **Chapter 7**.

Table 6- 1 The corresponding table of Fault type and fault code

Fault code	Fault type	Fault code	Fault type
0	No fault		
1	Hardware over voltage during acceleration	28	Motor short circuit to ground fault
2	Hardware over voltage during deceleration	29	External fault
3	Hardware over voltage during constant speed	30	Keypad communication fault
4	Software over voltage during acceleration	31	RS485 communication fault
5	Software over voltage during deceleration	32	Optional card communication fault
6	Software over voltage during constant speed	33	Optional card connection fault
7	Under voltage	34	Auto tune fault
8	Hardware over current during acceleration	35	PID feedback over range
9	Hardware over current during deceleration	36	EEPROM R/W fault
10	Hardware over current during constant speed	37	Parameter setting fault
11	Software over current during acceleration	38	Accumulative power-on time reached
12	Software over current during deceleration	39	Accumulative running time reached
13	Software over current during constant speed	40	Motor switchover during running status.
14	IGBT saturation trip during acceleration	41	Too large speed deviation
15	IGBT saturation trip during deceleration	42	Motor over speed
16	IGBT saturation trip during constant speed	43	Flux pole detection fault
17	Heatsink of rectifier overheat	44	UVW signal feedback fault
18	Heatsink of inverter overheat	45	Encoder fault
19	Input phase loss	46	User-defined fault 1
20	Output phase loss	47	User-defined fault 2
21	Soft startup relay fault	48	Motor in current stall status
22	Current detection fault	49	Motor in voltage stall status
23	CBC fault	50	Motor in frequency drop status as dc-link voltage drop
24	VFD overload	51	System fault
25	Motor overload	52	Interlock warning during multi-pump operation mode
26	Motor under load	53	Soft startup resistor overload
27	Motor overheat	54	Sleep status

A1.01	Range: 0.00~ b0.00	Default: 0.00
Output frequency upon latest fault	Unit: Hz Same as A0.00	
A1.02	Range: 0.00~655.35	Default: 0.00
Output current upon latest fault	Unit: A Same as A0.04	
A1.03	Range: 0.0~6553.5	Default: 0.0
Dc-link voltage upon latest fault	Unit: V Same as A0.02	
A1.04	Range: 0~1023	Default: 0
X terminals state upon latest fault	Same as A0.16	
A1.05	Range: 0~511	Default: 0
Y terminals state upon latest fault	Same as A0.17	
A1.06	Range: 0~65535	Default: 0
VFD state upon latest fault	Same as A0.10	
A1.07	Range: -40.0~125.0	Default: 0.0
Inverter temperature upon latest fault	Unit: <input type="checkbox"/> Same as A0.60	
A1.08	Range: 0~65535	Default: 0
Power-on time upon latest fault	Unit: Min Same as A0.52	
A1.09	Range: 0.0~6553.5	Default: 0.0
Running time upon latest fault	Unit: Min Same as A0.53	
A1.10	Range: 0~9999	Default: 0
Accumulative running day upon latest fault	Unit: Day Total accumulative running time upon latest fault is A1.10+A1.11	
A1.11	Range: 0.00~23.99	Default: 0.00
Accumulative	Unit: h	

running hour upon latest fault Total accumulative running time upon latest fault is A1.10+A1.11

The parameters of **A1.12~A1.23** are the penultimate fault record, the mean of these parameters same as **A1.00~A1.11**

The parameters of **A1.24~A1.35** are the third fault record, the mean of these parameters same as **A1.00~A1.11**

Group b0: Basic Parameters

b0.00^o	Range: 30.00~650.00/30.00~3500.00	Default: 50.00
Maximum frequency	Unit: Hz	
	B2.07=2, Maximum frequency limit is 650Hz ; B2.07=1, Maximum frequency limit is 3500Hz.	
	The parameter define the Max allowable output frequency. it is the reference of some frequency setting, but also the acceleration and deceleration time. Please set up suitable value in the actual application filed.	
b0.01^o	Range: 0~5	Default: 0
Source of Upper limit frequency	Please select suitable value according to the actual demand.	
	0: b0.02	1: AI1 2: AI2
	3: AI3	4: X6/FI 5: Communication setting
b0.02	Range: b0.03~b0.00	Default: 50.00
Digital setting of upper limit frequency	Unit: Hz	
	The upper limit frequency is used to set the maximum allowable output frequency, its value should be less than or equal to the maximum frequency. When setting frequency is higher than the upper limit frequency, drive will run in the upper limit frequency.	
b0.03	Range: 0.00~ b0.02	Default: 0.00H
Lower limit frequency	Unit: Hz	
	The lower limit frequency is used to set the allowable minimum frequency of the motor running, its value should be less than or equal to the upper limit frequency. When setting frequency less than the lower limit of frequency converter, the run mode according to the b1.17.	
Note: the parameters of max frequency, upper limit frequency and lower limit frequency should be set based on the motor. The relationship of these parameters is max frequency ≥upper limit frequency ≥lower limit frequency.		
b0.04	Range: 0.1~6000.0	Default: Model dependent

Acceleration Unit: Sec
time 1 Acceleration time indicates the time required by the drive to accelerate from 0 Hz to **E4.09**, please see the T1 in the following figure.
b0.05 Range: 0.1~6000.0 Default: Model dependent
Deceleration Unit: Sec
time 1 Deceleration time indicates the time required by the drive to decelerate from **E4.09** to 0 Hz, please see the T2 in the following figure.




Figure 6- 3 Acc/Dec time map

b0.06^o Range: 0.1~999.9 Default: Model dependent
Motor rated power Unit: kW
 The default value of motor rated power is the same with AC drive rated power(G type).
 For example:
 If the AC drive type is 4T-3R7G/5R5L, then the default value of motor rated power is 3.7kW.
 If the AC drive type is 4T-5R5G/7R5L, then the default value of motor rated power is 5.5kW.
b0.07^o Range: 1~2000 Default: Model dependent
Motor rated voltage Unit: V
 The default value of motor rated voltage and AC drive voltage level are consistent.
b0.08^o Range:
Motor rated current 0.01~655.35(Drive power ≤ 55kW) Default: Model dependent
 0.1~6553.5(Drive power ≥ 75kW)
 Unit: A
 The default value of motor rated current matches with motor rated power.
 When you modified b0.06(motor rated power), motor rated current default value will be changed.
b0.09^o Range: 10.00~**b0.00** Default: 50.00

Motor rated frequency Unit: Hz
 Please set according to the motor nameplate data.

b0.10^o Range: 1~65535 Default: 1460

Motor rated speed Unit: RPM
 The default value of this parameter is estimated based on the motor which have four poles.
 Please set according to the motor nameplate data.

Note: both the VF and vector control, in order to ensure the control performance, please be sure to follow the actual motor nameplate data set the correct values of b0.06~b0.10 parameters.

b0.11 Range: 0~2 Default: 0

Command source
 The parameter is used to select command source. Run Command includes: start, stop, forward, reverse, JOG and so on.

0: keypad control
 These keys of "RUN", "JOG", "STOP/RST" are used to control drive run.
 If the keypad is command source then the light of "MON" on the keypad keep off state always.

1: I/O terminal control
 System control drive run, stop, forward, reverse, forward JOG, reverse JOG and so on by configure the X terminal functions. control mode can be two line or three line, about detail please see the parameter of **C0.17**.
 If the terminal is command source then the light of "MON" on the keypad keep bright state always.

3: communication
 PC send run command to drive by RS485 field bus.
 If the terminal is command source then the light of "MON" on the keypad keep flashing state.

Note: the command source of keypad, terminal and communication can be switched each other by the x terminal function of number 32(the command source switching terminal 1) and number 33(the command source switching terminal 2).

b0.12^o Range: 0~13 Default: 0

Application setting
 0: General
 1: PID application
 2: Constant pressure water supply of one AC drive with two pumps
 3~13: Reserved

Code	Name	Setting value when b0.12= 1	Setting value when b0.12= 2
b0.03	Lower limit frequency	20.00Hz	20.00Hz
b0.11	Command source	1: I/O terminal	1: I/O terminal
b1.20	Reverse prohibition	1: Reverse disabled	1: Reverse disabled

b2.00	Main frequency source A	5: PID	5: PID
C0.03	X3 function	-	48: Motor 1# interlock input
C0.04	X4 function	-	49: Motor 2# interlock input
C0.18	UP/DOWN adjustment selection	2: PID reference	2: PID reference
C1.04	T1 function	-	40: Motor 1# control output
C1.05	T2 function	38: PID sleep status indication	41: Motor 2# control output
C2.04	AI curve1 minimum input	2.00V	2.00V
E5.00^o	PID engineering unit	1: Pressure(MPa)	1: Pressure(MPa)
E5.01	PID engineering unit resolution	2: Two decimals	2: Two decimals
E5.02	Maximum setting of PID engineering unit	1.00 MPa	1.00 MPa
E5.05	PID digital setting	0.50 MPa	0.50 MPa
E5.26	PID deviation limit	1.0%	1.0%
E5.36	Wake up level	50.0%	50.0%
E5.37	Wake up delay time	1.0 Sec	1.0 Sec
E5.40	Sleep frequency	22.00 Hz	22.00 Hz
E5.41	Sleep delay time	1.0 Sec	1.0 Sec
E6.00	Multi-pump control mode	-	4: Frequency pump circulation,Support auto change
E6.01	Number of motors	-	2
E6.05	Interlock functions	-	01: Interlock enabled,decided by X terminals
H0.01	LED display running parameters 1	24715(1+2+8+128+8192+16384)	24715(1+2+8+128+8192+16384)
H0.02	LED display running parameters 2	-	1024
H0.03	LED display stop parameters	787(1+2+16+256+512)	787(1+2+16+256+512)

Group b1: Run & Stop Logic

b1.00[Ⓞ] Range: 0~1 Default: 0
Acceleration /Deceleration mode It is used to set the frequency change mode during the drive start and stop process
 0: Linear

The output frequency increases or decreases in linear mode, please see the following figure.

1: S curve

Use S curve mode at the beginning and the ending period of acceleration and deceleration can make the process more smooth. It could protect the load from impact. Please see the following figure.




Figure 6- 4 S curve acc/dec

b1.01 and b1.02 set the proportion of S curve on the beginning section and the ending section of acceleration and deceleration period. Please see the figure above, T1, T3 and T2, T4. At the beginning of section(T1, T3) and end of section(T2, T4), slope of acceleration and deceleration is gradually changing; Within the time of middle segment(T1-T2 and T3-T4), the slope of the output frequency change remains unchanged. that is, linear acceleration/deceleration.

For example: if set the current acceleration time is acceleration time 1(b0.04) and the current deceleration time is deceleration 1(b0.05), then:

$$T1 = b0.04 * b1.01 \quad T2 = b0.04 * b1.02$$

$$T3 = b0.05 * b1.01 \quad T4 = b0.05 * b1.02$$

b1.01[Ⓞ] Range: 0.0~ (100.0 - **b1.02**) Default: 30.0
Time proportion of S-curve start segment Unit: %
 These parameter define the time proportions of the start segment of S-curve acceleration/deceleration.

b1.02[Ⓞ] Range: 0.0~ (100.0 - **b1.01**) Default: 30.0
Time proportion of S-curve end segment Unit: %
 These parameter define the time proportions of the end segment of S-curve acceleration/deceleration.

b1.03	Range: 0.00~50.00	Default: 0.00
Startup frequency	Unit: Hz	
	Start frequency is the initial frequency of drive from stop to start. It not restricted by lower frequency limit. If setting frequency less than startup frequency, the drive will run with the frequency of zero.	
b1.04^o	Range: 0.0~100.0	Default: 0.0
Startup frequency holding time	Unit: s	
	When startup, drive will run and use the frequency of b1.03, it will holding the frequency base on b1.04 then accelerate to setting frequency.	
	Note:	
	<ul style="list-style-type: none"> ◆ If the set target frequency is lower than the startup frequency, the drive will not start. ◆ During switchover between forward rotation and reverse rotation, the startup frequency holding time is disabled. ◆ The holding time is not included in the acceleration time. ◆ The holding time is included in the running time of PLC. 	
b1.05	Range: 0~1	Default: 0
Start mode	0: Ramp start from startup frequency	
	It is applicable to small-inertia load. DC braking before the start is applicable to drive of load such as elevator and crane.	
	Startup frequency is applicable to drive with burst start under start torque, such as cement mixer.	
	1: Rotational speed tracking start	
	It is applicable to large-inertia load. If the load motor is still rotating due to the inertia when the drive starts, this mode is used to prevent start overcurrent.	




Figure 6- 5 startup frequency

b1.06^o	Range: 0~2	Default: 0
--------------------------	------------	------------

Flying start mode	To complete the rotational speed tracking process within the shortest time, select the proper mode in which the drive tracks the motor rotational speed. 0: From frequency at stop It is the commonly selected mode 1: From zero frequency It is applicable to restart after a long time of power failure. 2: From maximum frequency It is applicable to the power-generating load.	
b1.07^o	Range: 50.0~200.0	Default: 90.0
Flying start current	Unit: % It is used to setting the output current when drive in speed tracking. It is not be changed commonly.	
b1.08	Range: 1~100	Default: 5
Flying start speed	The larger the value is, the faster the tracking is. However, too large value may cause unreliable tracking.	
b1.09^o	Range: 30.0~100.0	Default: 100.0
V/f coefficient for flying start	Unit: % When drive is tracking the motor speed, v/f curve will multiply by the parameter. it could restrain the output current and improve the reliability of speed tracking.	
b1.10	Range: 0~1	Default: 0
Stop mode	0: Ramp stop After the stop command is enabled, the drive decreases the output frequency according to the deceleration time and stops when the frequency decreases to zero. 1: Coasting stop After the stop command is enabled, the drive immediately stops the output. The motor will coast to stop based on the mechanical inertia.	
b1.11^o	Range: 0~100	Default: 20
Start DC brake current	Unit: % This parameter specifies the output current at DC braking when drive is starting. it is a percentage relative to the base value, the base value is motor rate current. If the parameter value is bigger than drive rate current then the output brake current will be limited by drive rate current. The brake current larger, the greater the brake torque.	
b1.12^o	Range: 0.0~100.0	Default: 0.0
Start DC brake	Unit: Sec	

time	This parameter specifies DC brake time when drive startup. If the startup DC braking time is 0, the drive starts directly without DC braking.	
b1.13	Range: 0.00~ b0.00	Default: 0.00
Initial frequency of stop DC brake	Unit: Hz	
	During the process of decelerating to stop, the drive starts DC braking when the running frequency is lower than the value set in F6-11.	
b1.14	Range: 0.0~100.0	Default: 0.0
Stop DC brake waiting time	Unit: s	
	When the running frequency decreases to the initial frequency of stop DC braking, the drive stops output for a certain period and then starts DC braking. This prevents faults such as overcurrent caused due to DC braking at high speed. About the detail please see figure below.	
b1.15	Range: 0~100	Default: 20
Stop DC brake current	Unit: %	
	This parameter specifies the output current at DC braking when drive is stopping. It is a percentage relative to the base value, the base value is motor rate current. If the parameter value is bigger than drive rate current then the output brake current will be limited by drive rate current.	
b1.16	Range: 0.0~100.0	Default: 0.0
Stop DC brake time	Unit: s	
	This parameter specifies the holding time of DC braking. If it is set to 0, DC braking is invalid.	

In deceleration stopping(**b1.10** set to 0), if the output frequency is reduced to the set value of **b1.13**, then drive enter DC brake process. At first, the drive output close PWM(the close PWM time is determined by **b1.14**), and then drive enter the DC brake mode. The brake current is determined by **b1.15**, the duration is determined by **b1.16**. If **b1.16** is set to 0, then stop DC brake is invalid, drive will stop according to time. Specific braking process is shown in the following figure.

Note:

1. The appropriate stop DC brake waiting time could decrease the fault when motor is running with high speed and start DC braking.
2. The larger the braking current is, the greater the braking torque greater, but too much braking current and long braking time may damage the motor and drive.




Figure 6-6 Stop DC brake

- b1.17** Range: 0~3 Default: 0
Running mode when running frequency lower than frequency lower limit
 The parameter determined drive action when setting frequency lower than frequency lower limit.
 0: Run at frequency lower limit
 1: Run at zero speed
 2: Stop
 3: Stop, restart when setting frequency higher than lower limit.
- b1.18** Range: 0~1 Default: 0
Keypad direction
 You can change the rotation direction of the motor just by modifying this parameter without changing the motor wiring. It is valid whatever the command source is.
 0: Same direction 1: Reverse direction

b1.19 Range: 0.0~3000.0 Default: 0.0
Forward/Reverse rotation dead-zone time Unit: s
 It is used to set the time when the output is 0Hz at transition of the drive forward rotation and reverse rotation, as shown in the following figure.




Figure 6- 7 Forward/reverse rotation dead-zone time

b1.20 Range: 0~1 Default: 0
Reverse control 0: Enabled
 1: Disabled
 It is used to set whether the drive allows reverse rotation. In the applications where reverse rotation is prohibited, set this parameter to 1.

b1.21 Range: 0~1 Default: 1
Stop key function STOP/RST key stop effective selection of functional mode.
 0: STOP/RST key enabled only in keypad control
 1: STOP/RST key enabled in any operation mode
 Because the key of STOP/RST is multiplexed, when the key is used to reset fault, it is enabled always.

b1.22 Range: 0~1 Default: 1
Startup protection 0: No 1: Yes
 This parameter is used to set whether to enable the safety protection. If it is set to 1, the drive does not respond to the run command valid upon drive power-on (for example, an input terminal is ON before power-on). The drive responds only after the run command is canceled and becomes valid again.
 In addition, the drive does not respond to the run command valid upon fault reset of the drive. The run protection can be disabled only after the run command is canceled.
 In this way, the motor can be protected from responding to run commands upon power-on or fault reset in unexpected conditions.

b1.23 Range: 0~100 Default: 100
Dynamic brake use ratio Unit: %
 The larger the value of this parameter is, the better the braking result will be. However, too larger value causes great fluctuation of the drive bus voltage during the braking process. If it is set to 0, dynamic brake is invalid. d0.13 needs to be set as 0 before using the dynamic brake function.

b1.24 Range: Model dependent Default: Model dependent
Dynamic brake voltage Unit: V
 Different drive voltage grade have different range and default value, please see the table below:

Table 6- 2 the relation of drive voltage grade with dynamic brake voltage

Volt Grade	Default	Min	Max
Three-phase 380V	680V	630V	770V
Three-phase 480V	750V	660V	870V

Note: In actual application, you can combine dynamic braking, flux braking and overvoltage stall control to optimize braking effect.

For example:

- ◆ Set V/F over-excitation gain(d0.09) to 77 then make the over excitation become to 1.2 times of standard when drive in decelerating. It can increase the excitation and increase the braking capacity.
- ◆ Set overvoltage stall protective voltage(d0.14) to 720V.
- ◆ Set overvoltage stall gain(d0.13) to 10.
- ◆ Set Dynamic brake voltage(b1.24) to 700V.
- ◆ Set dynamic brake use ratio to 50%, you can modify the value according to actual power consumption on braking resistor.

It not only can meet the requirements of rapid deceleration but also can avoid overvoltage in the rapid decelerating.

b1.25^o Range: 0~1 Default: 1
Multi function of JOG key For function selection of JOG key on Keypad.
 0: JOG 1: Forward/Reverse switching 2: Command source switching

Group b2: Frequency Source

b2.00[®]	Range: 0~8	Default: 0
Main frequency source A	It is used to select the setting channel of the main frequency A. You can set the main frequency in the following 9 channels: 0: Digital setting b2.01 +UP/DOWN The initial value of the set frequency is the value of b2.01 (Preset frequency). You can change the set frequency by turn the knob or X input terminal UP/DOWN function. When the drive is powered on again after power off or start again after stop, the set frequency is memorized or not determined by C0.19 . 1: AI1 2: AI2 3: AI3 The frequency is set by analog input. The AC drive control board provides two analog input (AI) terminals (AI1, AI2). Another AI terminal (AI3) is provided by the I/O extension card. AI1 and AI2 can select voltage mode(-10v~10v) or current mode(0~20mA) by CJ1 and CJ2(on control board). The corresponding relationship between the analog input value and the setting frequency please see the group C2 . 4: X6/FI The frequency is set by X6/FI terminal. You should set the function to 31 for X6 terminal. The corresponding relationship between pulse input frequency and setting frequency please see the parameters description between C4.00 to C4.04 . 5: PID The output of PID control is used as the running frequency. PID control is generally used in on-site closed-loop control, such as constant pressure closed-loop control and constant tension closed-loop control. When applying PID as the frequency source, you need to set parameters of PID function in group E5 . 6: PLC When PLC mode is used as the frequency source, the running frequency of the drive can be switched over among the 16 frequency references. You can set the holding time and acceleration/deceleration time of the 16 frequency references. For details, refer to the descriptions of Group E3 .	

7: Multi-reference

In multi-reference mode, combinations of different DI terminal states correspond to different set frequencies. The AC drive supports a maximum of 16 speeds implemented by 16 state combinations of four DI terminals (allocated with functions 16 to 19) from **E2.01** to **E2.16**. Multi-reference is prioritized.

8: Communication setting

PC can set the value of Main frequency source A through the standard RS485 port. The detail please see chapter 8(MODBUS communication protocol).

b2.01 Range: 0.00~**b0.00** Default: 50.00
Preset Frequency Unit: Hz
 If the frequency source is digital setting, the value of this parameter is the initial frequency of drive.

b2.02[®] Range: 0~8 Default: 0
Auxiliary frequency source B The same as **b2.00**.

Note:

1. The main frequency source A and auxiliary frequency source B must not be set to same value.
2. If frequency source selection is set to main frequency source A and auxiliary frequency source B operation relationship(The Unit's digit of b2.05 set to 1,3 or 4), the 100% of AI1, AI2 and pulse input corresponding to the maximum frequency(b0.00).

b2.03 Range: 0~100 Default: 100
Range of auxiliary frequency source B Unit: %
 If frequency source selection is set to main frequency source A and auxiliary frequency source B operation relationship(The Unit's digit of b2.05 set to 1,3 or 4), the parameter is used to set the range of auxiliary frequency source B, the base value is max frequency.

b2.04 Range: 0.00~**b0.00** Default: 0.00
Offset frequency for A and B operation Unit: Hz
 If frequency source selection is set to main frequency source A and auxiliary frequency source B operation relationship(The Unit's digit of b2.05 set to 1,3 or 4), The final frequency is obtained by adding the frequency offset set in this parameter to the A and B operation result.

b2.05	Range: 00~34	Default: 00
Frequency source selection	Unit's digit: Frequency source selection	
	0: Main frequency source A.	
	1: A and B operation	
	The result of A and B operate as the aim frequency, the operate relationship determined by ten's digit of the parameter.	
	2: Switchover between A and B	
	Switchover between main frequency source A and auxiliary frequency source B. If X terminal function of 29 is invalid then the main frequency source A as the aim frequency. If X terminal function of 29 is valid then the auxiliary frequency source B as the aim frequency.	
	3: Switchover between A and "A and B operation"	
	Switchover between main frequency source A and the result of "main frequency source A and auxiliary frequency source B" operation. If X terminal function of 29 is invalid then the main frequency source A as the aim frequency. If X terminal function of 29 is valid then the result of "main frequency source A and auxiliary frequency source B" operation as the aim frequency.	
	4: Switchover between B and "A and B operation"	
	Switchover between main frequency source B and the result of "main frequency source A and auxiliary frequency source B" operation. If X terminal function of 29 is invalid then the main frequency source B as the aim frequency. If X terminal function of 29 is valid then the result of "main frequency source A and auxiliary frequency source B" operation as the aim frequency.	
	Ten's digit: A and B operation relationship	
	0: A+B	
	The operation method is main frequency source A add auxiliary frequency source B.	
	1: A-B	
	The operation method is main frequency source A subtract auxiliary frequency source B.	
	2: min{A,B}	
	The operation method is get the minimum value between main frequency source A and auxiliary frequency source B.	
	3: max{A,B}	
	The operation method is get the maximum value between main frequency source A and auxiliary frequency source B.	

b2.06	Range: 000~999	Default: 000
Binding command source to frequency source	<p>It is used to bind the three running command sources with the nine frequency sources, facilitating to implement synchronous switchover.</p> <p>Unit's digit: Binding the frequency source together with Keypad control source</p> <p>0: No binding 1: Frequency source by digital setting b2.01+UP/DOWN 2: AI1 3: AI2 4: AI3 5: Pulse setting (DI5) 6: Multi-reference 7: Simple PLC 8: PID 9: Communication setting</p> <p>Ten's digit: Binding the frequency source together with Terminal control source</p> <p>0–9, same as unit's digit</p> <p>Hundred's digit: Binding the frequency source together with Communication control source</p> <p>0–9, same as unit's digit</p> <p>Note:</p> <ul style="list-style-type: none">◆ Different running command sources can be bound to the same frequency source.◆ if a command source has a bound frequency source, the frequency source set in b2.00 to b2.05 no longer takes effect when the command source is effective.	
b2.07^o	Range: 1~2	Default: 2
Frequency resolution	<p>It is used to set the resolution of all frequency-related parameters.</p> <p>1: Minimum unit is 0.1 Hz 2: Minimum unit is 0.01 Hz</p> <p>If the resolution is 0.1 Hz, the AC drive can output up to 3000.0 Hz(CDE360B type). If the resolution is 0.01 Hz, the AC drive can output up to 600.00 Hz.</p> <p>Note: Modifying this parameter will make the decimal places of all frequency-related parameters change and corresponding frequency values change(pay attention to the rated motor frequency specially, b0.09 will change from 50.00Hz to 500.0Hz when set b2.07 from 1 to 2).Please confirm again after the operation of motor, otherwise it may cause personal and property losses.</p>	

Group C0: Digital Input

C0.00 Range: 0.000~1.000 Default value: 0.010
X terminals filter time Unit: Sec
 X1~X10 (X6/FI act as common terminal usage) sample filter time setting. Appropriate to adjustment the filter time can increase the terminal input signal ability of anti-interference, prevent the miss-operation; but with the slow response time.




Figure 6- 8 Digital input filter time.

C0.01^o Range: 0~58 Default: 3
X1 Function Set the X1 terminal of the corresponding function, a detailed explanation see the table below.

Table 6- 3 Functions of digit input

Setting	Function	Description
0	No function	When no function assigned to terminal, set to 0 can prevent miss-operation
1	Forward JOG(FJOG)	FJOG or RJOG through the terminal, JOG status depended on E0.00 (JOG frequency), E0.01 (JOG acceleration time), E0.02 (JOG deceleration time), E0.03 (JOG stop mode).
2	Reverse JOG(RJOG)	
3	Forward RUN(FWD)	When the run source is DI(b0.11 = 1),The run command of AC drive is depended on these terminals. A detailed explanation of usage refer to C0.17(Terminal command mode).
4	Reverse RUN(REV)	
5	Three-line control	
6	Run pause	When the AC drive in the process of operation, the X terminal configuration for this function effectively, the AC drive deceleration stop, at the same time keep the relevant operation parameters. Once the X terminal is invalid, the AC drive resumed operation.
7	Coast to stop	When the configuration for X terminal for this function effectively, the AC drive output immediately blockade and enter to the stop state. The stop mode is depended to b1.10.
8	External STOP terminal 1	When the command source is keypad(b0.11), and the configuration for this function is effective. The AC drive will stop according to the stop mode configuration. This is equal to keypad stop.

Setting	Function	Description
9	External STOP terminal 2	Under any control mode(b0.11 is an arbitrary value), the configuration of this function can make the AC drive stopped according to the stop mode. This deceleration time is fixed for E4.05(deceleration time 4).
10	Emergency Stop	When the configuration for X terminal for this function is effective, the AC drive will stop use the shortest possible stop time. The current arrives to the upper limit when stop in process, the bus voltage arrives to the voltage point for the over voltage control. This function is used to satisfy the system is in a state of emergency occasion, and need to quickly stop.
11	Immediate DC braking	When the configuration for X terminal for this function is effective, the AC drive immediately into DC braking state; The AC drive resumes to operation when the terminal is invalid, and accelerate to the setting frequency according to the setting acceleration time. Note: When the motor is running under high frequency, immediately switch into DC braking may cause the over current fault.
12	Deceleration DC braking	When the configuration for X terminal for this function is effective, the AC drive begin to slow down. When the output frequency is reduced to b1.13(Stop DC braking initial frequency), start to execute stop DC brake.
13	Terminal UP	Through the X terminal configuration for this function, can achieve the increment and decrement of specific variables.
14	Terminal DOWN	Specific variables by C0.18(UP/DOWN adjustment of choice) decision. Adjust the speed by C0.20(terminal UP/DOWN change rate) decision.
15	UP/DOWN setting clear (terminal, operation panel)	Through the X terminal configuration for this function, you can clear the adjustment of terminal UP/DOWN or keypad knob, so the settings back to the corresponding digital set value.
16	Multi-reference terminal 1	Through the multi speed terminal 1~4, can combined up to 16 section of frequency selection set, please refer to table below this table. When any X terminal selects multi speed function and effective. The frequency source forced to multi speed.
17	Multi-reference terminal 2	
18	Multi-reference terminal 3	
19	Multi-reference terminal 4	

Setting	Function	Description															
20	Terminal 1 for Acceleration /deceleration time selection	Through the X terminal configuration of these two functions, combination of up to 4 kinds of acceleration and deceleration time, as shown in the following table. <table border="1" style="margin: 10px auto;"> <thead> <tr> <th>Acceleration and deceleration time selection 2</th> <th>Acceleration and deceleration time selection 1</th> <th>Actual acceleration and deceleration time</th> </tr> </thead> <tbody> <tr> <td>OFF</td> <td>OFF</td> <td>Acc/Dec time 1 (b0.04,b0.05)</td> </tr> <tr> <td>OFF</td> <td>ON</td> <td>Acc/Dec time 2 (E4.00,E4.01)</td> </tr> <tr> <td>ON</td> <td>OFF</td> <td>Acc/Dec time 3 (E4.02,E4.03)</td> </tr> <tr> <td>ON</td> <td>ON</td> <td>Acc/Dec time 4 (E4.04,E4.05)</td> </tr> </tbody> </table>	Acceleration and deceleration time selection 2	Acceleration and deceleration time selection 1	Actual acceleration and deceleration time	OFF	OFF	Acc/Dec time 1 (b0.04,b0.05)	OFF	ON	Acc/Dec time 2 (E4.00,E4.01)	ON	OFF	Acc/Dec time 3 (E4.02,E4.03)	ON	ON	Acc/Dec time 4 (E4.04,E4.05)
Acceleration and deceleration time selection 2	Acceleration and deceleration time selection 1		Actual acceleration and deceleration time														
OFF	OFF	Acc/Dec time 1 (b0.04,b0.05)															
OFF	ON	Acc/Dec time 2 (E4.00,E4.01)															
ON	OFF	Acc/Dec time 3 (E4.02,E4.03)															
ON	ON	Acc/Dec time 4 (E4.04,E4.05)															
21	Terminal 2 for Acceleration /deceleration time selection	Note: You can change the Acc/Dec time when running.															
22	Acceleration /Deceleration prohibited	The function is effective to maintain the current AC drive output frequency, no longer in response to a change of frequency setting, but when receive a stop command, the AC drive can response the normal deceleration stop, and don't response to the terminal function.															
23	Fault reset	When a fault occurs , you can reset fault through this terminal function. The same as keypad key STOP/RST.															
24	Normally open (NO) input of external fault	A external fault signal can enter through the terminal, this is convenient for fault monitoring and protection of external equipment. If set to 24, when the terminal state is valid, the AC drive display the external fault according to the fault protection operation mode for fault treatment; If set to 25, when the terminal state is invalid, the AC drive display the external fault according to the fault protection operation mode for fault treatment.															
25	Normally closed (NC) input of external fault																
26	Frequency modification forbidden	When this terminal function effectively, regardless of whether the set frequency is modified, the AC drive never refresh the current set frequency; When the terminal function invalid, the AC drive refresh the set frequency in real time.															
27	Force main frequency source A to b2.01+UP/DOWN	When this terminal function effectively, force switch the frequency source A to 0: Digital set b2.01+UP/DOWN. When the terminal is invalid, the frequency A is decided by the parameter b2.00.															
28	Force auxiliary frequency source B to b2.01+UP/DOWN	When this terminal function effectively, force switch the auxiliary frequency source B to 0: Digital set b2.01+UP/DOWN. When the terminal is invalid, the frequency B is decided by the parameter b2.00.															
29	Frequency source switchover	When the unit of b2.05(frequency given way) set to 2, 3 or 4, by configuring this function, X terminal can switch between different frequency setting mode: When set to 2, can switch between A and B. When set to 3, can switch between A and the result of A,B operation. When set to 4, can switch between B and the result of A,B operation.															

Setting	Function	Description																																																				
30	Motor 1/2 switchover	The configuration of this function can select the current load motor. When the terminal is invalid, select the motor 1; When the terminal is valid, select the motor 2.																																																				
31	Pulse input(enabled only for X6/FI)	Only X6 terminal effective. When X6 selects this function, the pulse signal can be received act as the given frequency or count.																																																				
32	Command source switchover terminal 1	<p>When the setting of b0.11(command source selection) is effective, through the configuration of these two functions, can realize the switching between different command source.</p> <p>Such as X1 selects the "command source switching terminal 1" and X2 selects the "command source switching terminal 2". So:</p> <ul style="list-style-type: none"> When X1 and X2 has the same state, the command source is the value of b0.11 When the X1 is valid and X2 is invalid, the command source is the next setpoint of b0.11 When the X1 is invalid and X2 is valid, the command source is the previous setpoint of b0.11 The range of b0.11 is 0~2, the next of 0 is 1, the previous of 0 is 2; the next of 1 is 2 and the previous of 1 is 0; the next of 2 is 0, the previous of 2 is 1. <p>Table 6- 4 The truth table of command source switch terminals 1/2</p> <table border="1"> <thead> <tr> <th>b0.11 Setpoint</th> <th>Command source switch terminal 2</th> <th>Command source switch terminal 1</th> <th>Actual invalid command source</th> </tr> </thead> <tbody> <tr> <td>0 (Keypad control)</td> <td>OFF</td> <td>OFF</td> <td>Keypad control</td> </tr> <tr> <td>0 (Keypad control)</td> <td>OFF</td> <td>ON</td> <td>Terminal control</td> </tr> <tr> <td>0 (Keypad control)</td> <td>ON</td> <td>OFF</td> <td>Communication control</td> </tr> <tr> <td>0 (Keypad control)</td> <td>ON</td> <td>ON</td> <td>Keypad control</td> </tr> <tr> <td>1 (Terminal control)</td> <td>OFF</td> <td>OFF</td> <td>Terminal control</td> </tr> <tr> <td>1 (Terminal control)</td> <td>OFF</td> <td>ON</td> <td>Communication control</td> </tr> <tr> <td>1 (Terminal control)</td> <td>ON</td> <td>OFF</td> <td>Keypad control</td> </tr> <tr> <td>1 (Terminal control)</td> <td>ON</td> <td>ON</td> <td>Terminal control</td> </tr> <tr> <td>2 (Communication control)</td> <td>OFF</td> <td>OFF</td> <td>Communication control</td> </tr> <tr> <td>2 (Communication control)</td> <td>OFF</td> <td>ON</td> <td>Keypad control</td> </tr> <tr> <td>2 (Communication control)</td> <td>ON</td> <td>OFF</td> <td>Terminal control</td> </tr> <tr> <td>2 (Communication control)</td> <td>ON</td> <td>ON</td> <td>Communication control</td> </tr> </tbody> </table>	b0.11 Setpoint	Command source switch terminal 2	Command source switch terminal 1	Actual invalid command source	0 (Keypad control)	OFF	OFF	Keypad control	0 (Keypad control)	OFF	ON	Terminal control	0 (Keypad control)	ON	OFF	Communication control	0 (Keypad control)	ON	ON	Keypad control	1 (Terminal control)	OFF	OFF	Terminal control	1 (Terminal control)	OFF	ON	Communication control	1 (Terminal control)	ON	OFF	Keypad control	1 (Terminal control)	ON	ON	Terminal control	2 (Communication control)	OFF	OFF	Communication control	2 (Communication control)	OFF	ON	Keypad control	2 (Communication control)	ON	OFF	Terminal control	2 (Communication control)	ON	ON	Communication control
b0.11 Setpoint	Command source switch terminal 2	Command source switch terminal 1	Actual invalid command source																																																			
0 (Keypad control)	OFF	OFF	Keypad control																																																			
0 (Keypad control)	OFF	ON	Terminal control																																																			
0 (Keypad control)	ON	OFF	Communication control																																																			
0 (Keypad control)	ON	ON	Keypad control																																																			
1 (Terminal control)	OFF	OFF	Terminal control																																																			
1 (Terminal control)	OFF	ON	Communication control																																																			
1 (Terminal control)	ON	OFF	Keypad control																																																			
1 (Terminal control)	ON	ON	Terminal control																																																			
2 (Communication control)	OFF	OFF	Communication control																																																			
2 (Communication control)	OFF	ON	Keypad control																																																			
2 (Communication control)	ON	OFF	Terminal control																																																			
2 (Communication control)	ON	ON	Communication control																																																			
33	Command source switchover terminal 2																																																					

Setting	Function	Description
34	Speed control/torque control switchover	Through the configuration of this function, can realize the switch over speed control and torque control. Only the vector control support torque control.
35	Torque control prohibited	If the configuration of this function is effective, the AC drive force to speed control.
36	PLC status reset	If the configuration of this function is effective, pause the PLC running process, resume to the original state, if run again, from the original state. The PLC related parameter configuration is not be changed.
37	Reverse PID action direction	The combination of this terminal function and E5.21(PID output characteristic), can choose PID output characteristic direction. When the terminal is valid, the output direction is same as E5.21, when the terminal is invalid, the output direction is opposite to E5.21
38	PID pause	If the configuration of this function is effective, PID stop adjustment, the output frequency of the AC drive maintains the current state; When the terminal is invalid, PID resume to adjustment.
39	PID integral pause	If the configuration of this function is effective, the PID integrator stops accumulating, keep the current constant; When the terminal is invalid, PID resume to integrator.
40	PID parameter switchover	When E5.15 (PID parameter switching conditions) is set to 1(according to the X terminal of switching), through the X terminal's function configuration, can switch between the two sets of PID parameters. <ul style="list-style-type: none"> ● When X terminal is invalid, the PID parameter use set one (E5.09~E5.11). ● When X terminal is valid, the PID parameter use set two(E5.12~E5.14).
41	PID wakeup mandatory	PID wake up conditions generally depended by E5.36(wake-up threshold setting) and E5.37 (wake-up delay time). PID forced wake up function refers to whether or not PID wake up conditions are satisfied, as long as X terminal is valid, PID will exit the dormant state
42	Counter input	Through the configuration of the input count pulse function. When the frequency is high, you must use the X6/FI. A0.25(pulse count value) do display the current input count pulse. With the E7.05(set count value) and E7.06(specified count) and Y terminal function(20: set count arrive, 21: specify count arrive), you can realize the "Set count reach" and "Specify count reach" control.
43	Counter reset	Through the configuration of this function, you can clear the current value A0.25(Pulse count value).

Setting	Function	Description
44	length Count input	Through the configuration of the pulse length count function, AC drive can calculate the actual length for fixed length control. The current length value can be saved when power off. When the frequency is high, you must use the X6/FI. Please refer to the E7.07(set length) and E7.08(pulse number per meter) parameters' instruction.
45	Length reset	Through the configuration of this function, you can clear the calculated value of A0.26
46	Swing pause	Through the configuration of this function, is the X terminal is effective, the AC drive use A0.29(swing-frequency center frequency) to run.
47	Current running time reset	If the configuration of this function is effective, the A0.53(current run time) will be clear. With the Eb.03(current operating time limit) and Y terminal function(25:the current running time arrive). You can realize the "Current running time reach" control.
48	Motor 1# interlock input	Under multi-pump control, when the set value of E6.05(Motor interlock enable) is 01(interlock enable, the join of motor decided by X terminal), When the corresponding X terminal of motor receive s a effective signal, the AC drive will take the motor into multi-pump control logic, otherwise, always treat this motor not join the system.
49	Motor 2# interlock input	
50	Motor 3# interlock input	
51	Motor 4# interlock input	
52	User-Defined fault 1 input	If the configuration of these two functions are effective, the AC drive will respectively prompt "Er46" and "Er47", and running based on the F0.23(Fault protection option 5).
53	User-Defined fault 2 input	
54	static auto tune	Under standby mode, when the configuration of X terminal for this function change from invalid to effective, the AC drive start static parameter identification.
55	rotational auto tune	Under standby mode, when the configuration of X terminal for this function change from invalid to effective, the AC drive start gyrate parameter identification.
56	Force main frequency source A to PID	When configuration of this function and X terminal is effective, the AC drive mandatory use PID as current main frequency source A.
57	Force main frequency source A to PLC	When configuration of this function and X terminal is effective, the AC drive mandatory use PLC as current main frequency source A.
58	Fire mode input	When configuration of this function and X terminal is effective, the AC drive force into fire mode operation.

Note:

1. The priority of frequency source is Fire mode >JOG >Frequency bind >Force to PID >Force to PLC >Force to digit set >Multi speed >Configuration of main and auxiliary frequency source parameter configuration.
2. The enforcement action of frequency source through the terminal, equals to modify b2.00(Main frequency source option A) as corresponding value. For example,b2.00 = 0(Main frequency source option A), it's equal to modify b2.00 = 5(PID) when a X terminal with the configuration of function 56 is effective.

Table 6- 5 Multi-reference configuration choice

Multi-reference terminal 4	Multi-reference terminal 3	Multi-reference terminal 2	Multi-reference terminal 1	Setting frequency
OFF	OFF	OFF	OFF	Multi-reference 0 (E2.01)
OFF	OFF	OFF	ON	Multi-reference 1 (E2.02)
OFF	OFF	ON	OFF	Multi-reference 2 (E2.03)
OFF	OFF	ON	ON	Multi-reference 3 (E2.04)
OFF	ON	OFF	OFF	Multi-reference 4 (E2.05)
OFF	ON	OFF	ON	Multi-reference 5 (E2.06)
OFF	ON	ON	OFF	Multi-reference 6 (E2.07)
OFF	ON	ON	ON	Multi-reference 7 (E2.08)
ON	OFF	OFF	OFF	Multi-reference 8 (E2.09)
ON	OFF	OFF	ON	Multi-reference 9 (E2.10)
ON	OFF	ON	OFF	Multi-reference 10 (E2.11)
ON	OFF	ON	ON	Multi-reference 11 (E2.12)
ON	ON	OFF	OFF	Multi-reference 12 (E2.13)
ON	ON	OFF	ON	Multi-reference 13 (E2.14)
ON	ON	ON	OFF	Multi-reference 14 (E2.15)
ON	ON	ON	ON	Multi-reference 15 (E2.16)

C0.02^o	Range: 0~58	Default: 23
X2 function	Same as C0.01 .	
C0.03^o	Range: 0~58	Default: 0
X3 function	Same as C0.01 .	
C0.04^o	Range: 0~58	Default: 0
X4 function	Same as C0.01 .	
C0.05^o	Range: 0~58	Default: 0
X5 function	Same as C0.01 .	

C0.06^o	Range: 0~58	Default: 0
X6 function	Same as C0.01 .	
C0.07^o	Range: 0~58	Default: 0
X7 function	Same as C0.01 .	
C0.08^o	Range: 0~58	Default: 0
X8 function	Same as C0.01 .	
C0.09^o	Range: 0~58	Default: 0
X9 function	Same as C0.01 .	
C0.10^o	Range: 0~58	Default: 0
X10 function	Same as C0.01 .	
C0.11	Range: 0000~1111	Default: 0000
X1~X4 terminal logic	Used to define X1~X4 terminal logically valid state, Set according to LED bits(unit,tens,hundreds,thousands): Unit corresponding to X1,Tens corresponding to X2,Hundreds corresponding to X3,Thousands corresponding to X4. The definition for each bit: 0: Closed effective. If the 24V connect to CMX, when the terminal and COM short connection indicate effectively. 1: Disconnect effective. If the 24V connect to CMX, when the terminal and COM disconnected indicate effectively.	
C0.12	Range: 0000~1111	Default: 0000
X5~X8 terminal logic	Used to define X5~X8 terminal logically valid state, Set according to LED bits(unit,tens,hundreds,thousands): Unit corresponding to X5, Tens corresponding to X6, Hundreds corresponding to X7, Thousands corresponding to X8.	
C0.13	Range: 00~11	Default: 00
X9~X10 terminal logic	Used to define X9~X10 terminal logically valid state, Set according to LED bits(unit,tens,hundreds,thousands): Unit corresponding to X9,Tens corresponding to X10, Each bit definition is same as C0.11	
C0.14	Range: 0.0~3000.0	Default: 0.0
X1 terminal delay time	Unit: Sec Delayed response time to set the X1 terminal of the input signal	

C0.15	Range: 0.0~3000.0	Default: 0.0
X2 terminal delay time	Unit: Sec Delayed response time to set the X2 terminal of the input signal	
C0.16	Range: 0.0~3000.0	Default: 0.0
X3 terminal delay time	Unit: Sec Delayed response time to set the X3 terminal of the input signal	

Through the **C0.14~C0.16** three parameters, you can set the X1~X3 terminal input signal response delay time, and further enhance the three switch input terminal of the antijamming ability.

Note:

- > The state changes of terminal include two kinds of situations."From the broken open to closed "and "From the closed to broken open".
- > Exactly the terminal delay time can be used with C0.00(terminal filter time) at the same time, X1,X2 and X3 terminal signal first passes through the filter, and then delay the time setting, and then the AC drive takes action.
- > X terminals except X1,X2,X3 haven't the delay timing function.
- > All X terminals(include virtual and logic output),shall be functional exclusion.

C0.17^o	Range: 0~3	Default: 0
Terminal command mode	Exactly the run command given by terminals have four different ways.	
	0: Two lines 1	
	● "Forward run"terminal input forward run command.	
	● "Reverse run"terminal input reverse run command.	
	1: Two lines 2	
	● "Forward run"terminal input run stop command.	
	● "Reverse run"terminal input run direction.	
	2: Three lines 1	
	● "Forward run"terminal input forward run command.	
	● "Reverse run"terminal input reverse run command.	
	● "Three lines run enable"terminal input run enable.	
	3: Three lines 2	
	● "Forward run"terminal control the AC drive run and stop.	
	● "Reverse run"terminal decides the direction.	
	● "Three lines run enable"terminal control run enable.	
	Note: Terminal command mode is invalid for JOG.	

Take X1, X2 and X3 three switch input terminal to explain the four ways defined by C0.17.
X1, X2 and X3 can be any three X terminals in actual use.

Example 1: Two lines 1.

Terminal X1 controls forward run, and X2 controls reverse run. The parameters' configuration show as following table.

Table 6- 6 Two lines 1 parameters' configuration

Parameter	Setting
C0.17 (Terminal command mode)	0 (Two lines 1)
C0.01 (X1 terminal function)	3 (Run forward)
C0.02 (X2 terminal function)	4 (Run reverse)

The wiring is shown in the following figure. Among them:

When K1 closed, the AC drive run forward:

When K2 closed, the AC drive run reverse:

When K1 and K2 have the same status, the AC drive stopped:

Both X1,X2 are level active.

K2	K1	Run command
0	0	Stop
1	1	Stop
0	1	Run forward
1	0	Run reverse




Figure 6- 9 Two lines 1

Example 2: Two lines 2.

Terminal X1 controls run and stop,terminal X2 controls run direction. The parameters' configuration show as following table.

Table 6- 7 Two lines 2 parameters' configuration

Parameter	Setting
C0.17 (Terminal command mode)	1 (Two lines 2)
C0.01 (X1 terminal function)	3 (Run forward)
C0.02 (X2 terminal function)	4 (Run reverse)

Although the configuration of C0.01 and C0.02 are the same, but they have different meaning between two line type 2 and two line type 1.

The wiring is shown in the following figure. Among them:

If K1 closed, K2 broken open the AC drive run forward, K2 closed the AC drive run reverse; If K1 broken open, the AC drive stop running. Both X1 and X2 are level effective.




Figure 6- 10 Two lines 2

Example 3: Three lines 1.

X1 controls forward run, X2 controls reverse run, X3 is run enable. The parameters' configuration is shown as the table below.

Table 6- 8 Three lines 1 parameters' configuration

Parameter	Setting value
C0.17 (Terminal command mode)	2 (Three lines 1)
C0.01 (X1 terminal function)	3 (Forward run)
C0.02 (X2 terminal function)	4 (Reverse run)
C0.03 (X3 terminal function)	5 (Three lines run control)

By the "forward run" terminal controls the AC drive run forward, "reverse run" terminal controls the AC drive run reverse, "Three lines run enable" terminal controls the AC drive stop.

The wiring is shown below in the following figure. Among them:

For normal starting and running, the SB3 button must remain closed;

If the SB3 button is closed, press the SB1 button the AC drive is run forward, press the SB2 button, the AC drive is run reversed;

At the moment of SB3 broken open, the AC drive shutdown;

X1 and X2 receives invalid command at the moment of rising edge in closing action, it is pulse trigger effective.




Figure 6- 11 Three lines 1

Example 4: Three lines 2.

X1 determines whether to run,X2 determines run direction,X3 determines run enable.
 The parameters' configuration is shown as the table below..

Table 6- 9 Three lines 2 parameters' configuration

Parameters	Setting value
C0.17 (Terminal command mode)	3 (Three lines 2)
C0.01 (X1 terminal function)	3 (Run forward)
C0.02 (X2 terminal function)	4 (Run reverse)
C0.03 (X3 terminal function)	5 (Three lines run control)

The wiring is shown in the following figure. Among them:

For normal starting and running, the SB2 button must remain closed;

When the SB2 button in the closed state, press the SB1 button, the AC drive start to run;

If K is broken open, the AC drive run forward, else run reverse;

At the moment of SB2 button broken open, the AC drive stopped;

The command received by X1 is effective at the rising edge in closing action;

X2 is the level effective.




Figure 6- 12 Three lines 2

C0.18	Range: 0~2	Default: 0
UP/DOWN	0: Frequency reference	
Regulation	When b2.00(Frequency source A selection) or b2.02(Auxiliary frequency source B selection) is set to 0(digital setting b2.01 + UP/DOWN set), terminal UP/DOWN and keypad regulation will be superposed to b2.01, the superposition of the results will be the given of main frequency source A or auxiliary frequency source B.	
chose	1: Torque reference 2: PID reference	
	When E5.04(PID set mode) is set to 0 (digital setting E5.05 + UP/DOWN), terminal UP/DOWN and keypad regulation will be superposed to E5.05, the superposition of the results will be used as PID reference.	
C0.19	Range: 00~11	Default: 11
UP/DOWN	Units: Retentive at stop	
adjustment	Tens: Retentive at power down	
memory	0: No 1: Yes	
C0.20	Range: 0.01~100.00	Default: 1.00
Terminal	Unit: %	
UP/DOWN ramp	Define terminal UP/DOWN and keypad button regulation change rate. Larger values change more quickly.	
rate	UP/DOWN regulation will be added to the reference setting set by C0.18.	

Group C1: Digital Output

C1.00	Range: 0~1	Default: 0
Y2/FO output	0: Pulse output(FO)	
choice	1: Switch signal output(Y2)	
	When set to 0, Y2 terminal act as high speed pulse output(maximum output frequency is 100KHz), its function is decided by C4.06(FO output function).	
	When set to 1, Y2 terminal act as an open collector output, its function is decided by C1.02.	
C1.01	Range: 0~45	Default: 3
Y1 function	The definition of the digital output terminals Y1 function selection, refer to the table below.	

Table 6- 10 Switch input and output function table

Setting	Function	Description
0	No output	The output terminal is invalid, and not output signal.
1	Under voltage	When the bus voltage is below the under voltage level, the terminal output "ON" signal, and LED display "Er07".
2	Ready for run	The AC drive is waiting for operation or has been running and without any fault, the terminal output "ON" signal.
3	Running	The AC drive output "ON" signal when running and output "OFF" signal when stop.
4	Zero-speed running 1 (no output at stop)	The AC drive is in the running state and the output frequency is 0HZ, the output signal is "ON".
5	Zero-speed running 2 (having output at stop)	As long as the AC drive output frequency is 0HZ, no matter whether the AC drive running or stop, the terminal stall output "ON" signal.
6	Reverse running	When the AC drive in running reverse mode, the terminal output "ON" signal.
7	Frequency reached	When the D-value of output frequency and set frequency is less than Eb.08(Frequency reaches the detection width), the terminal output "ON" signal.
8	Frequency upper limit reached	When the AC drive output frequency reaches the upper limit frequency, the terminal output ON signal.
9	Frequency lower limit Reached (no output at stop)	When the output frequency decelerate to the lower limit frequency, the terminal output ON signal. The terminal still output OFF signal when stop.
10	FDT1 detection output	Reference to Eb.13(FDT1 detection value) and Eb.14(FDT1 detection lag value) parameters description.
11	FDT2 detection output	Reference to Eb.15(FDT5 detection value) and Eb.16(FDT2 detection lag value) parameters description.
12	Torque limited	In the speed control mode, if the output torque reaches to the torque limit value, then the terminal output ON signal.
13	Fault output(VFD stop)	When the AC drive shutdown due to a fault, the terminal output ON signal.
14	Warning output (continue running)	The AC drive has warning and continue running, then the terminal output ON signal.
15	Motor overload pre-warning	When the output current exceeds the cumulative of overload inverse time curve and F0.08(Motor overload warning coefficient), the terminal output ON signal. See details about F0.08.
16	VFD overload prewarning	The terminal output ON signal when the AC drive into the overload inverse time calculation.

Setting	Function	Description
17	Module temperature reached	When the A0.60(AC drive temperature) is greater than or equal to Eb.27(Module temperature reaches the set value), the terminal output ON signal.
18	Motor Over heat pre-warning	When A0.59(The temperature of the motor) is greater than or equal to F0.14(Motor overheat warning threshold), the terminal output ON signal.
19	Zero current status	When the AC drive output current is less than Eb.17(Zero current detection level), and duration is reached to Eb.18(Zero current detection delay time) set value, the terminal output ON signal
20	Set count value reached	Please refer to the E7.05(Set count value) parameters.
21	Designated count value reached	Please refer to the E7.06(Designated count value) parameters.
22	Length reached	Please refer to the E7.07(Set length) parameters.
23	Accumulative power-on time reached	When A0.54(Accumulative power on time(day)) + A0.55(Accumulative power on time(hour)) equals to Eb.04(Accumulative power-on time(day) threshold) + Eb.05(Accumulative power-on time(hour) threshold), the terminal output ON signal. If Eb.04(Accumulative power-on time(day) threshold) is set to 0, the cumulative power on timing function is disabled, and output OFF signal.
24	Accumulative running time reached	When A0.56(Accumulative running time(day)) + A0.57(Accumulative running time(hour)) equals to Eb.06(Accumulative running time(day) threshold) + Eb.07(Accumulative running time(hour) threshold), the terminal output ON signal. If Eb.06(Accumulative running time(day) threshold) is set to 0, the cumulative power on timing function is disabled, and output OFF signal.
25	Current running time reached	When A0.53 (Running time) reaches to the set value of Eb.03 (Current running time reached) the terminal output ON signal
26	Frequency 1 reached	Reference to Eb.09 (Any frequency reaching detection value 1) and Eb.10 (Any frequency reaching detection amplitude 1) parameter's description
27	Frequency 2 reached	Reference to Eb.11 (Any frequency reaching detection value 2) and Eb.12 (Any frequency reaching detection amplitude 2) parameter's description
28	Current 1 reached	Reference to Eb.21 (Any current reaching 1) and Eb.22 (Any current reaching 1 amplitude) parameter's description
29	Current 2 reached	Reference to Eb.23 (Any current reaching 2) and Eb.24 (Any current reaching 2 amplitude) parameter's description
30	Underload	Reference to F0.09 (Under load protection) and F0.10 (Detection level of under load) parameter's description

Setting	Function	Description
31	AI1 input limit exceeded	When the input voltage of AI1 is less than Eb.25(AI1 input voltage lower limit), or greater than Eb.26(AI1 input voltage upper limit), the terminal output ON signal.
32	Timing reached	Reference to Eb.00 (Timing function) , Eb.01 (Timing duration source) and Eb.02 (Timing duration) parameters' description.
33	PLC cycle complete	When the PLC completes a run cycle, the terminal output a 250ms width ON signal.
34	Current limit exceeded	Reference to Eb.19 (Output over current threshold), Eb.20 (Output over current detection delay time) parameters' description.
35	Communication setting	The terminal output state is set by communication, please reference to chapter eight.
36	AI1>AI2	When the value of AI1 is bigger than AI2, the terminal output ON signal, otherwise output OFF signal.
37	PID feedback Limit exceeded	Please reference to the PID feedback measurement relevant parameters description E5.30~E5.35
38	PID sleep status indication	The terminal output ON signal when the PID in dormant state. Please reference to dormancy logic parameters description E5.38~E5.41
39	Frequency limited	When the AC drive set reference frequency exceeds the upper limit frequency or below the lower limit frequency, and the output reaches to the upper limit or lower limit frequency point, the terminal output ON signal.
40	Motor 1# control output	Used to control motors ' switching in multi-pump system. More detailed explanation, please reference to the description of group E6(Multi pump control).
41	Motor 2# control output	
42	Motor 3# control output	
43	Motor 4# control output	
44	External brake control	Please reference to the parameters' description of group EA.
45	Simple brake control	Please reference to the parameters' description of Eb.28~Eb.29.

C1.02	Range: 0~45	Default: 7
Y2 Function	Defines the functions of terminal Y2, same as C1.01.	
C1.03	Range: 0~45	Default: 0
Y3 Function	Defines the functions of terminal Y3, same as C1.01.	
C1.04	Range: 0~45	Default: 13
T1 Function	Defines the functions of rely T1, same as C1.01.	
C1.05	Range: 0~45	Default: 0
T2 Function	Defines the functions of rely T2, same as C1.01.	

C1.06	Range: 0~45	Default: 0
T3 Function	Defines the functions of rely T3, same as C1.01.	
C1.07	Range: 0~45	Default: 0
T4 Function	Defines the functions of rely T4, same as C1.01.	
C1.08	Range: 0~45	Default: 0
T5 Function	Defines the functions of rely T5, same as C1.01.	
C1.09	Range: 0~45	Default: 0
T6 Function	Defines the functions of rely T6, same as C1.01.	
C1.10	Range: 000~111	Default: 000
Y terminals valid state logic	0: Positive logic; When valid output ON signal, when invalid output OFF signal. 1: Negative logic; When valid output OFF signal, when invalid output ON signal.	
	Unit: Y1	Tens: Y2 Hundreds: Y3
C1.11	Range: 0000~1111	Default: 0000
T1~T4 terminals valid state logic	Define the relays T1~T4 valid state, same as C1.10.	
	Unit: T1	Tens: T2 Hundreds: T3 Thousands: T4
C1.12	Range: 00~11	Default: 00
T5~T6 terminals valid state logic	Define the relays T5~T6 valid state, same as C1.10.	
	Unit: T5	Tens: T6
Note:	0: Positive logic said digital output terminal and the common end(COM) connected state. Connect means ON state, disconnect means OFF state. 1: Positive logic said digital output terminal and the common end(COM) connected state. Connect means OFF state, disconnect means ON state.	
C1.13	Range: 0.0~3000.0	Default: 0.0
Y1 output delay time	Unit: Sec Define the output delay time of output switch terminal Y1. Represents the delay time of output function state changes to the actual output changes, this is can increase the stability of the output signal, as the following figure shown.	




Figure 6- 13 digital output terminals output delay time diagram.

C1.14	Range: 0.0~3000.0	Default: 0.0
Y2 output delay time	Unit: Sec	
	Define the output delay time of output switch terminal Y2.	
C1.15	Range: 0.0~3000.0	Default: 0.0
Y3 output delay time	Unit: Sec	
	Define the output delay time of output switch terminal Y3.	
C1.16	Range: 0.0~3000.0	Default: 0.0
T1 output delay time	Unit: Sec	
	Define the output delay time of relay T1.	
C1.17	Range: 0.0~3000.0	Default: 0.0
T2 output delay time	Unit: Sec	
	Define the output delay time of relay T2.	
C1.18	Range: 0.0~3000.0	Default: 0.0
T3 output delay time	Unit: Sec	
	Define the output delay time of relay T3.	
C1.19	Range: 0.0~3000.0	Default: 0.0
T4 output delay time	Unit: Sec	
	Define the output delay time of relay T4.	
C1.20	Range: 0.0~3000.0	Default: 0.0
T5 output delay time	Unit: Sec	
	Define the output delay time of relay T5.	
C1.21	Range: 0.0~3000.0	Default: 0.0
T6 output delay time	Unit: Sec	
	Define the output delay time of relay T6.	

C1.22	Range: 0.0~600.0	Default: 0.0
Interval of Y1 output active state	Unit: Sec	
	Define the digital output terminal Y1 output effective state holdoff time..	
C1.23	Range: 0.0~600.0	Default: 0.0
Interval of Y2 output active state	Unit: Sec	
	Define the digital output terminal Y2 output effective state holdoff time.	
C1.24	Range: 0.0~600.0	Default: 0.0
Interval of T1 output active state	Unit: Sec	
	Define the relay T1 output effective state holdoff time.	
C1.25	Range: 0.0~600.0	Default: 0.0
Interval of T2 output active state	Unit: Sec	
	Define the relay T2 output effective state holdoff time.	

In some occasions, when the digital output terminals' state is effective, hopes that the output state of the terminal is time length adjustable, and not only a level signal. The holdoff time of terminal's effective state is only available after the output delay time.

Note: When the holdoff time of terminal's effective state set to 0, equivalent cancel the terminal's effective state.




Figure 6- 14 The effective signal holdoff time of digital output terminal

Group C2: Analog Input

C2.00	Range: 0.00~10.00	Default: 0.10
AI1 filter time	Unit: Sec	
	Define the filter time of analog input signal AI1, to filter processing. Properly increasing this value can enhance the anti-interference ability of analog input, but will weaken the sensitivity.	




Figure 6- 15 figure of AI signal filter

C2.01	Range: 0.00~10.00	Default: 0.10
AI2 filter time	Unit: Sec	
	Define the filter time of AI2 signal, to filter processing.	
C2.02	Range: 0.00~10.00	Default: 0.10
AI3 filter time	Unit: Sec	
	Define the filter time of AI3 signal, to filter processing.	
C2.03	Range: 111~333	Default: 321
AI curve selection	Analog input size and the corresponding relationship between the setting value, can be defined by a specific curve. Enter to this parameter, can do the curve selection of AI1,AI2 through the LED's unit and tens bits.	
	1: AI curve 1 (Two points, reference to C2.04 ~ C2.07)	
	2: AI curve 2 (Two points, reference to C2.08 ~ C2.11)	
	3: AI curve 3 (Two points, reference to C2.12 ~ C2.15)	
	Unit's digit: AI1 Tens's digit: AI2 Hundred's digit: AI3	
C2.04	Range: -10.00~ C2.06	Default: 0.00
AI curve 1 minimum input	Unit: V	
	AI curve 1 minimum input signal.	
C2.05	Range: -100.0~100.0	Default: 0.0
Corresponding setting of AI curve 1 minimum input	Unit: %	
	The relationship between AI curve 1 minimum input signal and the percentage of set value.	
C2.06	Range: C2.04~10.00	Default: 10.00
AI curve 1 maximal input	Unit: V	
	AI curve 1 maximal input signal	

C2.07	Range: -100.0~100.0	Default: 100.0
Corresponding setting of AI curve 1 maximal input	Unit: % The relationship between AI curve 1 maximal input signal and the percentage of set value.	
C2.08	Range: -10.00~C2.10	Default: 0.00
AI curve 2 minimum input	Unit: V AI curve 2 minimum input signal	
C2.09	Range: -100.0~100.0	Default: 0.0
Corresponding setting of AI curve 2 minimum input	Unit: % The relationship between AI curve 2 minimum input signal and the percentage of set value.	
C2.10	Range: C2.08~10.00	Default: 10.00
AI curve 2 maximal input	Unit: V AI curve 2 maximal input signal	
C2.11	Range: -100.0~100.0	Default: 100.0
Corresponding setting of AI curve 2 maximal input	Unit: % The relationship between AI curve 2 maximal input signal and the percentage of set value.	

Both curve 1 and curve 2 are two point curves.

AI1, AI2 can select -10~10V voltage input or 0~20mA current input through jumper terminal CJ1 and CJ2 on the control board.

When chose the 0~20mA current input, 0mA corresponding to the 0V, and 20mA corresponding to 10V.

Example:

- The maximum frequency of b0.00 = 50.00 HZ
- The frequency selection method of b2.05 = 00
(Chose main frequency source A as output)
- The Main frequency source A selection b2.00 = 1
(Main frequency source A select AI1)
- The analog input AI curve selection C2.03 = 321(AI1 choice AI curve 1)
- The minimal input of AI curve 1 C2.04 = 0.00V
- The corresponding setting of AI curve 1 minimal input C2.05 = 0.0%
- The maximal input of AI curve 1 C2.06 = 10.00V
- The corresponding setting of AI curve 1 maximal input C2.07 = 100.0%
- When AI1 = 4V, the output frequency of this time is: $50.00 * (4.00 / 10.00) = 20.00\text{Hz}$




Figure 6- 16 AI curve 1/2 normal setting

C2.12	Range: -10.00~ C2.14	Default: 0.00
AI curve 3 minimum input	Unit: V AI curve 3 minimal input signal size	
C2.13	Range: -100.0~100.0	Default: 0.0
Corresponding setting of AI curve 3 minimum input	Unit: % The relationship between AI curve 3 minimum input signal and the percentage of set value.	
C2.14	Range: C2.12 ~10.00	Default: 10.00
AI curve 3 maximal input	Unit: V AI curve 3 maximal input signal size.	
C2.15	Range: -100.0%~100.0%	Default: 100.0
Corresponding setting of AI curve 3 maximal input	Unit: % The relationship between AI curve 3 maximal input signal and the percentage of set value.	
C2.16	Range: -100.0~100.0	Default: 0.0
Jump point of AI1 input corresponding setting	Unit: % Jump point of AI1 input corresponding setting.	

C2.17	Range: 0.0~100.0	Default: 0.5
Jump amplitude of AI1 input corresponding setting	Unit: % Jump amplitude of AI1 input corresponding setting	
C2.18	Range: -100.0~100.0	Default: 0.0
Jump point of AI2 input corresponding setting	Unit: % Jump point of AI2 input corresponding setting.	
C2.19	Range: 0.0~100.0	Default: 0.5
Jump amplitude of AI2 input corresponding setting	Unit: % Jump amplitude of AI2 input corresponding setting	
C2.20	Range: -100.0~100.0	Default: 0.0
Jump point of AI3 input corresponding setting	Unit: % Jump point of AI3 input corresponding setting.	
C2.21	Range: 0.0~100.0	Default: 0.5
Jump amplitude of AI3 input corresponding setting	Unit: % Jump amplitude of AI3 input corresponding setting	

Jump range includes lower and upper limit, defined as following:

Jump lower limit = Jump point – Jump amplitude

Jump upper limit = Jump point + Jump amplitude

When the analog input in the jump range, setting frequency will be fixed at the jump point.

Example:

Set C2.16(AI1 jump point) equal to 50.0%,C2.17(AI1 jump amplitude) equal to 10.0%. So if corresponding percentage of AI input through the curve conversion is 40.0%~60.0%, always judged to be 50.0%

C2.22	Range: 000~111	Default: 000
Setting for AI less than minimum input	Used to configure the setting when AI signal is less than the minimum input. The Unit and Tens of this parameter is corresponding to AI1 and AI2 respectively. The definition of each value are as follows: 0: Corresponding to the minimum input setting; When the AI signal is	

lower than the minimum input, the corresponding setting is decided by the minimum input corresponding setting(C2.05,C2.09).

1: 0.0%; When the AI signal is lower than the minimum input, the corresponding setting is 0%.

Unit's digit: AI1 **Ten's digit:** AI2 **Hundred's digit:** AI3

Note:

- When the analog input greater than the maximum analog input(C2.06,C2.10), the corresponding setting is decided by the maximal input corresponding setting.
- When the analog input below the minimum input, the corresponding parameter setting determined by C2.22.

Group C3: Analog Output

C3.00 Range: 0.00~10.00 Default: 0.00
AO1 filter time Unit: Sec

The parameter is used to set the software filter time of AO1. If the analog output is liable to interference, increase the value of this parameter to stabilize the detected analog output. However, increase of the AO filter time will slow the response of analog detection. Set this parameter properly based on actual conditions.




Figure 6- 17 Analog output 1 filter

C3.01 Range: 0.00~10.00 Default: 0.00
AO2 filter time Unit: Sec
 Same as **C3.00**.

C3.02 Range: 0~17 Default: 1
AO1 function The parameter defined the AO1 function,as the table below.

C3.03 Range: 0~17 Default: 2
AO2 function The parameter defined the AO2 function,as the table below.

AO1 and AO2 can select 0~10V voltage mode or 0~20mA current mode by the terminal CJ3 and CJ4 which on control board.

Table 6- 11 Relation table of analog value and pulse output

Value	Function	Range
0	Setting frequency	0~Max frequency(b0.00)
1	Running frequency	0~Max frequency(b0.00)
2	Output current	0~2 times motor rated current
3	Output voltage	0~1.2 times motor rated voltage
4	Output power	0~2 times motor rated power
5	Output torque	0~2 times motor rated torque
6	AI1	0V~10V (or 0~20mA)
7	AI2	0V~10V (or 0~20mA)
8	AI3	0V~10V (or 0~20mA)
9	X6/FI	0.00kHz~100.00kHz
10	Target torque	0~2 times motor rated torque
11	PID setting	0.0%~100.0%
12	PID feedback	0.0%~100.0%
13	PID output	0.0%~100.0%
14	Actual length	0~Sett length(E7.07)
15	Count value	0~Set count value(E7.05)
16	Communication setting	0.0%~100.0%
17	Feedback frequency	0~Max frequency(b0.00)

C3.04 Range: 11~22 Default: 21

AO curve selection AO curve specified the relationship between the output percentage and analog output signal.

Provide two AO curves. Parameters' edit according to digit

1: AO curve 1(Two points,Refer to **C3.05~C3.08**)

2: AO curve 2(Four points,Refer to **C3.09~C3.12**)

Unit's digit: AO1 **Ten's digit:** AO2

C3.05 Range: 0.00~10.00 Default: 0.00

AO curve 1 minimum output Unit: V
 Define AO curve 1 minimum output value. When chose the 0~20mA current input, 0mA corresponding to the 0V, and 20mA corresponding to 10V.

C3.06 Range: 0.0~**C3.08** Default: 0.0

Corresponding setting of AO curve 1 minimum output Unit: %
 The relationship between AO curve 1 minimum input signal and the percentage of set value.

C3.07 Range: 0.00~10.00 Default: 10.00
AO curve 1 maximum output Unit: V
 AO curve 1 maximal input signal.

C3.08 Range: **C3.06**~100.0 Default: 100.0
Corresponding setting of AO curve 1 maximum output Unit: %
 The relationship between AO curve 1 maximal input signal and the percentage of set value.




Figure 6- 18 AO curve 1

Example:

- Analog output AO1 output function selection C3.02 = 1(Running frequency)
- Max frequency b0.00 = 50.00 Hz
- AO curve selection C3.04 = 21 (AO1 curve selection 1)
- AO curve 1 minimum output C3.05 = 1.00V
- AO curve 1 minimum output corresponding setting C3.06 = 5%
- AO curve 1 maximal output C3.07 = 9.00V
- AO curve 1 maximal output corresponding setting C3.08 = 80%
- If output frequency is 20Hz,so corresponding voltage is:
 $4.73V = \{ (20Hz - 50Hz * 5\%) / (50Hz * 80\% - 50Hz * 5\%) \} * (9.00V - 1.00V) + 1.00V$

C3.09 Range: 0.00~10.00 Default: 0.00
AO curve 2 minimum output Unit: V
 Define AO curve 2 minimum output value. When chose the 0~20mA current input, 0mA corresponding to the 0V, and 20mA corresponding to 10V.

C3.10 Range: 0.0~**C3.12** Default: 0.0
Corresponding setting of AO curve 2 minimum Unit: %
 The relationship between AO curve 1 minimum input signal and the percentage of set value.

output

C3.11	Range: 0.00~10.00	Default: 10.00
AO curve 2 maximum output	Unit: V	
	Define AO curve 2 maximal output value. When chose the 0~20mA current input, 0mA corresponding to the 0V, and 20mA corresponding to 10V.	
C3.12	Range: C3.10 ~100.0	Default: 100.0
Corresponding setting of AO curve 2 maximum output	Unit: %	
	The relationship between AO curve 2 maximal input signal and the percentage of set value.	

Group C4: Pulse Input/Output

When the parameter of C0.06 set to 31, the pulse input function is enabled. The curve relationship can be set by parameters **C4.00~C4.04**. The maximum pulse input signal is 100KHz, the percent reference is maximum frequency(**b0.00**).

C4.00	Range: 0.00~10.00	Default: 0.10
FI filter time	Unit: Sec	
	The parameter is used to set the software filter time of FI. If the pulse input signal is liable to interference, increase the value of this parameter to stabilize the pulse input.	




Figure 6- 19 Pulse input filter

C4.01	Range: 0.00~ C4.03	Default: 0.00
FI minimum input	Unit: kHz	
	If the pulse input lower C4.01 then it will be limited by C4.01 .	

C4.02	Range: -100.0~100.0	Default: 0.0
Corresponding setting of FI minimum input	Unit: % The percent of corresponding to pulse minimum input frequency.	
C4.03	Range: C4.01 ~100.00	Default: 50.00
FI maximum input	Unit: kHz If the pulse input higher C4.03 then it will be limited by C4.03 .	
C4.04	Range: -100.0~100.0	Default: 100.0
Corresponding setting of FI maximum input	Unit: % The percent of corresponding to pulse maximum input frequency.	
C4.05	Range: 0.00~10.00	Default: 0.10
FO filter time	Unit: Sec If the parameter of C4.05 is non-zero then the pulse output function is enabled. Increase the value of this parameter to stabilize pulse output.	
C4.06	Range: 0~17	Default: 1
FO function	When C1.00 set to 0, the pulse output function is enabled, the functions description please see the parameter description of C3.02 .	
C4.07	Range: 0.00~100.00	Default: 0.00
FO output minimum frequency	Unit: kHz Set the minimum pulse output pulse.	
C4.08	Range: 0.0~ C4.10	Default: 0.0
Corresponding setting of FO output minimum frequency	Unit: % The percent of corresponding to pulse minimum output frequency.	
C4.09	Range: 0.00~100.00	Default: 50.00
FO output maximum frequency	Unit: kHz Set the maximum pulse output pulse.	
C4.10	Range: C4.08 ~100.0	Default: 100.0
Corresponding setting of FO output maximum frequency	Unit: % The percent of corresponding to pulse maximum output frequency.	

Group C5: Virtual Digital Input/Output

Virtual terminals can be useful in some applications such as input terminal signal is determined by output terminal.

User can connect the virtual outputs with virtual inputs without actual wires. The usage method is similar with actual terminal.

C5.00^o	Range: 0~58	Default: 0
VX1 function	Same As C0.01. Refer to Tab6-C1.	
C5.01^o	Range: 0~58	Default: 0
VX2 function	Same As C0.01. Refer to Tab6-C1.	
C5.02^o	Range: 0~58	Default: 0
VX3 function	Same As C0.01. Refer to Tab6-C1.	
C5.03^o	Range: 0~58	Default: 0
VX4 function	Same As C0.01. Refer to Tab6-C1.	
C5.04	Range: 0000~4444	Default: 1111
VX active state mode selection	This defines signal source for virtual digital input.	
	0: VYn	1: C5.05
	● VYn=1, VXn function is active.	2: AI1
	● VYn=0, VXn function is inactive.	3: AI2
	● n = 1~4	4: AI3
	Unit's digit: VX1	Hundred's digit: VX3
	Ten's digit: VX2	Thousand's digit: VX4
C5.05	Range: 0000~1111	Default: 0000
Digital setting of VX active state	When C5.04 = 1, VX1~VX4 input status are determined by C5.05.	
	0: active	1: inactive
	Unit's digit: VX1	Hundred's digit: VX3
	Ten's digit: VX2	Thousand's digit: VX4
C5.06^o	Range: 000~111	Default: 000
Active mode for AI as VX input	When C5.04 select AI as the input for VX, AI level defines as high level if AI voltage is greater than the setting of C5.07 , AI level defines as low level if AI voltage is less than the setting of C5.08 .	
	This parameter defines the active status is high level or low level.	
	0: high level	
	1: low level	
	Unit's digit: AI1	Ten's digit: AI2 Hundred's digit: AI3

C5.07^o	Range: C5.08 ~8.00	Default: 6.70	Unit: V
AI high level threshold	This defines the threshold voltage that AI treated as high level should be greater than.		
C5.08^o	Range: 1.00~ C5.07	Default: 3.20	Unit: V
AI low level threshold	This defines the threshold voltage that AI treated as low level should be less than.		
C5.09^o	Range: 0~45	Default: 0	
VY1 function	There are 4 virtual digital output terminals for the AC drive. The usage method is similar with actual terminal. 0: Corresponding to the status of X1 >0: Same as Y (digital output) terminal usage, refer to C1.01.		
C5.10^o	Range: 0~45	Default: 0	
VY2 function	0: Corresponding to the status of X2 >0: Same as Y (digital output) terminal usage, refer to C1.01.		
C5.11^o	Range: 0~45	Default: 0	
VY3 function	0: Corresponding to the status of X3 >0: Same as Y (digital output) terminal usage, refer to C1.01.		
C5.12^o	Range: 0~45	Default: 0	
VY4 function	0: Corresponding to the status of X4 >0: Same as Y (digital output) terminal usage, refer to C1.01.		
C5.13	Range: 0.0~3600.0	Default: 0.0	Unit: Sec
VY1 output delay time	This defines the delay time of VY1 output. Refer to C1.13.		
C5.14	Range: 0.0~3600.0	Default: 0.0	Unit: Sec
VY2 output delay time	This defines the delay time of VY2 output. Refer to C1.13.		
C5.15	Range: 0.0~3600.0	Default: 0.0	Unit: Sec
VY3 output delay time	This defines the delay time of VY3 output. Refer to C1.13.		
C5.16	Range: 0.0~3600.0	Default: 0.0	Unit: Sec
VY4 output delay time	This defines the delay time of VY4 output. Refer to C1.13.		
C5.17	Range: 0000~1111	Default: 0000	
VY terminal active state logic	0: Positive logic. VY output ON signal when it is active. VY output OFF signal when it is inactive. 1: Negative logic. VY output OFF signal when it is active. VY output ON signal when it is inactive.		
	Unit's digit: VY1	Ten's digit: VY2	
	Hundred's digit: VY3	Thousand's digit: VY4	

Group d0: Motor Control

d0.00^o	Range: 0 ~ 2	Default: 0
Motor control mode	0: V/f Constant Volt/Hertz proportion control. It is applicable to applications with low load requirements or applications where one AC drive operates multiple motors, such as fan and pump. 1: Open loop vector control (SVC) It is applicable to high-performance speed control or torque control applications without speed encoder. One AC drive can operate only one motor. 2: Closed loop vector control (VC) It is applicable to high-accuracy speed control or torque control applications with speed encoder. One AC drive can operate only one motor. An encoder and a PG card must be installed and setting correctly in group L2.	
	Note: <ul style="list-style-type: none">➢ If vector control is selected, motor auto-tuning must be performed before first running. Motor parameters which calculated from auto-tuning shall be store in Group d1.➢ If vector control is selected, the rated power between AC drive and motor cannot mismatched too much. Otherwise, the performance could be decreased.➢ Motor control mode (d0.00) is used for motor 1, please refer Group d5 to set for motor 2 when motor 2 is used.	
d0.01	Range: 1.0 ~ 16.0	Default: Model dependent
Carrier frequency	Unit: kHz The default value of carrier frequency is depended on AC drive hardware, as shown in the table below. It is no need to change this parameter in common usage. If the set carrier frequency is higher than default setting, you need to de-rate the AC drive. If the carrier frequency is low, output current has high harmonics, and the power loss and temperature rise of the motor increase. If the carrier frequency is high, power loss and temperature rise of the motor declines. However, the AC drive has an increase in power loss, temperature rise and interference.	

Table 6- 12 default carrier frequency and range

Volt Grade	Power Grade	carrier frequency Range
Single-phase 220V	≤ 2.2KW	1.0kHz - 12.0kHz
Three-phase 220V	3.7~5.5KW	1.0kHz - 12.0kHz
Three-phase 380V	7.5~15KW	1.0kHz - 10.0kHz
Three-phase 480V	≥ 18.5KW	1.0kHz - 8.0kHz
Three-phase 690V	≤ 200KW	1.0kHz - 3.0kHz
	≥ 220KW	1.0kHz - 2.0kHz
Three-phase 1140V	All grades	1.0kHz - 1.0kHz

Note:

When AC drive running in SVC or VC mode, carrier frequency shall be limit between 2kHz to 8kHz automatically.

d0.02	Range: 0 ~ 1	Default: 1
Carrier frequency adjustment with temperature	0: disable 1: enable It is used to set whether the carrier frequency is adjusted based on the temperature. When this parameter is set to enable, it can be reduce the overheat alarms.	
d0.03	Range: 0 ~ 10	Default: 0
Random PWM depth	0: Disable random PWM >0: setting the depth of random PWM Random PWM function is enable when this parameter is greater than 0. It can help to reduce the motor noise.	
d0.04	Range: 0.00 ~ Max frequency(b0.00)	Default: 50.00
DPWM switchover frequency upper limit	If the output frequency is higher than this Value + 3Hz, the DPWM modulation mode is adopted, or else continuous method is adopted.	
d0.05	Range: 0 ~ 1	Default: 0
PWM Modulation mode	0: asynchronous modulation 1: synchronous modulation	

d0.06 Torque boost	Range: 0 ~ 30% 0: auto torque boost >0: fixed torque boost When this parameter is set to 0, output voltage shall be adjust automatically based on the changing of the load. When this parameter is greater than 0, the value that output voltage increase shall be depend on this setting.	Default: Model dependent
d0.07^o Cut-off frequency of torque boost	Range: 0.00 ~ (b0.00) Unit: Hz This parameters determine the range that torque boost is valid.	Default: 37.00
d0.08 V/f slip compensation gain	Range: 0.0% ~ 100.0% Setting this parameter can help to compensate the motor speed change in case of load change. When this parameter is set to 100%, it means rated motor slip shall be used for compensation under rated load. The rated motor slip is calculated from rated motor frequency and rated motor speed. Therefore, correct motor parameter setting is required.	Default: 0.0%
d0.09 V/F over-excitation gain	Range: 0 ~ 250 It can increase flux current to exhaust the regenerating energy. It can shorten the actual decelerating time when motor is running in regenerating mode during deceleration. Set this parameter to 0 in case of situations that brake resistor is used or DC voltage will not rise during motor deceleration.	Default: 64
d0.10 V/F oscillation suppression gain	Range: 0 ~ 100 When motor is oscillating, adjusting this parameter can help to improve motor stability. It may influence V/F control performance when it set too	Default: Model dependent
d0.11 Overcurrent stall gain	Range: 0 ~ 100 0: Overcurrent stall function > 0: Enable overcurrent stall function When the load is heavy or accelerating / decelerating time is too short, output current exceeds the setting of d0.12, overcurrent stall function shall adjust output frequency to avoid over current trip. After output current declines, output frequency shall resume to reference frequency. Generally, the larger gain the better over current suppression result will be. At the same time, larger gain may cause oscillation.	Default: Module dependent

d0.12 Range: 30% ~ 200% Default: 150%
Overcurrent stall protective current It used to determine the point that overcurrent stall function is active. The based value is rated motor current.
 Note: "d0.12 * the motor rated current" generally can not be greater than "d0.32 *the limited current value".




Figure 6-20 Overcurrent stall function

d0.13 Range: 0 ~ 100 Default: Module dependent
Overvoltage stall gain 0: Disable overvoltage stall function
 > 0: enable overvoltage stall function
 When motor rotor speed is greater than synchrony frequency, motor running in regenerating mode. In this situation, the DC voltage of AC drive will rise and cause over voltage trip. To avoid this situation, overvoltage stall function shall adjust output frequency when DC voltage exceeds the setting of d0.14. The larger gain the better over voltage suppression result will be. The actual decelerating time may not accurate with small gain. Set this parameter to 0 when brake resistor is used or accurate decelerating time is required applications.

d0.14 Range: Model dependent Default: Model dependent
Overvoltage stall protective voltage The voltage point that over voltage control function is active. The default value of this parameter refer to table6-D2.

Table 6- 13 the default value and range of overvoltage stall protective voltage

Volt Grade	default	Range
Single-phase 220V	350 V	330V - 380V
Three-phase 220V	350 V	330V - 380V
Three-phase 380V	710 V	630V - 770V
Three-phase 480V	750 V	660V - 870V
Three-phase 690V	1100 V	1050V - 1150V
Three-phase 1140V	2100 V	1900V - 2300V

- d0.15** Range: 00 ~ 11 Default: 00
- Stall control mode** If the utility supply voltage declines, the output frequency will decrease to maintain a constant motor V/f relation. In some applications the motor is required to operate at the desired set speed, regardless of supply line voltage variations. In this situation, the under voltage control is disable, the frequency will not decrease as the utility supply voltage decreases. This could lead to under exciting the motor, resulting in a large increase in motor current during under voltage conditions.
Unit's digit: Under voltage control enable 0: Disabled 1: Enabled
Ten's digit: Overvoltage and overcurrent stall control
 0:Auto limit of acceleration and deceleration step
 1:Operating frequency automatic control
- d0.16^o** Range: 0 ~ 9 Default: 0
- V/f curve selection** Voltage / frequency curve selection.
 0: linear
 The voltage of the motor changes linearly with the frequency in the constant flux area from 0 Hz to the motor rated frequency where the rated voltage is supplied to the motor. Linear V/f curve should be used in constant torque applications.
 1: multi-point V/f
 User can program multi-point V/f based on the needs of application. See Fig.6-D2
 2: 1.2-power V/F
 3: 1.4-power V/F
 4: 1.6-power V/F
 5: 1.8-power V/F
 6: squared V/f
 Squared V/f curve can be used in applications where torque demand of the load is proportional to the square of the speed, e.g in centrifugal fans and pumps.
-

7: V/f complete separation

Output frequency and output voltage are independent. Output frequency is from frequency source, and output voltage is set by d0.21. This V/f curve can be used in applications such as induction heating, inverse power supply and torque motor control.

8: V/f half separation

The output voltage is determined by the voltage calculated from linear V/f and the setting of d0.21.

$$V_o = \frac{f_o}{f_{rated}} V_{rated} * d0.21$$

V_o : output voltage f_o : output frequency

V_{rated} : motor rated voltage f_{rated} : motor rated frequency

9: Flux Optimization

It is recommended that the motor keeps running with light or no load.

d0.17°	Range: 0.00 ~ 40.0	Default: 1.5
Multi-point V/f zero frequency voltage	Unit: % Multi-point V/f V0	
d0.18°	Range: 0.00 ~ d0.20	Default: 3.00
Multi-point V/f frequency 1	Unit: Hz Multi-point V/f f1	
d0.19°	Range: 0.0 ~ 100.0	Default: 8.0
Multi-point V/f voltage 1	Unit: % Multi-point V/f V1	
d0.20°	Range: d0.18 ~ d0.22	Default: 25.00
Multi-point V/f frequency 2	Unit: Hz Multi-point V/f f2	
d0.21°	Range: 0.0 ~ 100.0	Default: 55.0
Multi-point V/f voltage 2	Unit: % Multi-point V/f V2	
d0.22°	Range: d0.20 ~ b0.09	Default: 50.00
Multi-point V/f Frequency 3	Unit: Hz Multi-point V/f f3	

d0.23^o Range: 0.0 ~ 100.0 Default: 100.0
Multi- point V/f Unit: %
voltage 3 Multi-point V/f V3

When **V/f curve selection (d0.16)** is set to 1, output voltage characteristic is determined by the settings of d0.17 ~ d0.23. 100% of voltage indicates motor rated voltage. See Fig6-D2

Note:

- Multi-point V/f curve's setting must based on motor and load characteristic. Inappropriate setting may cause motor damaged.
- If motor 1 is active, 100% of voltage indicates motor 1 rated voltage.
- If motor 2 is active, 100% of voltage indicates motor 2 rated voltage.
- The relationship between voltages and frequencies is: $V1 < V2 < V3, F1 < F2 < F3$.




Figure 6- 21 multi-point V/f curve

d0.24 Range: 0 ~ 8 Default: 0
Voltage source for V/f separation This parameter is valid when d0.14 is set to 7.
 0: d0.25 1: AI1 2: AI2 3: AI3 (optional card) 4: X6/FI
 5: PID. The output voltage is generated based on PID closed loop.
 6: PLC. The voltage source is from simple PLC mode.
 7: Multi-Reference. The voltage source is from multi-reference.
 8: Communication

The output voltage is set by the host computer by means of communication.

Note:

- 100.0% of the setting in each mode corresponds to the rated motor except d0.25.
 - If a negative percentage is set, its absolute value is used instead.
- The voltage source for V/F separation is set in the same way as the frequency source.

- d0.25** Range: 0 ~ (b0.07) Default: 0
Voltage digital setting for V/f separation Unit: V
 Voltage digital setting for V/f separation.
- d0.26** Range: 0.0 ~ 1000.0 Default: 0.0
Voltage ramp time of V/f separation Unit: Sec
 This defines the time required for voltage to change from 0 to rated voltage or change from rated voltage to 0. See Fig6-D3




Figure 6- 22 V/F separation Voltage ramp time curve

- d0.31** Range: 0 ~ 1 Default: 1
CBC current control Unit: 1
 0: Disable 1: Enable
 Cycle by cycle tripping for current limiting operation.
- d0.32** Range: 0.50 ~ 2.20 Default: 2.00
CBC current limit Unit: 0.01
 This defines the CBC current limit point that CBC current control function is active. 1.00 of the setting corresponds to AC drive rated current.
- d0.33** Range: 10 ~ 9999 Default: 500
CBC current control delay time Unit: mSec
 This defines the time that CBC current control is allowed to run when it is active. If CBC current control running exceeds this setting time, a CBC trip will occurred.
Caution: Increasing d0.33 must decrease d0.32 as the same time. Otherwise, hardware of AC drive could be damaged with large running current.
- d0.34** Range: 50.0~100.0 Default: 65.0
Energy saving coefficient Unit: %
 Voltage coefficient of the weak magnetic when output torque below 5%. Set too low may lead to motor stall.

Group d1: Motor Parameters

d1.01^o motor stator resistance	Range: 0.001 ~ 65.535 (drive power ≤ 55kW) Default: Model dependent 0.0001 ~ 6.5535 (drive power > 55kW) Unit: Ω asynchronous motor stator resistance.
d1.02^o motor rotor resistance	Range: 0.001 ~ 65.535 (drive power ≤ 55kW) Default: Model dependent 0.0001 ~ 6.5535 (drive power > 55kW) Unit: Ω asynchronous motor rotor resistance..
d1.03^o motor leakage inductance	Range: 0.01 ~ 655.35 (drive power ≤ 55kW) Default: Model dependent 0.001 ~ 65.535 (drive power > 55kW) Unit: mH asynchronous motor leakage inductance.
d1.04^o motor mutual inductance	Range: 0.1 ~ 6553.5 (drive power ≤ 55kW) Default: Model dependent 0.01 ~ 655.35 (drive power > 55kW) Unit: mH asynchronous motor mutual inductance
d1.05^o motor no-load current	Range: 0.01 ~ motor rated current Default: Model dependent (b0.08) (drive power ≤ 55kW) 0.1 ~ b0.08 (drive power > 55kW) Unit: A asynchronous motor no-load current.
d1.06^o Motor weaken flux coefficient 1	Range: 0.000 ~ 1.000 Default: 0.400 The flux coefficient corresponds to 20% of flux current.
d1.07^o Motor weaken flux coefficient 2	Range: 0.000 ~ 1.000 Default: 0.700 The flux coefficient corresponds to 50% of flux current.
d1.08^o Motor weaken flux coefficient 3	Range: 0.000 ~ 1.000 Default: 1.000 The flux coefficient corresponds to 80% of flux current.

Note:

- Parameters of d1.01~1.05 will be used when motor type is set as asynchronous motor.
- Please edit parameters of d1.01~d1.05 if you got the parameters of asynchronous motor.
- Parameters of d1.01~1.05 can be get from running No-load dynamic auto-tune.
- After running static auto-tune, only d1.01~1.03 can be got.
- Parameters of d1.01~1.05 will be refreshed to default values after changing rated motor power or voltage.

d1.15^o Auto tune	Range: 0 ~ 2 Default: 0 AC drive can calculate and store motor parameters automatically through auto-tune function. To get better performance, running auto-tune before first usage is strong recommended. 0: invalid 1: static auto-tune It is applied to applications that the motor cannot be disconnected from the load. Set d1.15 to 1, then press the running key, static auto-tune will be running. d1.15 will resume to 0 after auto-tune automatically. 2: rotational auto-tune(No-load) The motor must be disconnected from the load when running No-load dynamic auto-tune. Set d1.15 to 2, then press the running key, static auto-tune will be running. d1.15 will resume to 0 after auto-tune automatically. Please set appropriate accelerating/decelerating time (accelerating time 4, decelerating time 4), otherwise, over current or over voltage fault may be occurred. Generally, the larger rated motor power the longer accelerating/decelerating time is needed.
--	---

Note:

- Make sure the motor is static before running auto-tune.
 - "TUNE" will be displayed in keypad when auto-tune is running. After auto-tune, "TUNE" will be disappeared.
 - Motor parameters will be updated after auto-tune.
 - There are two methods to start auto-tune:
 - A: After setting d1.15 to 1 or 2, send a run command.
 - B: Run auto-tune directly through the digital terminal which is configured as function 54 or 55.
-

Group d2: Speed Control

d2.00	Range: 1 ~ 100	Default: 30
ASR proportional gain Kp1	Speed control loop proportional gain (Kp1) in low speed situation.	
d2.01	Range: 0.01 ~ 10.00	Default: 0.50
ASR integration time Ti1	Unit: Sec	
	Speed control loop proportional integral time (Ti1) in low speed situation.	
d2.02	Range: 1 ~ 100	Default: 20
ASR proportional gain Kp2	Speed control loop proportional gain (Kp2) in high speed situation.	
d2.03	Range: 0.01 ~ 10.00	Default: 1.00
ASR integration time Ti2	Unit: Sec	
	Speed control loop proportional integral time (Ti2) in high speed situation.	
d2.04	Range: 0.00 ~ d2.05	Default: 5.00
Low speed switchover frequency	Unit: Hz	
	switchover frequency1	
d2.05	Range: d2.04 ~ b0.00	Default: 10.00
High speed switchover frequency	Unit: Hz	
	switchover frequency2	

The speed dynamic response characteristics in vector control can be adjusted by setting the proportional gain and integral time of the speed loop controller.

- The larger proportional gain (Kp) the faster response will be. However, system may be unstable when Kp is too large.
- The less integral time (Ki) the faster response will be. However, system may be unstable when Ti is too small.
- If the running frequency is less than or equal to "Switchover frequency 1" (d2.04), the speed loop controller parameters are d2.00 and d2.01.
- If the running frequency is equal to or greater than "Switchover frequency 2" (d2.05), the speed loop controller parameters are d2.02 and d2.03.
- If the running frequency is between d2.04 and d2.05, the speed loop PI parameters

➤ are obtained from the linear switchover between the two groups of controller parameters, as shown in Fig6-D4.




Figure 6- 23 Relationship between running frequencies and speed loop Kp & Ti

Note: Improper controller parameter setting may cause overvoltage or over current trip.

d2.06	Range: 0 ~ 1	Default: 0
ASR integration attribute	0: integral separation is invalid 1: integral separation is valid If this parameter set to 1, integration of speed loop controller is valid only when speed error is small. Therefore, speed overshoot or oscillation can be avoided when the Ti is small.	
d2.07	Range: 50 ~ 120	Default: 100
Vector control slip gain	Unit: % Setting this parameter properly can improve system performance.	
d2.08	Range: 0 ~ 1023	Default: 0
ASR filter time	It need not be adjusted generally and can be increased in the case of large speed fluctuation. In the case of motor oscillation, decrease the value of this parameter properly.	
d2.09	Range: 0 ~ 7	Default: 0
Upper torque limit Source of forward motoring	0: d2.10 1: AI1 2: AI2 3: AI3 4: X6/FI 5: Communication 6: MIN (AI1,AI2) 7: MAX (AI1,AI2) This parameter allows user to select the desired source as upper torque to limit the motor output torque when the motor is running forward in motoring mode. More information, see d2.10.	

d2.10 Preset upper torque limit of forward motoring	Range: 0.0 ~ 300.0 Unit: % When d2.09 is set to 0, this parameter is used as upper torque limit when the motor is running forward in motoring mode. If the torque upper limit is analog, pulse or communication setting, 100% of the setting corresponds to the value of d2.10, and 100% of the value of d2.10 corresponds to the motor rated torque.	Default: 150.0
d2.11 Upper torque limit Source of reverse motoring	Range: 0 ~ 7 0: d2.10 1: AI1 2: AI2 3: AI3 4: X6/FI 5: Communication 6: MIN (AI1,AI2) 7: MAX (AI1,AI2) This parameter allows user to select the desired source as upper torque to limit the motor output torque when the motor is running reverse in motoring mode. More information, see d2.12.	Default: 0
d2.12 Preset upper torque limit of reverse motoring	Range: 0.0 ~ 300.0% Unit: % When d2.11 is set to 0, this parameter is used as upper torque limit when the motor is running reverse in motoring mode. If the torque upper limit is analog, pulse or communication setting, 100% of the setting corresponds to the value of d2.12, and 100% of the value of d2.12 corresponds to the motor rated torque.	Default: 150.0%
d2.13 Upper torque limit source of forward generating	Range: 0 ~ 7 0: d2.10 1: AI1 2: AI2 3: AI3 4: X6/FI 5: Communication 6: MIN (AI1,AI2) 7: MAX (AI1,AI2) This parameter allows user to select the desired source as upper torque to limit the motor output torque when the motor is running forward in generating mode. More information, see d2.14.	Default: 0

d2.14 Preset upper torque limit of forward generating	Range: 0.0 ~ 300.0 Unit: % When d2.13 is set to 0, this parameter is used as upper torque limit when the motor is running forward in generating mode. If the torque upper limit is analog, pulse or communication setting, 100% of the setting corresponds to the value of d2.14, and 100% of the value of d2.14 corresponds to the motor rated torque.	Default: 150.0
d2.15 Upper torque limit source of reverse generating	Range: 0 ~ 7 0: d2.10 1: AI1 2: AI2 3: AI3 4: X6/FI 5: Communication 6: MIN (AI1,AI2) 7: MAX (AI1,AI2) This parameter allows user to select the desired source as upper torque to limit the motor output torque when the motor is reverse forward in generating mode. More information, see d2.16.	Default: 0
d2.16 Preset upper torque limit of reverse generating	Range: 0.0 ~ 300.0 Unit: % When d2.15 is set to 0, this parameter is used as upper torque limit when the motor is running reverse in generating mode. If the torque upper limit is analog, pulse or communication setting, 100% of the setting corresponds to the value of d2.16, and 100% of the value of d2.16 corresponds to the motor rated torque.	Default: 150.0

There are four motor running modes based on directions of speed and torque. See 6-D5.




Figure 6- 24 Four motor running modes

d2.17	Range: 0 ~ 60000	Default: 2000
Proportional gain of flux current loop	Proportional gain of flux current loop.	
d2.18	Range: 0 ~ 60000	Default: 800
Integration time of flux current loop	Integration time of flux current loop.	
d2.19	Range: 0 ~ 60000	Default: 2000
Proportional gain of torque current loop	Proportional gain of torque current loop.	
d2.20	Range: 0 ~ 60000	Default: 400
Integration time of torque current loop	Integration time of torque current loop.	

Note: The system dynamic response characteristics in vector control can be adjusted by setting the proportional gain and integral time of the current loop controller. Improper controller parameter setting may cause overvoltage or over current trip.

d2.21[®]	Range: 000 ~ 111	Default: 110
Vector control optimization mode	0: Disable 1: Enable	
	Unit's digit: Loop control optimization	
	Ten's digit: Angle estimation optimization	
	Hundred's digit: Low frequency torque optimization	



Group d3: Torque Control

d3.00^o	Range: 0 ~ 1	Default: 0
Speed/Torque control selection	It is used to select motor control mode in vector control. 0: Speed Control 1: Torque Control If one of the input digital terminals is set to function 35 (torque control forbidden), speed control will be active when the terminal is active regardless the setting of d3.00. If one of the input digital terminals is set to function 34 (speed/torque control switch), the actual control mode will be different with the setting of d3.00 when the terminal is active.	
d3.01^o	Range: 0 ~ 7	Default: 0
Torque reference source	0: d3.02+UP/DOWN 1: AI1 2: AI2 3: AI3 4: X6/FI 5: Communication 6: MIN (AI1,AI2) 7: MAX (AI1,AI2) When this parameter is set to 0, the torque reference can be setting through terminal up/down adjustment function or up/down key when C0.18 is set to 1. When this parameter is set to none 0, 100% of the setting corresponds to the value of d3.02.	
d3.02	Range: -300.0 ~ 300.0	Default: 50.0
Digital setting of torque reference	Unit: % Digital setting of torque reference. 100% of the setting corresponds to the rated motor torque.	
d3.03^o	N/G	

d3.04 Range: -300.0 ~ 300.0 Default: 0.0
Digital setting of Coefficient rigidity Unit: %
 Digital setting of coefficient rigidity. Adjustment of torque's flexibility and rigidity. Smaller are more flexible and bigger are more rigid.




Figure 6- 25 torque reference for torque control

d3.05^o N/G

d3.06^o Range: 0 ~ 7 Default: 0
Maximum frequency source
 maximum frequency source:
 0: d3.07
 1: AI1
 2: AI2
 3: AI3
 4: X6/FI
 5: Communication
 6: MIN (AI1,AI2)
 7: MAX (AI1,AI2)
 When this parameter is set to 0, maximum frequency is set by d3.07.
 When this parameter is set to none 0, 100% of the setting corresponds to the value of d3.07.

d3.07	Range: -b0.00 ~b0.00	Default: 50.00
Digital setting of Maximum frequency	Unit: Hz Digital setting of maximum frequency.	
d3.08^o	Range: 0 ~ 7	Default: 0
Minimum frequency source	0: d3.09 1: AI1 2: AI2 3: AI3 4: X6/FI 5: Communication 6: MIN (AI1,AI2) 7: MAX (AI1,AI2) When this parameter is set to 0, minimum frequency is set by d3.09. When this parameter is set to none 0, 100% of the setting corresponds to the value of d3.09.	
d3.09	Range: - (b0.00) ~ (b0.00)	Default: -50.00
Digital setting of minimum frequency	Unit: Hz Digital setting of minimum frequency.	
d3.10	N/G	
d3.11	N/G	

When d3.05 is set to 0 (Minimum frequency to maximum frequency), speed limit mode is shown by Fig6-D7:




Figure 6- 26 d3.05=0 Minimum frequency to maximum frequency

When d3.05 is set to 1 (Minimum frequency to running frequency), speed limit mode is shown by Fig6-D8:




Figure 6- 27 d3.05=1 Minimum frequency to running frequency

When d3.05 is set to 2 (Negative running frequency to positive running frequency), speed limit mode is shown by Fig6-D9:




Figure 6- 28 d3.05=2 Negative running frequency to positive running frequency

When d3.05 is set to 3 (Running frequency to maximum frequency), speed limit mode is shown by Fig6-D10:




Figure 6- 29 d3.05=3 Running frequency to maximum frequency



When d3.05 is set to 4 (Running frequency + windows), speed limit mode is shown by Fig6-D11:




Figure 6- 30 d3.05=4 Running frequency + windows

When d3.05 is set to 5 (0Hz to running frequency), speed limit mode is shown by Fig6-D12:




Figure 6- 31 d3.05=5 0Hz to running frequency

d3.12	Range: 0.0 ~ 100.0	Default: 0.0
Static torque compensation	Unit: %	
	To overcome the static friction, static torque compensation is helpful. 100% of the setting corresponds to rated motor torque.	
	d3.12 Only works under torque control, Default is rated motor torque.	
	d3.12 Providing extra torque to overcome system's static friction.	
	d3.12 is invalid when motor starts operating.	
d3.13	Range: 0.0 ~ 100.0	Default: 0.0
Dynamic torque compensation	Unit: %	
	To overcome the dynamic friction, dynamic torque compensation is helpful. 100% of the setting corresponds to rated motor torque.	
d3.14	Range: 0.0 ~ 100.0	Default: 0.0
Inertia torque compensation	Unit: %	
	To overcome the system inertia, inertia torque compensation is helpful. 100% of the setting corresponds to rated motor torque.	

d3.15	Range: 0.00 ~ 650.00	Default: 2.00
Torque acceleration time	Unit: Sec This defines the time required for actual torque reference to change from 0 to rated motor torque.	
d3.16	Range: 0.00 ~ 650.00	Default: 2.00
Torque deceleration time	Unit: Sec This defines the time required for actual torque reference to change from 0 to rated motor torque.	
d3.17	N/G	
d3.18	N/G	

Group d5: Motor 2 Parameters

The AC drive can store two groups of motor parameters. User can switch the desired motor to run with the related motor parameters. The defines and usage is the same as motor 1. More detail information, refer to b0, d1,d2.

d5.00^o	Range: 0 ~ 1	Default: 0
Motor 1/2 selection	0: motor 1 Selecting motor 1 as the running motor. Motor 1 related parameters and control parameters can be set in group b0, d1,d2. 1: motor 2 Selecting motor 2 as the running motor. Motor 2 related parameters and control parameters can be set in group d5, d6. If one the input terminal has configured with function 30, motor 1/2 selection is determined by the terminal status regardless setting of d5.00.	
d5.01^o	Range: 0 ~ 2	Default: 0
Motor 2 control mode	0: V/f 1: Open loop vector control 2: Close loop vector control	
d5.03	Range: 0.1 ~ 999.9	Default: Model dependent
Motor 2 rated Power	Unit: kW motor 2 rated power	

d5.04^o	Range: 1 ~ 2000	Default: Model dependent
Motor 2 rated Voltage	Unit: V motor 2 rated voltage	
d5.05^o	Range: 0.01 ~ 655.35 (drive power ≤ 55kW) 0.1 ~ 6553.5 (drive power > 55kW)	Default: Model dependent
Motor 2 rated Current	Unit: A motor 2 rated current	
d5.06^o	Range: 10.00 ~ b0.00	Default: Model dependent
Motor 2 rated Frequency	Unit: Hz motor 2 rated frequency	
d5.07^o	Range: 1 ~ 65535	Default: Model dependent
Motor 2 rated Speed	Unit: RPM motor 2 rated speed	
d5.08^o	Range: 0.001 ~ 65.535 (drive power ≤ 55kW) 0.0001 ~ 6.5535 (drive power > 55kW)	Default: Model dependent
Motor 2 rotor resistance	Unit: Ω asynchronous motor 2 rotor resistance.	
d5.09^o	Range: 0.001 ~ 65.535 (drive power ≤ 55kW) 0.0001 ~ 6.5535 (drive power > 55kW)	Default: Model dependent
Motor 2 stator resistance	Unit: Ω asynchronous motor 2 stator resistance.	
d5.10^o	Range: 0.01 ~ 655.35 (drive power ≤ 55kW) 0.001 ~ 65.535 (drive power > 55kW)	Default: Model dependent
Motor 2 leakage inductance	Unit: mH asynchronous motor 2 leakage inductance.	
d5.11^o	Range: 0.1 ~ 6553.5 (drive power ≤ 55kW) 0.01 ~ 655.35 (drive power > 55kW)	Default: Model dependent
Motor 2 mutual inductance	Unit: mH asynchronous motor 2 mutual inductance	

d5.12^o	Range: 0.01 ~ motor rated current (b0.08) (drive power <=55kW)	Default: Model dependent
Motor 2 no-load current	Unit: A asynchronous motor no-load 2 current.	
d5.13^o	Range: 0.000 ~ 1.000	Default: 0.400
Motor 2 weaken flux coefficient 1	The flux coefficient corresponds to 20% of flux current.	
d5.14^o	Range: 0.000 ~ 1.000	Default: 0.700
Motor 2 weaken flux coefficient 2	The flux coefficient corresponds to 50% of flux current.	
d5.15^o	Range: 0.000 ~ 1.000	Default: 1.000
Motor 2 weaken flux coefficient 3	The flux coefficient corresponds to 80% of flux current.	
d5.22^o	Range: 0 ~ 2	Default: 0
motor 2 auto tune	0: No action 1: Static auto tune 2: rotational auto tune	

Group d6: Motor 2 Speed Control

The AC drive can store two groups of speed control parameters. Group d2 is for motor 1 and group d6 is for motor 2. The defines and usage is the same as motor 1. More detail information, refer to d2.

d6.00	Range: 1 ~ 100	Default: 30
Motor 2 ASR proportional gain Kp1	Speed control loop proportional gain (Kp1) in low speed situation.	
d6.01	Range: 0.01 ~ 10.00	Default: 0.50
Motor 2 ASR integration time Ti1	Unit: Sec Speed control loop proportional integral time (Ti1) in low speed situation.	
d6.02	Range: 1 ~ 100	Default: 20
Motor 2 ASR proportional gain Kp2	Speed control loop proportional gain (Kp2) in high speed situation.	
d6.03	Range: 0.01 ~ 10.00	Default: 1.00
Motor 2 ASR integration time Ti2	Unit: Sec Speed control loop proportional integral time (Ti2) in high speed situation.	

d6.04 Motor 2 Low speed switchover frequency	Range: 0.00 ~ switchover frequency2 (d2.05) Unit: Hz switchover frequency1	Default: 5.00
d6.05 Motor 2 High speed switchover frequency	Range: Switchover Frequency 1 (d2.04) ~ Max Frequency (b0.00) Unit: Hz switchover frequency2	Default: 10.00
d6.06 Motor 2 ASR integration attribute	Range: 0 ~ 1 0: integral separation is invalid 1: integral separation is valid If this parameter set to 1, integration of speed loop controller is valid only when speed error is small. Therefore, speed overshoot or oscillation can be avoided when the Ti is small.	Default: 0
d6.07 Motor 2 Vector control slip gain	Range: 50 ~ 120 Unit: % Setting this parameter properly can improve system performance.	Default: 100
d6.08 Motor 2 ASR filter time	Range: 0 ~ 1023 It need not be adjusted generally and can be increased in the case of large speed fluctuation. In the case of motor oscillation, decrease the value of this parameter properly.	Default: 0
d6.09 Motor 2 Upper torque limit Source of forward motoring	Range: 0 ~ 7 0: d2.10 2: AI2 4: X6/FI 6: MIN (AI1,AI2) 1: AI1 3: AI3 5: Communication 7: MAX (AI1,AI2) This parameter allows user to select the desired source as upper torque to limit the motor output torque when the motor is running forward in motoring mode. More information, see d6.10.	Default: 0
d6.10 Motor 2 Preset upper torque limit of forward motoring	Range: 0.0 ~ 200.0 Unit: % When d6.09 is set to 0, this parameter is used as upper torque limit when the motor is running forward in motoring mode. If the torque upper limit is analog, pulse or communication setting, 100% of the setting corresponds to the value of d6.10, and 100% of the value of d6.10 corresponds to the motor rated torque.	Default: 150.0

d6.11	Range: 0 ~ 7	Default: 0
Motor 2 Upper torque limit	0: d2.10 2: AI2 4: X6/FI 6: MIN (AI1,AI2) 1: AI1 3: AI3 5: Communication 7: MAX (AI1,AI2)	
Source of reverse motoring	This parameter allows user to select the desired source as upper torque to limit the motor output torque when the motor is running reverse in motoring mode. More information, see d6.12.	
d6.12	Range: 0.0 ~ 200.0%	Default: 150.0%
Motor 2 Preset upper torque limit of reverse motoring	Unit: %	
	When d6.11 is set to 0, this parameter is used as upper torque limit when the motor is running reverse in motoring mode. If the torque upper limit is analog, pulse or communication setting, 100% of the setting corresponds to the value of d6.12, and 100% of the value of d6.12 corresponds to the motor rated torque.	
d6.13	Range: 0 ~ 7	Default: 0
Motor 2 Upper torque limit source of forward generating	0: d2.10 2: AI2 4: X6/FI 6: MIN (AI1,AI2) 1: AI1 3: AI3 5: Communication 7: MAX (AI1,AI2)	
	This parameter allows user to select the desired source as upper torque to limit the motor output torque when the motor is running forward in generating mode. More information, see d6.14.	
d6.14	Range: 0.0 ~ 200.0	Default: 150.0
Motor 2 Preset upper torque limit of forward generating	Unit: %	
	When d6.13 is set to 0, this parameter is used as upper torque limit when the motor is running forward in generating mode. If the torque upper limit is analog, pulse or communication setting, 100% of the setting corresponds to the value of d6.14, and 100% of the value of d6.14 corresponds to the motor rated torque.	
d6.15	Range: 0 ~ 7	Default: 0
Motor 2 Upper torque limit source of reverse generating	0: d2.10 2: AI2 4: X6/FI 6: MIN (AI1,AI2) 1: AI1 3: AI3 5: Communication 7: MAX (AI1,AI2)	
	This parameter allows user to select the desired source as upper torque to limit the motor output torque when the motor is reverse forward in generating mode. More information, see d6.16.	
d6.16	Range: 0.0 ~ 200.0	Default: 150.0
Motor 2 Preset upper torque limit of reverse generating	Unit: %	
	When d6.15 is set to 0, this parameter is used as upper torque limit when the motor is running reverse in generating mode. If the torque upper limit is analog, pulse or communication setting, 100% of the setting corresponds to the value of d6.16, and 100% of the value of d6.16 corresponds to the motor rated torque.	

d6.17	Range: 0 ~ 60000	Default: 2000
Motor 2		
Proportional gain of flux current loop	Proportional gain of flux current loop.	
d6.18	Range: 0 ~ 60000	Default: 800
Motor 2 Integration time of flux current loop	Integration time of flux current loop.	
d6.19	Range: 0 ~ 60000	Default: 2000
Motor 2		
Proportional gain of torque current loop	Proportional gain of torque current loop.	
d6.20	Range: 0 ~ 60000	Default: 400
Motor 2 Integration time of torque current loop	Integration time of torque current loop.	

Group E0: JOG

JOG function is useful and convenient for equipment debugging, it can make the AC drive working at any output frequency temporarily.

E0.00	Range: 0.00~ b0.00	Default: 5.00
JOG frequency	Unit: Hz	
E0.01	Range: 0.1~6000.0	Default: 10.0
JOG acceleration time	Unit: Sec The time JOG running from 0Hz to b0.00 (Max frequency).	
E0.02	Range: 0.1~6000.0	Default: 10.0
JOG deceleration time	Unit: Sec The time JOG running from b0.00 (Max frequency) to 0Hz.	

These parameters are used to define the set frequency and acceleration/deceleration time of the AC drive when JOG running.

The JOG command can be sent from Keypad, Terminal and Communication.

The startup mode is "Ramp start from startup frequency" (**b1.05** = 0) and the stop mode is depending on **E0.03** during JOG running.

E0.03	Range: 0~1	Default: 0
JOG stop mode	0: Ramp stop 1: Coasting stop	
E0.04	Range: 0~1	Default: 0
JOG preferred	When set E0.04 to 1, the AC drive will response the JOG command of current control source immediately even if in running state. And the JOG command form other control source will be ignored.	
	0: Disabled 1: Enabled	

Group E1: Skip Frequency

If the set frequency is within the frequency jump range, the actual running frequency is the skip frequency close to the set frequency. Setting the skip frequency helps to avoid the mechanical resonance point of the load.

The AC drive supports two skip frequencies. If both are set to 0, the skip frequency function is disabled.

E1.00	Range: E1.01~b0.00	Default: 0.00
Skip frequency 1 high limit	Unit: Hz	
	As shown in the following figure.	
E1.01	Range: 0.00~E1.00	Default: 0.00
Skip frequency 1 low limit	Unit: Hz	
	As shown in the following figure.	
E1.02	Range: E1.03~b0.00	Default: 0.00
Skip frequency 2 high limit	Unit: Hz	
	As shown in the following figure.	
E1.03	Range: 0.00~E1.02	Default: 0.00
Skip frequency 2 low limit	Unit: Hz	
	As shown in the following figure.	

Note: The AC drive can output in the skip frequency range during acceleration and deceleration process.

The principle of the skip frequencies is shown in the following figure.




Figure 6- 32 Principle of the skip frequency

Group E2: Multi-Reference

The AC drive multi-reference has many functions. Besides multi-speed, it can be used as the setting source of the V/F separated voltage source and setting source of process PID.

The multi-reference is frequency value and ranges from **-b0.00** to **b0.00**.

As frequency source, it does not require conversion. As others, it needs to be changed to a percentage relative to **b0.00** (Max frequency).

Multi-reference can be switched over based on different states of X terminals. For details, see the descriptions of **Group C0**.

E2.00	Range: 0~6	Default: 0
Reference 0 source	0: Set by E2.01 1: Set by b2.01 , modified via UP/DOWN 2: AI1 3: AI2 4: AI3 5: X6/FI 6: PID	
	It determines the setting channel of reference 0. You can perform convenient switchover between the setting channels. When multi-reference or simple PLC is used as frequency source, the switchover between two frequency sources can be realized easily.	
E2.01	Range: -b0.00~b0.00	Default: 0.00
Reference 0	Unit: Hz	
	Multi-reference 0 set frequency.	

The descriptions of **Reference 1** to **Reference 15** are the same with **Reference 0 (E2.01)**.

E2.02	Reference 1
E2.03	Reference 2
E2.04	Reference 3
E2.05	Reference 4
E2.06	Reference 5
E2.07	Reference 6
E2.08	Reference 7
E2.09	Reference 8
E2.10	Reference 9
E2.11	Reference 10
E2.12	Reference 11
E2.13	Reference 12
E2.14	Reference 13
E2.15	Reference 14
E2.16	Reference 15

Group E3: Simple PLC

Simple PLC can complete simple combination of multi-reference.

- E3.00** Range: 0~2 Default: 0
- Simple PLC running mode** Simple PLC can be either the frequency source or V/F separated voltage source. When simple PLC is used as the frequency source, whether parameter values of **E2.01** to **E2.16** are positive or negative determines the running direction. If the parameter values are negative, it indicates that the AC drive runs in reverse direction.
- 0: Stop after the AC drive runs one cycle
 The AC drive stops after running one cycle, and will not start up until receiving another command.
- 1: Keep final values after the AC drive runs one cycle
 The AC drive keeps the final running frequency and direction after running one cycle.
- 2: Repeat after the AC drive runs one cycle
 The AC drive automatically starts another cycle after running one cycle, and will not stop until receiving the stop command.




Figure 6- 33 Simple PLC when used as frequency source

- E3.01** Range: 00~11 Default: 00
- Simple PLC retentive selection** **Unit's digit (Retentive upon power failure)**
Ten's digit (Retentive upon stop)
- 0: No 1: Yes

PLC retentive upon power failure indicates that the AC drive memorizes the PLC running moment and running frequency before power failure and will continue running from the memorized moment after it is powered on again. If the unit's digit is set to 0, the AC drive restarts the PLC process after it is powered on again.

PLC retentive upon stop indicates that the AC drive records the PLC running moment and running frequency upon stop and will continue running from the recorded moment after it starts up again. If the ten's digit is set to 0, the AC drive restarts the PLC process after it starts up again.

E3.02	Range: 0~1	Default: 0
Time unit of simple PLC running	Setting the time unit for simple PLC running.	
	0: s (second)	1: h (hour)
E3.03	Range: 0.0~6553.5	Default: 0.0
Running time of simple PLC reference 0	Unit: Sec(h)	
	Setting the time for simple PLC reference 0 running.	
E3.04	Range: 0~3	Default: 0
Acceleration/ deceleration time of simple PLC reference 0	0: Acceleration/deceleration time 1(As b0.04,b0.05)	
	1: Acceleration/deceleration time 2(As E4.00,E4.01)	
	2: Acceleration/deceleration time 3(As E4.02,E4.03)	
	3: Acceleration/deceleration time 4(As E4.04,E4.05)	

The parameter descriptions of simple PLC **Reference 1 to 15** are the same with **Reference 0(E3.03 and E3.04)**.

E3.05	Running time of simple PLC reference 1	E3.21	Running time of simple PLC reference 9
E3.06	Acceleration/deceleration time of simple PLC reference 1	E3.22	Acceleration/deceleration time of simple PLC reference 9
E3.07	Running time of simple PLC reference 2	E3.23	Running time of simple PLC reference 10
E3.08	Acceleration/deceleration time of simple PLC reference 2	E3.24	Acceleration/deceleration time of simple PLC reference 10
E3.09	Running time of simple PLC reference 3	E3.25	Running time of simple PLC reference 11
E3.10	Acceleration/deceleration time of simple PLC reference 3	E3.26	Acceleration/deceleration time of simple PLC reference 11
E3.11	Running time of simple PLC reference 4	E3.27	Running time of simple PLC reference 12
E3.12	Acceleration/deceleration time of simple PLC reference 4	E3.28	Acceleration/deceleration time of simple PLC reference 12
E3.13	Running time of simple PLC reference 5	E3.29	Running time of simple PLC reference 13
E3.14	Acceleration/deceleration time of simple PLC reference 5	E3.30	Acceleration/deceleration time of simple PLC reference 13
E3.15	Running time of simple PLC reference 6	E3.31	Running time of simple PLC reference 14
E3.16	Acceleration/deceleration time of simple PLC reference 6	E3.32	Acceleration/deceleration time of simple PLC reference 14
E3.17	Running time of simple PLC reference 7	E3.33	Running time of simple PLC reference 15
E3.18	Acceleration/deceleration time of simple PLC reference 7	E3.34	Acceleration/deceleration time of simple PLC reference 15
E3.19	Running time of simple PLC reference 8		
E3.20	Acceleration/deceleration time of simple PLC reference 8		

Group E4: Acc & Dec time

The AC drive provides a total of four groups of acceleration/deceleration time, that is the following three groups and the group defined by **b0.04** and **b0.05**. Definitions of four groups are completely the same, see the descriptions of **b0.04** and **b0.05**. You can switch over between the four groups of acceleration/deceleration time through different state combinations of X terminals. For more details, see the function No.20 and No.21 descriptions of **C0.01**.

The descriptions of **E4.00~E4.05** are the same with **b0.04~b0.05**, ranges from 0.1 to 6000.0 seconds, defaults to model dependent.

E4.00	Acceleration time 2	E4.02	Acceleration time 3	E4.04	Acceleration time 4
E4.01	Deceleration time 2	E4.03	Deceleration time 3	E4.05	Deceleration time 4

E4.06 Range: 0.00~**b0.00** Default: 0.00
Frequency switchover point between acceleration time 1&2
 Unit: Hz
 See the following figure.

E4.07 Range: 0.00~**b0.00** Default: 0.00
Frequency switchover point between deceleration time 1&2
 Unit: Hz
 See the following figure.

The AC drive can switchover automatically between Acceleration/Deceleration time 1 and 2 with no X terminal signal when setting proper **E4.06** or **E4.07**. In acceleration process, the time 2 will be used when output frequency is lower than **E4.06**, otherwise time 1 will be used. In deceleration process, the time 1 will be used when output frequency is higher than **E4.07**, otherwise time 2 will be used.

If any X terminal is set as 20~21 function (Acceleration/Deceleration time select), the actual acceleration/deceleration time will be determined by X terminal states.




Figure 6- 34 Acceleration/Deceleration time 1/2 switching

E4.08^o Range: 0~2 Default: 1
Unit of Acceleration/Deceleration time
 0: 1s (second) 1: 0.1s 2: 0.01s
 Available for acceleration/deceleration time 1 to 4.

E4.09^o Range: 0~2 Default: 1
Reference frequency of Acceleration/Deceleration time
 0: Max frequency(b0.00) 1: Current setting frequency 2: 100Hz
 Acc/Dec time is defined as the running time needed between 0Hz to E4.09

Group E5: PID

<p>E5.00^o PID engineering unit</p>	<p>Range: 0~1 Default: 0</p> <p>This parameter determines the unit of PID regulator. 0: Percentage(%) 1: Pressure(MPa)</p> <p>The following parameters' unit is determined by E5.00.</p> <ul style="list-style-type: none"> ● E5.05(PID digital setting) ● E5.03(Minimum setting of PID engineering unit) ● E5.02(Maximum setting of PID engineering unit) ● E5.16(PID parameter switchover deviation 1) ● E5.17(PID parameter switchover deviation 2) ● E5.26(PID deviation limit) ● E5.33(Upper limit of PID feedback detection) ● E5.34(Lower limit of PID feedback detection) ● E5.36(Wake up level) ● E5.39(Sleep level) ● A0.20(PID reference) ● A0.21(PID feedback) <p>Note:The above 12 parameters' unit will change immediately according to E5.00.</p>
<p>E5.01 PID engineering unit resolution</p>	<p>Range: 0~3 Default: 1</p> <p>0: No decimal 1: One decimal 2: Two decimal 3: Three decimal</p> <p>This parameter determined the resolution of the following parameter:</p> <ul style="list-style-type: none"> ● E5.05(PID digital setting) ● E5.03(Minimum setting of PID engineering unit) ● E5.02(Maximum setting of PID engineering unit) ● E5.16(PID parameter Switchover deviation 1) ● E5.17(PID parameter switchover deviation 2) ● E5.26(PID deviation limit) ● E5.33(Upper limit of PID feedback detection) ● E5.34(Lower limit of PID feedback detection) ● E5.36(Wake up level) ● E5.39(Sleep level) ● A0.20(PID reference) ● A0.21(PID feedback) <p>Note:The resolution of above 12 parameters will change immediately according to E5.01.</p>

The PID engineering unit is convenient for customer using. Different engineering unit will be converted to percentage in the AC drive PID regulator. The percentage value of final PID setting and feedback will be again converted to the real value with engineering unit, and then shown to customers.

E5.03 equals to 0% in PID regulator, and **E5.02** equals to 100%. That two points (**E5.03**, 0.0%) and (**E5.02**, 100.0%) determine a conversion line between the value with engineering unit and percentage, as shown in the following figure.

Example 1:

- > E5.00(Engineering unit)= 1(MPa)
- > E5.01(PID engineering unit resolution)= 3(Three decimals)
- > E5.03(Minimum setting of PID engineering unit)= 0.000(MPa)
- > E5.02(Maximum setting of PID engineering unit)= 8.000(MPa)
- > E5.05(PID digital setting)= 3.040(Mpa)
- > E5.04(PID setting source)= 0(E5.05+UP/DOWN)

The final PID setting with percentage as unit is:

$$(E5.05 - E5.03) / (E5.02 - E5.03) * 100\% = 38.0\%$$

A0.20(PID reference) is the final PID setting with engineering unit, its value is:

$$3.040 \text{ MPa} = 38.0\% * (E5.02 - E5.03) + E5.03$$




Figure 6- 35 The relationship between the value with engineering unit and the percentage value in AC drive PID regulator

Example 2:

- > E5.00(Engineering unit)= 1(MPa)
- > E5.01(PID engineering unit resolution)= 3(Three decimals)
- > E5.03(Minimum setting of PID engineering unit)= 0.000(MPa)
- > E5.02(Maximum setting of PID engineering unit)= 8.000(MPa)
- > E5.07(PID feedback source)= 0(AI1)
- > The max measure range of external equipment is 8 MPa, which equals to 16 mA of AI signal.
- > C2.03(AI curve selection)= 321(set AI1 to AI curve 1)
- > C2.06(AI curve 1 maximum input)= 8.00V
- > C2.07(Corresponding setting of AI curve 1 maximum input)= 100.0%
- > Suppose the AI current is 10mA

Then PID feedback with percentage unit is: $(10\text{mA} - 0\text{mA}) / (16\text{mA} - 0\text{mA}) * 100\% = 62.5\%$

A0.21(PID feedback) is the final PID feedback with engineering unit, its value is:

$$5.000 \text{ (MPa)} = 62.5\% * (E5.02 - E5.03) + E5.03$$

E5.02 Maximum setting of PID engineering unit	Range: E5.03 ~6553.5 Unit: % The unit and resolution will be changed according to E5.00 and E5.01 . E5.02 corresponds to 0% in AC drive, and affects the following parameters: ● A0.20 (PID reference) ● A0.21 (PID feedback)	Default: 100.0
E5.03 Minimum setting of PID engineering unit	Range: 0.0~ E5.02 Unit: % The unit and resolution will be changed according to E5.00 and E5.01 . E5.03 corresponds to 0% in AC drive, and affects the following parameters: ● A0.20 (PID reference) ● A0.21 (PID feedback)	Default: 0.0
E5.04 PID setting source	Range: 0~6 0: E5.05 +UP/DOWN 1: AI1 2: AI2 3: AI3 4: X6/FI 5: Multi-Reference 6: Communication	Default: 0
E5.05 PID digital setting	Range: E5.03 ~ E5.02 Unit: % This parameter is used for PID setting value when E5.04 = 0. The unit and resolution will be changed according to E5.00 and E5.01 .	Default: 50.0

E5.04 is used to select the channel of target process PID setting. The PID setting and feedback's unit will be changed based on engineering unit. And their value will be converted into relative value based on **E5.03** and **E5.02**.

The purpose of PID control is to make the PID setting and PID feedback equal.

E5.06 PID setting change time	Range: 0.00~99.99 Unit: Sec The time for PID setting value changing from E5.03 to E5.02 .	Default: 0.00
E5.07 PID feedback source	Range: 0~8 This parameter is used for setting PID feedback source. 0: AI1 1: AI2 2: AI3 3: AI1-AI2 4: X6/FI 5: AI1+AI2 6: MAX(AI1 , AI2) 7: MIN(AI1 , AI2) 8: Communication	Default: 0
E5.08 PID feedback filter time	Range: 0.00~60.00 Unit: Sec This parameter determines the AC drive response speed of PID feedback.	Default: 0.00




Figure 6- 36 PID feedback signal filtering

E5.09	Range: 0.0~999.9 Unit: %	Default: 15%
PID proportional gain Kp1	It decides the regulating intensity of the PID regulator. 100% indicates the adjustment amplitude of output frequency is b0.00 (Max frequency) in PID regulator when the deviation between PID feedback and PID setting is 100%. 0% means the PID regulator is a integral and differential controller. Higher proportional gain can speed up the dynamic response. But too high proportional gain will easily cause a system oscillation.	
E5.10	Range: 0.01~99.99 Unit: Sec	Default: 0.50S
PID integral time Ti1	It decides the integral regulating intensity. The shorter the integral time is, the larger the regulating intensity is. 1.00 second means the PID output will change with a speed of 10.0%/Sec when the deviation between PID feedback and PID setting is 10%. 0.00 second means the PID regulator is a proportional and differential controller. The integral control can reduce the static error. Short integral time can speed up the dynamic response. But too short integral time will easily cause overshoot and system oscillation.	
E5.11	Range: 0.000~9.999 Unit: Sec	Default: 0.000
PID differential time Td1	It decides the regulating intensity of the PID regulator on the deviation change. The longer the differential time is, the larger the regulating intensity is. 1.000 second means the PID output will change 10.0% when the deviation between PID feedback and PID setting is 10%. 0.000 second means the PID regulator is a proportional and integral controller. Differential control can forecast regulating intensity of the PID regulator on the deviation change, then make a quick response to improve the system dynamic performance. But it's easily interfered.	

E5.12	Range: 0.0~999.9	Default: 10.0
PID proportional gain Kp2	Unit: % Same with E5.09 (PID proportional gain Kp1).	
E5.13	Range: 0.01~99.99	Default: 1.00
PID integral time Ti2	Unit: Sec Same with E5.10 (PID integral time Ti1).	
E5.14	Range: 0.000~9.999	Default: 0.000
PID differential time Td2	Unit: Sec Same with E5.11 (PID differential time Td1).	

In some applications, PID parameters switchover is required when one group of PID parameters cannot satisfy the requirement of the whole running process.

The PID regulator has two groups of proportional gain,integral time and differential time.**E5.09~E5.11** is the first group parameters,and **E5.12~E5.14** is the second.

The switchover can be implemented via **E5.15**(PID parameter switchover condition).

E5.15	Range: 0~2	Default: 0
PID parameter switchover condition	Used for PID two groups parameters selection. 0:No switchover Always use the first group parameters(E5.09~E5.11). 1:Switchover via X terminals Use the first group parameters(E5.09~E5.11) when the X terminal is allocated with function No.40(PID parameter switchover) is valid,and the second(E5.12~E5.14) when X terminal is invalid. 2:Automatic switchover based on deviation Automatic switchover according to E5.16 (PID parameter switchover deviation 1)and E5.17 (PID parameter switchover deviation 2). Use the first group parameters(E5.09~E5.11) when the absolute value of the deviation between PID feedback and PID setting is smaller than the value of E5.16 ,and the second when higher than E5.17 . If the absolute value of deviation is between E5.16 and E5.17 ,PID regulator will use the linear interpolated value of two groups of parameters values,see the description of the following Figure.	
E5.16	Range: E5.03~E5.17	Default: 20.0
PID parameter switchover deviation 1	Unit: % The unit and resolution will be changed according to E5.00 and E5.01 . See the following figure.	

E5.17 Range: **E5.16~E5.02** Default: 80.0
PID parameter switchover deviation 2 Unit: %
 The unit and resolution will be changed according to **E5.00** and **E5.01**.
 See the following figure.




Figure 6- 37 The relationship between PID valid parameters and deviation

E5.18 Range: 0.0~100.0 Default: 0.0
PID output initial value Unit: %
 When the AC drive starts up, the PID starts closed-loop algorithm only after the PID output is fixed to **E5.18** and lasts the time set in **E5.19**.

E5.19 Range: 0.00~600.00 Default: 0.00
PID output initial value holding time Unit: Sec
E5.18 is invalid if setting **E5.19** to 0.00 second.

E5.20 Range: 0.00~60.00 Default: 0.00
PID output filter time Unit: Sec
 The PID output signal will be filtered by a first order filter.This parameter determine the filter time.
 Short filter time will speed up the response with low immunity,and long filter time will reduce the response speed with high immunity.

E5.21^o Range: 0~1 Default: 0
PID action direction
 0: Positive
 The AC drive will increase output frequency when the PID feedback value is lower than PID setting value.
 The AC drive will reduce output frequency when the PID feedback value is higher than PID setting value.
 1: Negative
 The AC drive will reduce output frequency when the PID feedback value is lower than PID setting value.
 The AC drive will increase output frequency when the PID feedback value is higher than PID setting value.
 See the following figure.

Table 6- 14 PID action direction selection

E5.21 (PID action direction)	X terminal function (Reverse PID action direction)	Final PID action direction
0(Positive)	OFF	Positive
0(Positive)	ON	Negative
1(Negative)	OFF	Negative
1(Negative)	ON	Positive

E5.22 PID differential limit	Range: 0.0~100.0 Unit: % It is used to set the PID differential output range. In PID control, the differential operation may easily cause system oscillation. Thus, the PID differential regulation is restricted to a small range.	Default: 0.5
E5.23 Maximum deviation between two PID outputs in forward direction	Range: 0.00~99.99 Unit: % This function is used to limit the deviation between two PID outputs (2 ms per PID output) to suppress the rapid change of PID output and stabilize the running of the AC drive. E5.23 and E5.24 respectively correspond to the maximum absolute value of the output deviation in forward direction and in reverse direction.	Default: 1.00
E5.24 Maximum deviation between two PID outputs in reverse direction	Range: 0.00~99.99 Unit: % Refer to E5.23.	Default: 1.00
E5.25 Cut-off frequency of PID reverse rotation	Range: 0.00~ b0.00 Unit: Hz In some situations, only when the PID output frequency is a negative value (AC drive reverse rotation), PID setting and PID feedback can be equal. However, too high reverse rotation frequency is prohibited in some applications, and FA-08 is used to determine the reverse rotation frequency upper limit.	Default: 0.00
E5.26 PID deviation limit	Range: 0.0~100.0 Unit: % Base on PID setting value.If the deviation between PID feedback and PID setting is smaller than the value of E5.26 , PID control stops. The small deviation between PID feedback and PID setting will make the output frequency stabilize, effective for some closed-loop control applications. See the following figure.	Default: 0.0

E5.27 Range: 0.0~320.0 Default: 0.0
PID deviation limit delay time Unit: Sec
 See the following figure.




Figure 6- 38 PID deviation limit function

E5.28 Range: 00~11 Default: 00
PID integral property **Unit's digit (Integral separated)**
 0: Invalid 1: Valid
 If it is set to valid, the PID integral operation stops when the DI allocated with function 39 "PID integral pause" is ON. In this case, only proportional and differential operations take effect.
 If it is set to invalid, integral separated remains invalid no matter whether the DI allocated with function 39 "PID integral pause" is ON or not.
Ten's digit (Whether to stop integral operation when the output reaches the limit)
 0: Continue integral operation 1: Stop integral operation
 If "Stop integral operation" is selected, the PID integral operation stops, which may help to reduce the PID overshoot.

E5.29 Range: 0~1 Default: 1
PID operation at stop
 0: No PID operation at stop 1: PID operation at stop
 It is used to select whether to continue PID operation in the state of stop. Generally, the PID operation stops when the AC drive stops.

E5.30 Range: 0~1 Default: 0
PID feedback detection enable
 0: Disabled 1: Enabled
 If "Disabled" is selected, the AC drive never detect whether PID feedback is lost.

E5.31 Minimum frequency of PID feedback detection	Range: 0.00~ b0.00 Unit: Hz When the PID output frequency is smaller than E5.31 ,the AC drive will not detect whether PID feedback is lost even if E5.30 =1.	Default: 5.00
E5.32 Waiting time of PID feedback detection	Range: 0.0~600.0 Unit: Sec When E5.30 =1 and the PID output frequency is higher than E5.31 for the time E5.32 set,the AC drive will detect whether PID feedback is lost .	Default: 0.0
E5.33 Upper limit of PID feedback detection	Range: E5.03 ~ E5.02 Unit: %. Unit/Decimal depends on E5.00 / E5.01 . The AC drive will not report any error when the PID feedback is between E5.34 ~ E5.33 .Otherwise,when the lasting time exceeds E5.35, Er35 "PID feedback over range" will be reported.	Default: 100.0
E5.34 Lower limit of PID feedback detection	Range: E5.03 ~ E5.02 Unit: %.Unit/Decimal depends on E5.00 / E5.01 . See the description of E5.33 .	Default: 0.0
E5.35 Detection time of PID feedback detection	Range: 0.0~600.0 Unit: Sec See the description of E5.33 .	Default: 0.0

These parameters are used to judge whether PID feedback is lost..




Figure 6- 39 PID feedback detection function

E5.36	Range: 0.0~200.0	Default: 0.0
Wake up level	Unit/Range depends on E5.44 .When in sleep mode,if the feedback is smaller than the value E5.36 set,and the lasting time exceeds E5.37 ,the AC drive will quit sleep mode.	
E5.37	Range: 0.0~6500.0	Default: 0.0
Wake up delay time	Unit: Sec See the description of E5.36 .	
E5.38	Range: 0~1	Default: 0
Sleep mode	0: Base on output frequency The AC drive enters sleep mode when PID output frequency is smaller than E5.40 and the lasting time exceeds E5.41 . 1: Base on PID feedback The AC drive enters sleep mode when PID feedback is higher than E5.39 and the lasting time exceeds E5.41 .	
E5.39	Range: 0.0~200.0	Default: 0.0
Sleep level	Unit/Range depends on E5.44 .See the description of E5.38 and the following figure.	
E5.40	Range: 0.00~b0.00	Default: 0.00
Sleep frequency	Unit: Hz See the description of E5.38 and the following figure.	
E5.41	Range: 0.0~6500.0	Default: 0.0
Sleep delay time	Unit: Sec 0 means no sleep function.See the description of E5.38 and the following figure.	

Here are two examples for two different PID sleep mode.

Example 1: E5.38 = 1(Base on PID feedback).




Figure 6- 40 Sleep base on PID feedback

Example 2: E5.38 = 0(Base on output frequency).




Figure 6- 41 Sleep base on output frequency

E5.42	Range: 0.0~100.0	Default: 100.0	Unit: %
PID setting high limit	PID setting value higher limit of internal operation.		
E5.43	Range: 0.0~100.0	Default: 0.0	Unit: %
PID setting low limit	PID setting value lower limit of internal operation.		
E5.44^o	Range: 0~1	Default: 0	
Base value selection of PID sleep and wake up threshold	The Unit/Range of E5.36 and E5.39 is determined by E5.44 . 0:Unit is Percentage (%),base value is PID setting and range is 0.0~200.0%. 1:Unit is the same as PID engineering unit(E5.00),range is E5.03~E5.02 .		

Group E6: Multi-Pump Control

Key points:

- Multi-pump control logic can control no more than 4 pumps when working together with PID regulator.
- AC drive can switch a pump to its output or power grid via a relay or Y terminal(controlling a external relay).
- A contact of the manual on/off switch (or protective device, such as a thermal relay, etc.) of each motor is wired to the interlock circuit. The logic will detect if a motor is unavailable and start the next available motor instead.
- Auto change function is used to make sure each pump takes the average load in the system.It will adjust the startup sequence to prevent pump rust caused by long time no used.The motor startup sequence will return to initial status when AC drive stops or re-power on.
- There are two ways for adding a pump.1)Directly connecting the auxiliary pumps to power grid(mode 1~2).2)The auxiliary pumps are softly started by AC drive first. Then it will be switch to power grid.AC drive will directly control another new speed-regulated pump(mode 3~4).
- If a motor can be connected to AC drive or power grid,the two switching contactors must be electric interlocked.
- The motor phase sequence must be validated before power on.Make sure the motor rotation direction under power grid is the same with connecting to AC drive.
- AC drive will enter sleep mode when meets the sleep conditions and there is only one speed-regulated pump running.




Figure 6- 42 Multi-pump control wiring diagram

E6.00^o Range: 0~4 Default: 0

Multi-pump control mode

This series AC drive support multi-pump control modes. Each of them is apply to different application area with different configuration and operation logic:

0:Inactive
 The AC drive can only work at single pump control mode.

1:Frequency pump fixed,No auto change
 The AC drive controls a specific adjustable speed motor,other auxiliary motors are all controlled via relays.
 This mode needs to configurate the system as shown in the top figure of next page.
 The auxiliary motor will be directly connected to power grid when adding a pump.

2:Frequency pump fixed,Support auto change
 Base on mode 1,auxiliary motors can be auto changed.

3:Frequency pump circulation,No auto change
 Any pump can be connected to power grid or directly controlled by AC drive in this mode.
 This mode needs to configurate the system as shown in the bottom figure of next page.
 The auxiliary motor will be softly start by AC drive when adding a pump.

4:Frequency pump circulation,Support auto change
 Base on mode 3,all motors can be auto changed.

Table 6- 15 multi-pump control mode

Multi-pump control mode	Frequency pump	Auto change	Configuration
1	Fixed	Nonsupport	The top figure of next page.
2	Fixed	Support	
3	Unfixed	Nonsupport	The bottom figure of next page.
4	Unfixed	Support	

Parameter	Configuration	
C1.04 (T1 function)	40	Motor1# Control output
C1.05 (T2 function)	41	Motor2# Control output




Figure 6-43 Frequency pump fixed wiring configuration

Parameter	Configuration	
C1.04 (T1 function)	40	Motor1# Control output
C1.05 (T2 function)	41	Motor2# Control output
C1.06 (T3 function)	42	Motor2# Control output




Figure 6-44 Frequency pump circulation wiring configuration

Note: If necessary, please use Y terminals to control external relays in multi-pump configuration.
 Do not directly use Y terminals.

E6.01	Range: 1~4	Default: 1
Number of motors	Motor numbers of multi-pump control system.	
E6.02	Range: 0.0~100.0	Default: 0.0
Reference step 1	Unit: % Add a percentage increment(base on PID setting) to the initial PID setting value. ✓ Be valid when there is at least 1 auxiliary motor running. Example: The AC drive controls 3 parallel pumps to supply water through pipeline.E5.05 sets the pipeline pressure. When the water consumption is small,there is only frequency pump running.The auxiliary pumps will be added one by one as the water consumption increasing. > Reference step is E6.02 when the first auxiliary pump starts. > Reference step is the sum of E6.02 and E6.03 when the second auxiliary pump starts. > Reference step is the sum of E6.02, E6.03and E6.04 when the third auxiliary pump starts.	
E6.03	Range: 0.0~100.0	Default: 0.0
Reference step 2	Unit: % See the parameter description of E6.02 . ✓ Be valid when there is at least 2 auxiliary motor running.	
E6.04	Range: 0.0~100.0	Default: 0.0
Reference step 3	Unit: % See the parameter description of E6.02 . ✓ Be valid when there is at least 3 auxiliary motor running.	
E6.05	Range: 00~11	Default: 00
Interlock functions	Interlock function is used to indicate whether each motor is connected to multi-pump control logic or not. Unit's digit: interlock enable 0:disabled 1:enabled Ten's digit: interlock mode 0:decided by X terminals 1:decided by E6.06	

Choose any of the following two connection mode for interlock circuit:

- 1) A contact of the manual on/off switch of each motor is wired to the interlock circuit. The logic will detect if a motor is unavailable and start the next available motor instead.
- 2) A contact of thermal relay (or other protective device) of each motor is wired to the interlock circuit. The logic will detect if a motor has fault and decide to stop it.

Examples of motor interlock in multi-pump control logic:

- > Suppose the motor startup sequence is: 1 -> 2 -> 3 -> 4.
- > If motor 3 is removed, then the motor startup sequence is: 1 -> 2 -> 4.
- > Then if motor 3 is added again, it will be added to the last of startup sequence: 1 -> 2 -> 4 -> 3.
- > If the multi-pump control system stops, or enters into sleep mode, the motor startup sequence will return to the initial status when system runs again: 1 -> 2 -> 3 -> 4.

E6.06	Range: 0000~1111	Default: 0000
Digital setting of Motor interlock	0: Not connected to multi-pump system 1: Connected to multi-pump system	
	Unit's digit: Motor1#	
	Ten's digit: Motor2#	
	Hundred's digit: Motor3#	
	Thousand's digit: Motor4#	
E6.07	Range: 0.1~6000.0	Default: 48.0
Auto-change interval	Unit: h When the lasting time exceeds the set value of E6.07, AC drive will begin auto changing if idle motor numbers is no less than E6.09 and speed-regulated motor operation frequency is lower than E6.08. Auto change function is to make an average distribution of the total working time to each motor in multi-pump system.	
E6.08	Range: 0.00~ b0.00	Default: 45.00
Auto-change frequency limit	Unit: Hz Auto-change function will be forbidden when AC drive output higher than the frequency E6.08 set.	
E6.09	Range: 1~3	Default: 1
Auto-change Motor limit	See the parameter description of E6.07 .	
E6.10	Range: 0.00~ b0.00	Default: 48.00
Add pump frequency 1	Unit: Hz The frequency to add the first auxiliary pump (controlled via a Y/T terminal with No.41 function "Motor 2# Control output").	

The first auxiliary pump startup conditions:

- > No auxiliary pump is running.
- > AC drive output frequency is higher than $E6.10+1\text{Hz}$, and the lasting time exceeds **E6.16**.

After the first auxiliary pump startup:

- > AC drive reduces output frequency by a step of **(E6.10-E6.11)**.
- > The reduced speed of speed-regulated motor gives a compensation to the increment from auxiliary pump startup. See the description of Figure below.




Figure 6- 45 Schematic diagram of adding pump logic

E6.11
Reduce pump
frequency 1

Range: 0.00~**E6.10**

Default: 25.00

Unit: Hz

The frequency to remove the first auxiliary pump (controlled via a Y/T terminal with No.41 function "Motor 2# Control output").

The first auxiliary pump stop conditions:

- > Only one auxiliary pump is running.
- > AC drive output frequency is lower than $E6.11-1\text{Hz}$, and the lasting time exceeds **E6.17**.

After the first auxiliary pump stop:

- > AC drive increases output frequency by a step of **(E6.10-E6.11)**.
- > The increased speed of speed-regulated motor gives a compensation to the decrement from auxiliary pump stop. See the description of Figure below.




Figure 6- 46 Schematic diagram of removing pump logic

- E6.12** Range: 0.00~**b0.00** Default: 48.00
Add pump frequency 2 Unit: Hz
 The frequency to add the second auxiliary pump(controlled via a Y/T terminal with No.42 function "Motor 3# Control output").
 The second auxiliary pump startup conditions:
 > Only one auxiliary pump is running.
 > AC drive output frequency is higher than E6.12+1Hz,and the lasting time exceeds **E6.16**.
- E6.13** Range: 0.00~**E6.12** Default: 25.00
Reduce pump frequency 2 Unit: Hz
 The frequency to remove the second auxiliary pump(controlled via a Y/T terminal with No.42 function "Motor 3# Control output").
 The second auxiliary pump stop conditions:
 > Two auxiliary pump are running.
 > AC drive output frequency is lower than E6.13-1Hz,and the lasting time exceeds **E6.17**.
- E6.14** Range: 0.00~**b0.00** Default: 48.00
Add pump frequency 3 Unit: Hz
 The frequency to add the third auxiliary pump(controlled via a Y/T terminal with No.43 function "Motor 4# Control output").
 The third auxiliary pump startup conditions:
 > Two auxiliary pump are running.
 > AC drive output frequency is higher than E6.14+1Hz,and the lasting time exceeds **E6.16**.

E6.15	Range: 0.00~ E6.14	Default: 25.00
Reduce pump frequency 3	Unit: Hz The frequency to remove the third auxiliary pump(controlled via a Y/T terminal with No.43 function "Motor 4# Control output"). The third auxiliary pump stop conditions: > Three auxiliary pump are running. > AC drive output frequency is lower than E6.15-1Hz,and the lasting time exceeds E6.17 .	
E6.16	Range: 0.0~3600.0	Default: 5.0
Add pump delay time	Unit: Sec The delay time of starting auxiliary motor.	
E6.17	Range: 0.0~3600.0	Default: 3.0
Dec pump delay time	Unit: Sec The delay time of removing auxiliary motor.	
E6.18	Range: 0.00~10.00	Default: 0.20
Electromagnetic Switch delay time	Unit: Sec Define the delay time of electromagnetic switch action.	
E6.19	Range: 0.00~ b0.00	Default: 50.00
Switchover frequency from AC Drive to grid	Unit: Hz Define the motor switchover frequency from AC drive to power grid.	

Multi-pump control mode 1:

> Pump adding logic

The speed-regulated pump starts after running AC drive.When the speed-regulated pump operation frequency is higher than "Add pump frequency 1+1Hz",and the lasting time exceeds "Add pump delay time",motor 2# will be connected to power grid.Meanwhile,AC drive reduces output frequency by a step of (add pump frequency 1 - reduce pump frequency 1).

> Pump removing logic

The speed-regulated pump operation frequency is lower than "Reduce pump frequency 1 - 1Hz",and the lasting time exceeds "Dec pump delay time",motor 2# will be removed from power grid.Meanwhile,AC drive increases output frequency by a step of (add pump frequency 1 - reduce pump frequency 1).

Multi-pump control mode 2:

- Pump adding logic
 - The same with mode 1.
- Pump removing logic
 - The same with mode 1.
- Auto change logic
 - Suppose current auxiliary pump startup sequence is 2->3->4.
 - speed-regulated motor and motor 2# are running, and the conditions is suitable for auto change..
 - Multi-pump control logic will switch auxiliary pump to the system by the sequence: 3->4->2.
 - First AC drive cuts off the connection of Motor 2#.
 - Then AC drive switch Motor 3# to the system directly.
 - And so on.

Multi-pump control mode 3:

- Pump adding logic
 - First all pumps are in stop mode.
 - When received running command, AC drive start Motor 1# after the time set by E6.18.
 - AC drive will stop by coasting mode and disconnect motor 1# if whole system can not meet the demand. Then motor 2# will be started by AC drive. After the time set by E6.18, motor 1# will be connected to power grid.
 - If the whole system still can not meet the demand, AC drive will stop by coasting mode and disconnect motor 2# . Then motor 3# will be started by AC drive. After the time set by E6.18, motor 2# will be connected to power grid.
 - And so on.
 - Pump removing logic
 - Current speed-regulated motor is motor 3#.
 - Suppose two auxiliary motors are running, and the system supply is more than actual demand.
 - If AC drive output decreases to lower than "Reduce pump frequency 2 - 1", and lasts for "Dec pump delay time", Motor 1# will be disconnected from power grid. Then AC drive will increase output frequency by a step of (Add pump frequency 2 - Reduce pump frequency 2).
 - Motor 2# removing logic is similar with motor 1#.
-

Multi-pump control mode 4:

- Pump adding logic
The same with mode 3.
- Pump removing logic
The same with mode 3.
- Auto change logic
 - Suppose current auxiliary pump startup sequence is 1->2->3->4.
 - Motor 1# and 2# are in running, and motor 2# is speed-regulated motor.
 - AC drive will stop by coasting mode when meets the auto change conditions.
 - And motor 2# contactor will be disconnected.
 - Motor 3# is chosen as the next speed-regulated motor.
 - Motor 3# contactor will be closed by multi-pump control logic. And the motor will be directly connected to AC drive output.
 - After the time set by E6.18, AC drive will start motor 3# from zero frequency according to PID regulator.
 - Then motor 2# contactor will be closed. And motor 2# is connected to power grid.
 - Finally motor 1# contactor will be disconnected. And motor 1# stop working.
 - Multi-pump control logic will make sure the total numbers of operating motor is the same before and after auto change.

Group E7: Swing Frequency

The swing frequency function is applied to the textile and chemical fiber fields and the applications where traversing and winding functions are required.

The swing frequency function indicates that the output frequency of the AC drive swings up and down with the set frequency as the center. The trace of running frequency at the time axis is shown in the following figure.

The swing amplitude is set in **E7.00** and **E7.01**. When **E7.01** is set to 0, the swing amplitude is 0 and the swing frequency does not take effect.




Figure 6- 47 Swing frequency control diagram

E7.00	Range: 0~1	Default: 0
Swing frequency setting mode	0: relative to setting frequency It is variable swing amplitude system. The swing amplitude varies with the central frequency (set frequency). $\text{Swing amplitude frequency } Dw = \text{current set frequency} * \mathbf{E7.01}$ 1: relative to max frequency It is fixed swing amplitude system. The swing amplitude is fixed. $\text{Swing amplitude frequency } Dw = \text{Max frequency}(\mathbf{b0.00}) * \mathbf{E7.01}$	
E7.01	Range: 0.0~100.0	Default: 0.0
Swing frequency amplitude	Unit: % 0 means the swing frequency does not take effect. Method of calculation please see the parameter description of E7.00 . The swing frequency is limited by the frequency upper limit b0.02 and frequency lower limit b0.03 .	
E7.02	Range: 0.0~50.0	Default: 0.0
Skip frequency amplitude	Unit: % The percentage of skip frequency amplitude to swing frequency amplitude. $\text{Skip frequency } Jw = \text{Swing amplitude frequency } Dw * \mathbf{E7.02}$.	
E7.03	Range: 0.1~3000.0	Default: 10.0
Swing frequency cycle	Unit: Sec The time of a complete swing frequency cycle.	
E7.04	Range: 0.1~99.9	Default: 50.0
Triangular wave rising time coefficient	Unit: % The time percentage of triangular wave rising time to E7.03 (Swing frequency cycle). $\text{Triangular wave rising time} = \mathbf{E7.03} (\text{Swing frequency cycle}) * \mathbf{E7.04}$ (Triangular wave rising time coefficient) $\text{Triangular wave falling time} = \mathbf{E7.03} (\text{Swing frequency cycle}) * (1 - \mathbf{E7.04})$ (Triangular wave falling time coefficient)	
E7.05	Range: E7.06 ~65535	Default: 1000
Set count value	The count value needs to be collected by X terminal. Allocate the corresponding X terminal with function 42 (Counter input) in applications. If the pulse frequency is high, X6/FI must be used. When the count value A0.25(Pulse counter) reaches E7.05(the set count value), the Y terminal allocated with function 20 (Set count value reached) becomes ON. Then the counter stops counting.	

E7.06 Range: 1~**E7.05** Default: 1000
Designated count value When the counting value reaches E7.06 (the designated counting value), the Y terminal allocated with function 21 (Designated count value reached) becomes ON. Then the counter continues to count until the set count value is reached.
 E7.06 should be equal to or smaller than E7.05.

Example:

E7.05(Set count value)= 7, E7.06(Designated count value)= 3, C0.01(X1function)= 42(Counter input), C0.02(X2 function)= 43(Counter reset), C1.01(Y1function)= 21(Designated count value reached), C1.02(Y2 function)= 20(Set count value reached).

So, Y1 will become ON when the third pulse inputs X1. Y2 will become ON when the seventh pulse inputs X1. Y1 and Y2 will return to OFF status when X2 becomes effective.




Figure 6- 48 Reaching the set count value and designated count value diagram

E7.07 Range: 0~65535 Default: 1000
Set length Unit: m
 Allocate corresponding X terminal with function 44 (Length count input) in applications. If the pulse frequency is high, X6/FI must be used.
 The length information is collected by X terminals. **A0.26** (Actual length) is calculated by dividing the number of pulses(collected from the X terminal) by **E7.08** (Number of pulses each meter).
 When the actual length **A0.26** exceeds the set length in **E7.07**, the Y terminal allocated with function 22 (Length reached) becomes ON.
 During the fixed length control, the length reset operation can be performed via the X terminal allocated with function 45(Length reset).

E7.08 Range: 0.1~6553.5 Default: 100.0
Number of Pulses per meter See the parameter description of **E7.07**.

Group E8: Droop Control

The drooping function enables speed drop as a function of load. It is used for balancing the workload allocation when multiple motors are used to drive the same load.

The output frequency of the AC drives decreases as the load increases.

You can reduce the workload of the motor under load by decreasing the output frequency for this motor, implementing workload balancing between multiple motors.

Please see the description of Figure below.

E8.00	Range: 0.00~10.00	Default: 0.00
Droop control	Unit: Hz	
	This parameter sets the droop frequency when motor is loader with its nominal torque. The drooping function is disabled when setting E8.00=0.	
E8.01	Range: 0.00~60.00	Default: 0.00
Droop control filter time	Unit: Sec	
	Decrease the value of E8.01 when the drooping function has a slow reaction.If there is a system oscillation or overshoot,please increase the value of E8.01.	




Figure 6- 49 The drooping function diagram

Group E9: Power Loss Ride Through

Upon power loss ride through or sudden voltage dip, the DC bus voltage of the AC drive reduces. This function enables the AC drive to compensate the DC bus voltage reduction with the load feedback energy by reducing the output frequency so as to keep the AC drive running continuously.

Upon power loss ride through or sudden voltage dip, the AC drive decelerates. Once the bus voltage resumes to normal, the AC drive accelerates to the set frequency. If the bus voltage remains normal for the time exceeding the value set in E9.03, it is considered that the bus voltage resumes to normal.

E9.00 Action selection at power loss ride through	Range: 0~1 0: Disabled 1: Enabled	Default: 0
E9.01 Action judging voltage at power loss ride through	Range: 40.0~150.0 Unit: % The AC drive begins to decelerate when the DC bus voltage is lower than E9.01. This is a relative value, and the base value is shown in the following table.	Default: 80.0

Table 6- 16 The base value of E9.01 under different input voltage level

Input voltage level	Base value	Input voltage level	Base value
Single-phase 220V	311V	Three-phase 480V	670V
Three-phase 220V	311V	Three-phase 690V	975V
Three-phase 380V	537V	Three-phase 1140V	1600V

E9.02 Action pause judging voltage at power loss ride through	Range: 60.0~150.0 Unit: % See the description of Figure below.	Default: 100.0
E9.03 Voltage rally judging time at power loss ride through	Range: 0.00~50.00 Unit: Sec See the description of Figure below.	Default: 0.50




Figure 6- 50 Power loss ride through diagram(E9.00 = 1)

Group EA: External Brake

EA.00^o Range: 0~1 Default: 0
External brake enable 0: Inactive
 1: Active
 See the description of Figure below.




Figure 6- 51 External brake control schematic diagram

1. The AC drive begins to output when receives a start command.
2. If the output current is higher than EA.02 and the output frequency reaches EA.01, the Y terminal allocated with function No.44 "External brake control" becomes OFF when the lasting time exceeds EA.03.
3. Then the AC drive keeps running at the frequency of EA.01, and begins to accelerate to set frequency when the lasting time reaches the value set by EA.04.
4. When there is a stop command, the AC drive decelerates to run at the frequency of EA.05.
5. The Y terminal allocated with function No.44 "External brake control" becomes ON after the time set by EA.06.
6. The AC drive goes to stop mode after the delay time set by EA.07.

EA.01^o Range: 0.00~10.00 Default: 2.50
External brake off frequency limit Unit: Hz
 The Y terminal allocated with function No.44 "External brake control" becomes OFF when the AC drive output frequency reaches EA.01.
 Please set this parameter according to the motor rated slip frequency.

EA.02^o	Range: 0.0~180.0	Default: 110.0
External brake off current limit	Unit: % The output current needs to be higher than EA.02 when the AC drive begins to accelerate from the frequency of EA.01. Base value is motor rated current.	
EA.03^o	Range: 0.00~10.00	Default: 0.50
External brake off delay time	Unit: Sec If the output current is higher than EA.02 and the output frequency reaches EA.01,the Y terminal allocated with function No.44 "External brake control" becomes OFF when the lasting time exceeds EA.03.	
EA.04^o	Range: 0.00~10.00	Default: 1.00
Acceleration pause time for external brake off	Unit: Sec The AC drive stops accelerating for the time set by EA.04 when the Y terminal allocated with function No.44"External brake control" becomes OFF.Then it begins to accelerate. Please set this parameter to suitable value according to the release time of mechanical brake.	
EA.05^o	Range: 0.00~10.00	Default: 2.00
External brake on frequency limit	Unit: Hz When received a stop command,the AC drive decelerates to run at the frequency of EA.05,and then the Y terminal allocated with function No.44 "External brake control" becomes OFF after the time set by EA.06.	
EA.06^o	Range: 0.00~10.00	Default: 0.00
External brake on waiting time	Unit: Sec See the parameter description of EA.05.	
EA.07^o	Range: 0.00~10.00	Default: 1.00
Stop delay time after external brake on	Unit: Sec The AC drive goes to stop mode after the delay time set by EA.07 when the Y terminal allocated with function No.44"External brake control" becomes ON.This action is used to make sure that the mechanical brake completely pulls.	

Group Eb: Supervision

Eb.00^o	Range: 0~1	Default: 0
Timing function	0: Inactive 1: Active	
	If the timing function is active,the AC drive begins to time after received a start commend.And the Y terminal allocated with function NO.32 "Timing reached" becomes ON when the timing duration reaches the value set by Eb.02.	
	Timing duration source is decided by Eb.01.	
	The rest of timing duration can be watched by A0.28.	
Eb.01^o	Range: 0~3	Default: 0
Timing duration source	0: Eb.02 1: AI1 2: AI2 3: AI3	
	The base value is Eb.02 when choose analog input as timing duration source.	
Eb.02^o	Range: 0.0~6500.0	Default: 0.0
Timing duration	Unit: Min	
	This is timing duration when Eb.01 is set to 0.	
	100% analog input equals to Eb.02 when Eb.01 is set to 1~3.	
Eb.03^o	Range: 0.0~6500.0	Default: 0.0
Current running time reached	Unit: Min	
	The Y terminal allocated with function No.25 "Current running time reached" becomes ON when the AC drive current running time reaches the value set by Eb.03.	
Eb.04	Range: 0~9999	Default: 0
Accumulative power-on time(day) threshold	Unit: Day	
	This parameter is with the use of Eb.05.	
	The AC drive accumulative power-on time is made up of Eb.04 and Eb.05.	
	1) Suppose that Eb.04 = 128 and Eb.05 = 12.30,then the total accumulative power-on time is 128 days 12 hours and 18 minutes.	
	2) The accumulative power-on time reached function is disabled when simultaneously setting Eb.04 and Eb.05 to 0.	
	The Y terminal allocated with function NO.23 "Accumulative power-on time reached" becomes ON when accumulative power-on time(A0.54+A0.55) reaches the set value(Eb.04+Eb.05).And the AC drive will act as the hundred's digit setting of F0.21.	
Eb.05	Range: 0.00~23.99	Default: 0.00
Accumulative power-on time(hour) threshold	Unit: h	
	See the parameter description of Eb.04.	

Eb.06	Range: 0~9999	Default: 0
Accumulative running time(day) threshold	Unit: Day	
	This parameter is with the use of Eb.07.	
	The AC drive accumulative running time is made up of Eb.06 and Eb.07.	
	3) Suppose that Eb.06 = 25 and Eb.07 = 10.55, then the total accumulative running time is 25 days 10 hours and 33 minutes.	
	4) The accumulative running time reached function is disabled when simultaneously setting Eb.06 and Eb.07 to 0.	
	The Y terminal allocated with function NO.24 "Accumulative running time reached" becomes ON when accumulative running time(A0.56+A0.57) reaches the set value(Eb.06+Eb.07). And the AC drive will act as the thousand's digit setting of F0.21.	
Eb.07	Range: 0.00~23.99	Default: 0.00
Accumulative running time(hour) threshold	Unit: h	
	See the parameter description of Eb.06 .	
Eb.08	Range: 0.0~100.0	Default: 0.2
Detection range Of frequency reached	Unit: %	
	If the AC drive running frequency is within the certain range of the set frequency, the Y terminal allocated with function No.7 "Frequency reached" becomes ON.	
	This parameter is used to set the range within which the output frequency is detected to reach the set frequency. The value of this parameter is a percentage relative to b0.00 (Max frequency). The detection range of frequency reached is shown in the following figure.	




Figure 6- 52 Detection diagram of frequency reached

Eb.09 Any frequency reaching detection value 1	Range: 0.00~ b0.00 Unit: Hz If the output frequency of the AC drive is within the positive and negative amplitudes of Eb.09, the Y terminal allocated with function No.26 "Frequency 1 reached" becomes ON. See the description of Figure below.	Default: 50.00
Eb.10 Any frequency reaching detection amplitude 1	Range: 0.0~100.0 Unit: % The base value is b0.00 (Max frequency). See the description of Figure below.	Default: 0.0
Eb.11 Any frequency reaching detection value 2	Range: 0.00~ b0.00 Unit: Hz If the output frequency of the AC drive is within the positive and negative amplitudes of Eb.11, the Y terminal allocated with function No.27 "Frequency 2 reached" becomes ON. See the description of Figure below.	Default: 50.00
Eb.12 Any frequency reaching detection amplitude 2	Range: 0.0~100.0 Unit: % The base value is b0.00 (Max frequency). See the description of Figure below.	Default: 0.0




Figure 6- 53 Any frequency 1/2 reaching detection function diagram

Eb.13 Frequency detection threshold 1 (FDT1)	Range: 0.00~ b0.00 Unit: Hz If the running frequency is higher than the value of Eb.13, the Y terminal allocated with function No.10 "FDT1 detection output" becomes ON. If the running frequency is lower than value of Eb.13*(1-Eb.14) , the Y terminal goes OFF. See the description of Figure below.	Default: 50.00
---	--	----------------

<p>Eb.14 Frequency detection Hysteresis 1 (FDT hysteresis1)</p>	<p>Range: 0.0~100.0 Unit: % This is a percentage of the hysteresis frequency to Eb.13. See the parameter description of Eb.13.</p>	<p>Default: 5.0</p>
<p>Eb.15 Frequency detection threshold 2 (FDT2)</p>	<p>Range: 0.00~b0.00 Unit: Hz If the running frequency is higher than the value of Eb.15, the Y terminal allocated with function No.11 "FDT2 detection output" becomes ON. If the running frequency is lower than value of Eb.15*(1-Eb.16), the Y terminal goes OFF. See the description of Figure below.</p>	<p>Default: 50.00</p>
<p>Eb.16 Frequency detection hysteresis2 (FDT hysteresis2)</p>	<p>Range: 0.0~100.0 Unit: % This is a percentage of the hysteresis frequency to Eb.15. See the parameter description of Eb.15.</p>	<p>Default: 5.0</p>




Figure 6- 54 FDT detection function diagram

<p>Eb.17 Zero current detection level</p>	<p>Range: 0.0~300.0 Unit: % This is a relative value to motor rated current. If the output current of the AC drive is equal to or less than Eb.17*b0.08(motor rated current) and the duration exceeds Eb.18 ,the Y terminal allocated with function No.19 "Zero current status" becomes ON. The zero current detection is shown in the following figure.</p>	<p>Default: 5.0</p>
<p>Eb.18 Zero current detection delay time</p>	<p>Range: 0.01~600.00 Unit: Sec Please see the description of the following figure.</p>	<p>Default: 0.10</p>




Figure 6-55 Zero current detection diagram

Eb.19
Output over
current threshold

Range: 0.0~300.0

Default: 200.0

Unit: %

This is a relative value to **b0.08**(motor rated current).

If the output current of the AC drive is equal to or higher than **Eb.19*b0.08** and the duration exceeds **Eb.20**,the Y terminal allocated with function No.34 “Current limit exceeded” becomes ON. The output over current detection function is shown in the following figure.

Eb.20
Output over
current detection
delay time

Range: 0.00~600.00

Default: 0.00

Unit: Sec

Please see the description of the following figure.




Figure 6-56 Output over current detection diagram

Eb.21
Any current
reaching 1

Range: 0.0~300.0

Default: 100.0

Unit: %

This is a relative value to **b0.08**(motor rated current).

If the output current of the AC drive is within the positive and negative amplitudes of **Eb.21*b0.08**, the Y terminal allocated with function No.28 “Current 1 reached” becomes ON.

The any current detection function is shown in the following figure.

- Eb.22** Range: 0.0~300.0 Default: 0.0
Any current reaching 1 amplitude Unit: %
 This is a relative value to **b0.08**(motor rated current). Please see the description of the following figure.
- Eb.23** Range: 0.0~300.0 Default: 100.0
Any current reaching 2 Unit: %
 This is a relative value to **b0.08**(motor rated current). If the output current of the AC drive is within the positive and negative amplitudes of **Eb.23*b0.08**, the Y terminal allocated with function No.29 "Current 2 reached" becomes ON. The any current detection function is shown in the following figure.
- Eb.24** Range: 0.0~300.0 Default: 0.0
Any current reaching 2 amplitude Unit: %
 This is a relative value to **b0.08**(motor rated current). Please see the description of the following figure.




Figure 6- 57 Any current reaching detection diagram

- Eb.25** Range: 0.00~**Eb.26** Default: 3.70
A11 input voltage lower limit Unit: V
Eb.25 and **Eb.26** are used to set the limits of the A11 input voltage to provide protection on the AC drive. When the A11 input is smaller than the value of **Eb.25** or larger than the value of **Eb.26**,the Y terminal allocated with function No.31 "A11 input limit exceeded" becomes ON.
- Eb.26** Range: **Eb.25**~10.00 Default: 7.20
A11 input voltage upper limit Unit: V
 Please see the parameter description of **Eb.25**.
- Note:** 1mA equals to 0.5V when A11 input signal is current type.
- Eb.27** Range: - 40.0~125.0 Default: 100.0
Module temperature threshold Unit: °C
 When the AC drive module heatsink temperature of the AC drive reaches the value of this parameter,the Y terminal allocated with function No.17 "AC drive module temperature reached" becomes ON.

- Eb.28** Range: 0.00~**b0.00** Default: 2.00
Simple brake frequency Unit: Hz
 In the process of stopping, Y/T terminal assigned with function '45: Simple brake control' will be ON for the time **Eb.29** set when the AC drive output frequency is lower than **Eb.28**.
- Eb.29** Range: 0.0~3000.0 Default: 0.0
Simple brake time Unit: Sec
 Set **Eb.29** to a nonzero value will enable simple brake function.

Group F0: Protection

- F0.00** Range: Model dependent Default: Model dependent
Under voltage threshold
 It is used to set the undervoltage threshold for the drive. The default value and range of different classes are list in the following table.

Table 6- 17 Undervoltage threshold in different voltage class

Voltage Class(V)	Default(V)	Range(V)	Voltage Class(V)	Default(V)	Range(V)
Single-phase 220	200	180 - 280	Three-phase 480	450	350 - 600
Three-phase 220	200	180 - 280	Three-phase 690	650	500 - 800
Three-phase 380	350	280 - 550	Three-phase 1140	1350	1100 - 1500

- F0.01^o** Range: Model dependent Default: Model dependent
Over voltage threshold
 It is used to set the overvoltage threshold for the drive. The default value and range of different classes are list in the following table.

Table 6- 18 Overvoltage threshold in different voltage class

Voltage Class(V)	Default(V)	Range(V)	Voltage Class(V)	Default(V)	Range(V)
Single-phase 220	380	360 - 410	Three-phase 480	880	660 - 900
Three-phase 220	380	360 - 410	Three-phase 690	1200	1100 - 1300
Three-phase 380	780	630 - 800	Three-phase 1140	2400	2300 - 2500

- F0.02** Range: 0~1 Default: 1
Input phase loss protection
 0: Disable If input phase loss then drive will not perform protecting action.
 1: Enable If input phase loss then drive will perform protecting action according to F0.19(Unit's digit).
Note: This protection is valid only in the AC drives which power are larger or equal than 11KW(G type).
- F0.03** Range: 0~1 Default: 1
Output phase loss protection
 0: Disable If out phase loss then drive will not perform protecting action.
 1: Enable If input phase loss then drive will perform protecting action according to F0.19(Ten's digit).

F0.04	Range: 0~1	Default: 0
Short-circuit to ground upon power-on	0: Disable 1: Enable It is used to determine whether to check the motor is short-circuited to ground at power-on of the drive. If this function is enabled, the drive's UVW will output voltage for a while after power-on for check motor insulation.	
F0.05	Range: 0.30~3.00	Default: 1.00
AC drive over load protection gain	When the carrier frequency or the ambient temperature is low, the drive overload capacity will enhance, increasing this parameter properly can improve the drive overload ability.	
F0.06	Range: 0~1	Default: 1
Motor overload protection	0: Disable 1: Enable If the motor overload protection function is enabled, protecting action will be performed when motor current and duration exceed the threshold. The characteristic curve of the motor overload protection is shown in figure below. Protecting action is depended on the setting of F0.19(Thousand's digit).	
F0.07	Range: 0.20~10.00	Default: 1.00
Motor overload protection gain	It is defined the motor overload protection gain, the detail as shown in figure below.	

The user can adjust the motor overload current and time by set the parameter of **F0.07**, 100% corresponds to motor current.

For example:

If F0.07 = 1.00 and the overload gain is 120%, then:

$$T_{120} = (120\% - 115\%) * (80 - 40) / (125\% - 115\%) + 40 = 60(\text{Minutes})$$

Assume that overload gain is 120% and 30 minutes motor overload time is expected, then:

the overload time of 30 minutes is firmed between 123% to 135% When F0.07 = 1.00 as the figure below,so the allowed overload gain is:

$$129\% = (30 - 15) * (135\% - 125\%) / (15 - 40) + 125\%$$

Then the motor overload protection gain of F0.07 = 120%/129% = 0.93




Figure 6- 58 the inverse time-lag curve

F0.08	Range: 50~100	Default: 80
Motor overload warning coefficient	Unit: %	
	This function is used to generate a warning signal to the control system via DO before motor overload protection. The larger the value is, the less advanced the pre-warning will be.	
	To generate this warning signal, a DO terminal can be configured as function 15 (motor overload pre-warning).	
F0.09	Range: 0~1	Default: 0
Under load protection	0: Disable 1: Enable	
	If the under load protection function is enabled, when the motor current is less than the detection level (F0.10 * b0.08) and the lasting time exceeds the detection time (F0.11), protecting action will perform corresponding to the setting of F0.20(unit's digit).	
F0.10	Range: 0.0~100.0	Default: 40.0
Detection level of Under load	Unit: %	
	It defines the detection level of under load.	
F0.11	Range: 0.0~60.0	Default: 1.0
Detection time of Under load	Unit: Sec	
	It defines the detection time of under load.	
F0.12	Range: 0~2	Default: 0
Motor temperature Sensor type	It is used to select the type of motor temperature sensor.	
	0: No temperature sensor 1: PT100 2: PT1000	
	The signal of the motor temperature sensor needs to be connected to the optional PT100/PT1000 extension card.	
F0.13	Range: 0.0~200.0	Default: 120.0
Motor overheat	Unit: <input type="checkbox"/>	

protection threshold	If the motor temperature(A0.59) exceeds the value of motor overheat protection threshold, the AC drive reports an alarm and performs protecting action according to F0.20(Ten's digit).	
F0.14	Range: 0.0~200.0	Default: 100.0
Motor overheat warning threshold	Unit: □ If the motor temperature exceeds the value of motor overheat warning threshold, the DO terminal allocated with function 18 (Motor overheat warning) will output ON signal.	
F0.15	Range: 0.0~50.0	Default: 20.0
Over-speed detection value	Unit: % This function is valid only when the AC drive runs in the VC mode.	
F0.16	Range: 0.0~60.0	Default: 5.0
Over-speed detection time	Unit: Sec If the over-speed detection time is 0.0s, the over-speed detection function is disabled.	
F0.17	Range: 0.0~50.0	Default: 20.0
Detection value of too large speed deviation	Unit: % This function is valid only when the AC drive runs in the VC mode.	
F0.18	Range: 0.0~60.0	Default: 1.0
Detection time of too large speed deviation	Unit: Sec If Detection time of too large speed deviation is 0.0s, this function is disabled.	
F0.19	Range: 0000~2222	Default: 0000
Fault protection action selection 1	Unit's digit: Power input phase loss 0: Coast to stop 1: Stop according to the stop mode 2: Continue to run Ten's digit: Power output phase loss Same as unit's digit Hundred's digit: Drive overload Same as unit's digit Thousand's digit: Motor overload Same as unit's digit	
F0.20	Range: 0000~2222	Default: 0000
Fault protection action selection 2	Unit's digit: Under load 0: Coast to stop 1: Stop according to the stop mode	

	2: Continue to run at 8% of rated motor frequency and resume to the set frequency if the load recovers Ten's digit: Motor overheat Same as unit's digit in F0.19 Hundred's digit: External Fault Same as unit's digit in F0.19 Thousand's digit: RS485 communication fault Same as unit's digit in F0.19	
F0.21 Fault protection action selection 3	Range: 0000~2222 Unit's digit: Optional card communication fault Same as unit's digit in F0.19 Ten's digit: PID feedback over range Same as unit's digit in F0.19 Hundred's digit: Accumulative power-on time reached Same as unit's digit in F0.19 Thousand's digit: Accumulative running time reached Same as unit's digit in F0.19	Default: 0000
F0.22 Fault protection action selection 4	Range: 0000~2222 Unit's digit: Too large speed deviation Same as unit's digit in F0.19 Ten's digit: Motor over speed Same as unit's digit in F0.19 Hundred's digit: Flux pole detection fault Same as unit's digit in F0.19 Thousand's digit: UVW signal feedback fault Same as unit's digit in F0.19	Default: 0000
F0.23 Fault protection action selection 5	Range: 0000~2222 Unit's digit: Encoder fault 0: Coast to stop 1: Switch over to V/F control, stop according to the stop mode 2: Switch over to V/F control, continue running Ten's digit: User-defined fault 1 Same as unit's digit in F0.19 Hundred's digit: User-defined fault 2 Same as unit's digit in F0.19 Thousand's digit: Interlock warning during multi-pump operation mode Same as unit's digit in F0.19	Default: 0000
F0.24	Range: 0~4	Default: 0

Group F1: Auto Reset

AC drive will auto reset after passing the time of **F1.01** when the fault happened.

If set F1.00 to 0 then the auto reset function invalid.

After the times of auto reset exceeds to **F1.00**, the AC drive will remain in the fault state. The user can press STOP/RST key or X terminal(function 23) to reset the fault and clear the accumulative time of auto reset.

F1.00	Range: 0~30	Default: 0
Fault auto reset times	This defines the maximum times for auto reset. After trying this setting times and the drive still fail to run, the AC drive will remain in the fault state.	
F1.01	Range: 0.1~100.0	Default: 1.0
Time interval of fault auto reset	Unit: Sec	
	It is used to set the waiting time from the alarm of the AC drive to fault auto reset.	
F1.02	Range: 00~11	Default: 00
DO action during fault auto reset	The unit's digit of F1.02 is used to decide whether the DO acts(function 13) during the fault auto reset if the fault auto reset function is selected. The ten's digit of F1.02 is used to decide whether auto restart after the fault is reset.	
	Unit's digit: Fault indication terminals	
	0: No action during fault reset process	
	1: Action during fault reset	
	Ten's digit: Restart after automatic fault reset	
	0: Not auto restart	
	1: having auto restart	



Group H0: System Parameters

H0.00 User password	Range: 0000~9999 Default: 0000 If it is set to any non-zero number, the password protection function is enabled. After a password has been set and taken effect, you must enter the correct password in order to enter the menu. If the entered password is incorrect you cannot view or modify parameters. You can set the user password successfully when you set the same value (none zero) two times to H0.00 . If the user password has been set successfully then the LED will display "P.Set". If you want to clear the user password then set zero the H0.00 two times. If you clear the user password successfully then the LED will display "P.Clr".
H0.01 LED display running parameters 1	Range: 0~65535 Default: 31 In the stop or running state, you can press shift key on the keypad to display monitor parameters. Whether parameters are displayed is determined by the binary bits of values converted from the values of H0.01~H0.03 in the decimal format. Bit0: running freq(1) Bit1: setting freq(2) Bit2: Dc-link voltage(4) Bit3: output current(8) Bit4: output voltage(16) Bit5: output torque(32) Bit6: output power(64) Bit7: AI1 voltage(128) Bit8: AI2 voltage(256) Bit9: AI3 voltage(512) Bit10: X terminal status(1024) Bit11: Y terminal status(2048) Bit12: PLC stage(4096) Bit13: PID setting(8192) Bit14: PID feedback(16384) Bit15: count value(32768)
H0.02 LED display running parameters 2	Range: 0~2047 Default: 0 Bit0: FI input freq(1) Bit6: Auxiliary frequency B display(64) Bit1: Linear speed(2) Bit7: FO output freq(128) Bit2: Load speed(4) Bit8: Feedback freq(256) Bit3: Length value(8) Bit9: motor speed (512) Bit4: Remaining running time(16) Bit10: Multi-Pump Control status words(1024) Bit5: Main frequency A display(32)
H0.03 LED display stop parameters	Range: 0~65535 Default: 3 Bit0: setting freq(1) Bit1: Dc-link voltage(2) Bit2: X terminal status(4) Bit3: Y terminal status(8) Bit4: AI1 voltage(16) Bit5: AI2 voltage(32) Bit6: AI3 voltage(64) Bit7: FI input freq(128) Bit8: PID feedback(256) Bit9: PID feedback(512) Bit10: PLC stage(1024) Bit11: pulse count(2048) Bit12: Length value(4096) Bit13~Bit15: reverse

For example:

- Determine the parameters to be displayed as below:

H0.01(LED display running parameters 1)	H0.02(LED display running parameters 2)
Bit0: running freq(Hz) (1)	Bit0: Fl input freq(kHz) (1)
Bit2: Dc-link voltage(V) (4)	Bit2: load speed (4)
Bit3: output current(A) (8)	
Bit4: output voltage(V) (16)	
Bit6: output power(kW) (64)	

- Set the binary data:

- H0.01 : 0000 0000 0101 1101B
- H0.02 : 0000 0000 0000 0101B

- Convert the binary data to decimal data:

- H0.01 should be set to 93 (1+4+8+16+64 = 93)
- H0.02 should be set to 5 (1+4 = 5)

H0.04^o	Range: 0~4	Default: 0
Parameter initial option	0: No Operation 1: Restore to factory default value, not include motor parameters 2: Restore to factory default value, include motor parameters 3: Parameter upload to keypad 4: Parameter download from keypad	
H0.05	Range: 0~2	Default: 0
Menu display selection	0: Display all parameter. 1: Display user-defined parameters. More details please see the P0 group description. 2: Display non factory setting parameters.	
H0.06	Range: 0~1	Default: 0
Function code lock	0: Disabled All writable parameters can be modified. 1: Enabled Only the parameter of H0.06 can be modified.	
H0.07	Range: 0000~9999	Default: 0000
Accumulative power on time lock password	You can set the locking password successfully when you set the same value (none zero) two times to H0.07 . If the locking password has been set successfully then the LED will display "P.Set". If you want to clear the locking password then set zero the H0.07 two times. If you clear the lock password successfully then the LED will display "P.CLR". If system has been set the locking password, You must input locking password when you want to modify the parameter of Eb.04 or Eb.05 .	

	If system set the lock password and the Accumulative power on time has reached then drive will display system fault(Er51), at this time, you should contact with distributor or technical service.	
H0.08	Range: 0.001~9.999	Default: 0.300
Load speed display coefficient	This parameter is used to adjust the relationship between the running frequency or setting frequency of the AC drive and the load speed.	
	<ul style="list-style-type: none"> ● When drive is running, A0.30 = A0.00*H0.08 ● When drive is running, A0.30 = A0.01*H0.08 ● The fraction points of A0.30 is decided by H0.09. 	
	For example: set A0.00=40.1Hz, H0.08=0.300, 40.1*0.3*10=120 then	
	◇ If H0.09 = 0 then A0.30 = 120	
	◇ If H0.09 = 1 then A0.30 = 12.0	
	◇ If H0.09 = 2 then A0.30 = 1.20	
	◇ If H0.09 = 3 then A0.30 = 0.120	
H0.09	Range: 0~3	Default: 1
Load speed display decimal digits	0: 0 decimal place	1: 1 decimal place
	2: 2 decimal places	3: 3 decimal places
H0.10^o	Range: 0~1	Default: 0
G/L setting	0: G type	
	AC Drive allows 1min/10min overload running at 150% rated current of the heavy load mode.	
	1: L type	
	Drive allows 1min/10min overload running at 110% rated current of the light load mode.	
	If set the parameter of H0.10 to 1, the motor parameters will be changed to match the L type motor.	
	Set parameter H0.04 to 2, the parameter of H0.10 will be restored to default value.	
H0.11^o	Range: 0~2	Default: 0
Fan control	0: Automatic run	
	The fan will run continuously when the AC drive is running.	
	When the AC drive is in stop state,the fan will run if heatsink's temperature higher than 45 ℃, and stop if lower than 40 ℃.	
	1: Run after power on	
	2: Temperature	
	When power on, the fan will just run for one minute,and then change to run according to the heatsink temperature——run if heatsink's temperature higher than 45 ℃, and stop if lower than 40 ℃.	

H0.12	Range: 0~3	Default: 2
Dead zone compensation mode selection	0: No compensation 1: Rectangle compensation 2: Trapezoid compensation 3: Trapezoid at Low frequency and rectangle at high frequency	
H0.13^o	Range: 1~2048	Default: 1024
Dead zone compensation size	It is used to increase or decrease the dead zone compensation based on the default dead compensation value.	
H0.14^o	Range: 1~3640	Default: Model dependent
Angle size when current across zero	It is used to set the angle size when current across zero, the 3640 equivalent to 20 degrees.	
H0.15^o	Range: 0.10~300.00	Default: 50.00
Dead zone compensation filter cut off frequency 1	Unit: Hz To improve the precision of the output voltage, current sample harmonic needs to be filtered. The parameter is used to set the filter frequency when drive in different output frequency.	
H0.16^o	Range: 0.10~300.00	Default: 200.00
Dead zone compensation filter cut off frequency 2	Unit: Hz Please see the following figure.	
H0.17^o	Range: 0.10~ H0.18	Default: 5.00
Dead zone compensation switchover frequency 1	Unit: Hz Please see the following figure.	
H0.18^o	Range: H0.17~b0.00	Default: 50.00
Dead zone compensation switchover frequency 2	Unit: Hz Please see the following figure.	




Figure 6- 59 the relations between running frequency and filter frequency

H0.19^o	Range: 0~11	Default: 0
Optional card selection	Control board have a slot for optional card, when you to inset different board in the slot, you need to set proper value to H0.19 .	
	0: no optional card	
	1: IO1(Y3,T3~T6 of normally open)	
	2: IO2(AI3,Y3, X7~X10)	
	3: IO3(X7~X10,T3~T4 of normally open)	
	4: IO4(PT100, PT1000)	
	5: PG1(ABZ differential type,optional 5V/12V)	
	6: PG2(ABZ OC & Push-pull type,optional 5V/12V/24V)	
	7: COM1(RS485+Modbus RTU,AI3,Y3,X7~X8)	
	8: COM2(Profibus)	
	9: COM3(CANopen)	
	10: COM4(GPRS)	
	11: COM5(Modbus TCP)	
H0.20	Range: 000~999	Default: Model dependent
Product series	AC drive product series, the parameter is read only.	
H0.21	Range: 0.00~99.99	Default: Factory setting
Function firmware version	Function software version of control board, the parameter is read only.	
H0.22	Range: 0.00~99.99	Default: Factory setting
Algorithm firmware version	Algorithm software version of control board, the parameter is read only.	
H0.23	Range: 0.00~99.99	Default: Factory setting
keypad firmware version	Software version of keypad, the parameter is read only.	
H0.24	Range: 0~65535	Default: Factory setting
Product series number higher bits	Read only.	

H0.25	Range: 0~65535	Default: Factory setting
Product series number lower bits	Read only.	
H0.26	Range: 0.00~99.99	Default: Factory setting
OTP version	Read only.	

Group H1: AI/AO Calibration

These parameters of **H1.00~H1.11** are used to calibrate analog inputs, they have been calibrated upon delivery. Generally, you need not perform calibration in the common applications.

The actual voltage indicates the actual input voltage value measured by instruments such as the multi-meter.

The display voltage is the drive calculated value which can be monitored from **A0.11~A0.13**.

During calibration, send two voltage values to each AI terminal, and save the measured values and displayed values to the function codes **H1.00~H1.11**, then the AC drive will automatically perform AI zero offset and gain calibration.

- **H1.00~H1.03** are used to calibrate AI1.
- **H1.04~H1.07** are used to calibrate AI2.
- **H1.08~H1.11** are used to calibrate AI3.
- When drive restore factory default value, **H1.00~H1.11** will be resumed to factory calibrated value.

H1.00	Range: 0.500~4.000	Default: Factory setting
AI1 actual voltage 1	Unit: V	
voltage 1	It is used to input the AI1 measured voltage.	
H1.01	Range: 0.500~4.000	Default: Factory setting
AI1 display voltage 1	Unit: V	
voltage 1	It is used to input the AI1 display voltage(A0.11).	
H1.02	Range: 6.000~9.999	Default: Factory setting
AI1 actual voltage 2	Unit: V	
voltage 2	It is used to input the AI2 measured voltage.	
H1.03	Range: 6.000~9.999	Default: Factory setting
AI1 display voltage 2	Unit: V	
voltage 2	It is used to input the AI1 display voltage(A0.12).	

The parameters used to calibrate AI2 and AI3 as below:

Function Code	Name	Function Code	Name
H1.04	AI2 actual voltage 1	H1.08	AI3 actual voltage 1

H1.05	AI2 display voltage 1	H1.09	AI3 display voltage 1
H1.06	AI2 actual voltage 2	H1.10	AI3 actual voltage 2
H1.07	AI2 display voltage 2	H1.11	AI3 display voltage 2

These parameters of **H1.12~H1.19** are used to calibrate analog outputs, they have been calibrated upon delivery. Generally, you need not perform correction in the common applications.

The actual voltage indicates the actual output voltage value measured by instruments such as the multi-meter.

The display voltage is the drive calculated value, please see these parameters of **A0.14~A0.15**.

During calibration, input two voltage values to each AO terminal, and save the measured values and displayed values to the function codes **H1.12~H1.19**, then the AC drive will calibrate AI zero offset and gain automatically.

- **H1.12~H1.15** are used to calibrate AO1.
- **H1.16~H1.19** are used to calibrate AO2.
- When drive restore factory default value, **H1.12~H1.19** will be resumed to factory calibrated value.

H1.12 Range: 0.500~4.000 Default: Factory setting
AO1 display voltage 1 Unit: V
 It is used to input the AO1 display voltage(**A0.14**).

H1.13 Range: 0.500~4.000 Default: Factory setting
AO1 actual voltage 1 Unit: V
 It is used to input the AO1 measured voltage.

H1.14 Range: 6.000~9.999 Default: Factory setting
AO1 display voltage 2 Unit: V
 It is used to input the AO1 display voltage(**A0.15**).

H1.15 Range: 6.000~9.999 Default: Factory setting
AO1 actual voltage 2 Unit: V
 It is used to input the AO2 measured voltage.

The parameters used to calibrate AO2 as below:

Function Code	Name
H1.16	AO 2display voltage 1
H1.17	AO2 actual voltage 1
H1.18	AO2 display voltage 2
H1.19	AO2 actual voltage 2

Group L0: Communication Setting

L0.00	Range: 0~4	Default: 1
Baud rate	Set the baud rate for RS485 communication.	
	0: 4800 bits/s	
	1: 9600 bits/s	
	2: 19200 bits/s	
	3: 38400 bits/s	
	4: 57600 bits/s	
L0.01	Range: 0~3	Default: 1
Data format	Set the data format for RS485 communication.	
	0: 8 data bit, no check, 1 stop bit<8,N,1>	
	1: 8 data bit, no check, 2 stop bit <8,N,2>	
	2: 8 data bit, even parity check, 1 stop bit<8,E,1>	
	3: 8 data bit, odd parity check, 1 stop bit <8,O,1>	
L0.02	Range: 1~247	Default: 1
Slave address	Set the drive communication address.	
	The slave address of zero is broadcast address, the address of 1~247 are usable.	
L0.03	Range: 0~20	Default: 2
Response delay	Unit: mSec	
	The interval from receiving data to replying data to the master.	
L0.04	Range: 0.0~60.0	Default: 0.0
Communication timeout detection	Unit: Sec	
	Set L0.04 to zero, the communication timeout function is invalid.	
	Set L0.04 to non-zero, if the interval time between twice communication exceed L0.04 , the AC drive will display "Er31"(RS485 communication fault)	

Group L1: Point-point Communication

L1.00^o	Range: 0~1 Default: 1	Default: 1
Master and slave selection	0: Master Drive send data to other external device as master. 1: Slave Drive receive data from other external device as slave. The received data is valid only when the conditions listed below are satisfied. 1) Command source is communication 3) L1.02 = 1 2) Reference source is communication 4) Receive broadcast frame	
L1.01^o	Range: 0~3 Default: 0	Default: 0
Send data selection of master	It is used to set send date type of master in P2P operation. 0: Torque reference, 100% corresponds to motor rated torque(b0.00). 1: Running frequency, 100% corresponds to max frequency(b0.00). 2: Setting frequency, 100% corresponds to max frequency(b0.00). 3: Feedback frequency, 100% corresponds to max frequency(b0.00).	
L1.02^o	Range: 0~1 Default: 0	Default: 0
Point-point communication enable	0: Disable 1: Enable	
L1.03^o	Range: 00~11 Default: 00	Default: 00
Usage of data received by slave	Unit's digit: Data usage of slave 0: As torque reference 1: As frequency reference Ten's digit: Whether to follow the master commands 0: No 1: Yes	
L1.04	Range: -9.99~10.00 Default: 1.00	Default: 1.00
Gain of received data	It is used to set the Point-to-point receive data gain for slave.	
L1.05	Range: -99.9~100.0 Default: 0.0	Default: 0.0
Zero offset of received data	Unit: % It is used to set the Point-to-point receive data offset for slave.	

The parameter of **L1.04** and **L1.05** are used to calibrate the slave received data.

If **L1.04** is expressed by character 'a' and the **L1.05** is expressed by character 'b', the received data is expressed by character 'x', the result used by slave is expressed by character 'y', then $y = a * x + b$, the range of y is -100.00%~100.00%.

Group L2: Encoder Setting

If drive use motor 1 to do VC control then set the parameters of **L2.00~L2.08**; If drive use motor 2 to do VC control then set the parameters of **L2.09~L2.17**.

The function of **L2.00~L2.08** are same as **L2.09~L2.17**.

L2.00^o	Range: 0~4	Default: 0
Encoder type	0: ABZ incremental encoder 1: UVW incremental encoder 2: Rotational resolver encoder 3: Sine and cosine Encoder 4: Wire-saving UVW Encoder	
L2.01^o	Range: 1~65535	Default: 1024
Encoder pulse per revolution	It is used to set the pulse number of per revolution, the parameter is valid only for ABZ incremental encoder and UVW incremental encoder. You need to set the parameter properly, otherwise the motor will run abnormally when drive running in VC control.	
L2.02^o	Range: 0~1	Default: 0
A/B phase sequence of ABZ incremental Encoder	0: Positive 1: Negative This parameter is valid only for ABZ incremental encoder(L2.00 = 0) and is used to set the A/B phase sequence of the ABZ incremental encoder. It is valid for both asynchronous motor and synchronous motor. The A/B phase sequence can be obtained through "Asynchronous motor complete auto-tuning" or "Synchronous motor no-load auto-tuning".	
L2.03^o	Range: 0.0~359.9	Default: 0.0
Z pulse initial angle of ABZ incremental Encoder	Unit: deg It is used to set the Z pulse initial angle of ABZ incremental encoder.	
L2.04^o	Range: 0.0~359.9	Default: 0.0
Encoder installation angle	Unit: deg It is used to set the encoder installation angle. This parameter is applicable only to synchronous motor. It is valid for ABZ incremental encoder, UVW incremental encoder, resolver and wire-saving UVW encoder, but invalid for SIN/COS encoder.	
L2.05^o	Range: 0~1	Default: 0
UVW phase sequence of UVW Encoder	0: Positive 1: Negative	

L2.06^o	Range: 0.0~359.9	Default: 0.0
UVW Encoder angle offset	Unit: deg The parameter is used to set the angle offset of UVW encoder.	
L2.07^o	Range: 1~65535	Default: 1
Poles of resolver	The parameter is used to set the poles of resolver.	
L2.08^o	Range: 0.0~10.0	Default: 0.0
Encoder wire-break fault detection time	Unit: Sec 0.0: The encoder wire-break detection function is disabled. >0.0: The encoder wire-break detection function is enabled. If drive detect the PG wire is break and the maintain time exceeds the set value of L2.08 then the fault of encoder fault(Er45) is displayed.	
L2.09^o	Range: 0~4	Default: 0
Motor 2 Encoder type	0: ABZ incremental encoder 1: UVW incremental encoder 2: Rotational resolver encoder 3: Sine and cosine Encoder 4:Wire-saving UVW Encoder	
L2.10^o	Range: 1~65535	Default: 1024
Motor 2 Encoder pulse per revolution	It is used to set the encoder installation angle for motor 2.	
L2.11^o	Range: 0~1	Default: 0
Motor 2 A/B phase sequence of ABC incremental Encoder	0: Positive 1: Negative	
L2.12^o	Range: 0.0~359.9	Default: 0.0
Motor 2 Z pulse initial angle of ABZ incremental Encoder	Unit: deg It is used to set the Z pulse initial angle of ABZ incremental encoder for motor 2.	
L2.13^o	Range: 0.0~359.9	Default: 0.0
Motor 2 Encoder installation angle	Unit: deg It is used to set the encoder installation angle for motor 2.	

L2.14^o	Range: 0~1	Default: 0
Motor 2 UVW phase sequence of UVW Encoder	0: Positive 1: Negative	
L2.15^o	Range: 0.0~359.9	Default: 0.0
Motor 2 UVW Encoder angle offset	Unit: deg The parameter is used to set the angle offset of UVW encoder for motor 2.	
L2.16^o	Range: 1~65535	Default: 1
Motor 2 poles of resolver	The parameter is used to set the poles of resolver for motor 2.	
L2.17^o	Range: 0.0~10.0	Default: 0.0
Motor 2 Encoder wire-break fault detection time	Unit: Sec 0.0: The encoder wire-break detection function is disabled. >0.0: The encoder wire-break detection function is enabled.	

Group P0: User-defined Parameters

In user-defined parameters Group, users can add some parameters to **P0** group for convenient view and set these parameters.

H0.05 = 1 Only display parameters that mapped by P0 group.

For example:

Set the value for P0 group parameters as below:

- H0.05 = 0(Display all parameters)
- P0.00 = b0.01
- P0.01 = b2.01
- P0.02 = L1.04
- H0.05 = 1(Only display user-defined parameters)
- Press Prg key return to Level 0
- Press Prg key again, you can use knob on the keypad view the three parameters as below:
 - b0.01
 - b2.01
 - L1.04

P0.00	Range: A0.00~P1.15	Default: A0.00
User-defined Parameter 0	It is used to provide convenient for view and modify parameters.	

The User-defined Parameters of 1~14 same as the User-defined Parameter 0(**P0.00**), but they have different default value.

Code	Name	Default	Code	Name	Default
P0.01	User-defined Parameter 1	A0.01	P0.08	User-defined Parameter 8	A0.08
P0.02	User-defined Parameter 2	A0.02	P0.09	User-defined Parameter 9	A0.09
P0.03	User-defined Parameter 3	A0.03	P0.10	User-defined Parameter 10	A0.10
P0.04	User-defined Parameter 4	A0.04	P0.11	User-defined Parameter 11	A0.11
P0.05	User-defined Parameter 5	A0.05	P0.12	User-defined Parameter 12	A0.12
P0.06	User-defined Parameter 6	A0.06	P0.13	User-defined Parameter 13	A0.13
P0.07	User-defined Parameter 7	A0.07	P0.14	User-defined Parameter 14	A0.14

P0.15 Range: **H0.05~H0.05** Default: **H0.05**
User-defined Parameter 15 The parameter is map to **H0.05** always, it is used to modify the display mode for keypad.

Group P1: Debug Parameters

These parameters are used to debug for factory, users don't need to modify them generally.

P1.00 Range: 0~100 Default: depends model
Debug parameter 0 It is used to debug for factory, users don't need to modify them generally.

The debug parameters of 1~15 same as the debug parameter 0(**P1.00**). P1.08 Set the output frequency point of the converter, less than the set frequency has no output, when set to 0, the zero frequency converter has output.

Code	Name
P1.01	Debug parameter 1
P1.02	Debug parameter 2
P1.03	Debug parameter 3
P1.04	Debug parameter 4
P1.05	Debug parameter 5
P1.06	Debug parameter 6
P1.07	Debug parameter 7
P1.08	Output choice,
P1.09	Debug parameter 9
P1.10	Debug parameter 10
P1.11	Debug parameter 11
P1.12	Debug parameter 12
P1.13	Debug parameter 13
P1.14	Debug parameter 14
P1.15	Debug parameter 15

Chapter 7 Fault Detection and Diagnostics

7.1 Faults and Solutions

If a fault or alarm happened, keypad will display the fault or alarm at once. Fault displays “Er”+fault code and the alarm displays “AL”+fault code. You can use the STOP/RST key or X terminal reset function to reset the fault or alarm.

These parameters of **A1.00**~**A1.35** are used to record the fault code and drive status of the recent three faults of the drive.

Table 7- 1 LED Fault and display

Display	Fault Name	Possible Causes	Solutions
Er01	Hardware over voltage during acceleration	The acceleration time is too short.	Increase the acceleration time.
		The inertia of the load is too large.	Enable dynamic brake.
		The output circuit is short circuited.	Check motor wiring and output to ground impedance.
		The input voltage is too high.	Adjust the voltage to normal range.
Er02	Hardware over voltage during deceleration	The deceleration time is too short.	Increase the deceleration time.
		The inertia of the load is too large.	Use dynamic brake.
		The output circuit is short circuited.	Check motor wiring and output to ground impedance.
		The input voltage is too high.	Adjust the voltage to normal range.
		the regulator parameters are improper In SVC control mode.	Set regulator parameters properly.
Er03	Hardware over voltage during constant speed	The motor parameters are improper.	Set regulator parameters properly.
		The load fluctuation is too big	Check the load.
		The input voltage is too high.	Adjust the voltage to normal range.
		The output circuit is short circuited.	Check motor wiring and output to ground impedance.
		the regulator parameters are improper In SVC control mode.	Set regulator parameters properly.
Er04	Software over voltage during acceleration	Motor to ground is short circuit.	Check motor wiring.
		The input voltage is too high.	Adjust the voltage to normal range.
		Start again quickly when motor in high speed rotating.	Start again when motor is stop.

Display	Fault Name	Possible Causes	Solutions
Er05	Software over voltage during deceleration	Motor to ground is short circuit.	Check motor wiring.
		The inertia of the load is too large.	Select the dynamic brake resistor properly.
Er06	Software over voltage during constant speed	Motor to ground is short circuit.	Check motor wiring.
		The input voltage is too high.	Adjust the voltage to normal range.
		The inertia of the load is too large.	Select the dynamic brake resistor properly.
Er07	Under voltage	The input voltage is too low.	Adjust the voltage to normal range.
		Internal power supply of drive is abnormal.	Contact with technical service.
Er08	Hardware over current during acceleration	The input voltage is too low.	Adjust the voltage to normal range.
Er09	Hardware over current during deceleration	The input voltage is too low.	Adjust the voltage to normal range.
		The inertia of the load is too large.	Select the dynamic brake resistor properly.
Er10	Hardware over current during constant speed	Load change suddenly when drive is running.	Lower the load mutation frequency and mutation range.
		The input voltage is too low.	Adjust the voltage to normal range.
Er11	Software over current during acceleration	The motor parameters are improper.	Set regulator parameters properly.
		Startup frequency is too high.	Decrease startup frequency.
		The deceleration time is too short.	Increase the deceleration time.
		The selected drive power grade is too small.	Select drive power grade properly.
Er12	Software over current during deceleration	The motor parameters are improper.	Set regulator parameters properly.
		The deceleration time is too short.	Increase the deceleration time.
		The selected drive power grade is too small.	Select drive power grade properly.
Er13	Software over current during constant speed	The motor parameters are improper.	Set regulator parameters properly.
		The selected drive power grade is too small.	Select drive power grade properly.

Display	Fault Name	Possible Causes	Solutions
Er14	IGBT saturation trip during acceleration	Motor to ground is short circuit.	Check motor wiring.
		The acceleration time is too short.	Increase the acceleration time.
		The fan is blocked or damaged.	Clean the air filter or Replace the damaged fan.
		The AC drive module is abnormal.	Contact with technical service.
		Switch power supply is damaged.	Contact with technical service.
		The control board is abnormal.	Contact with technical service.
		The ambient temperature is too high.	Cool down environment.
Er15	IGBT saturation trip during deceleration	The acceleration time is too short.	Increase the acceleration time.
		Motor to ground is short circuit.	Check motor wiring.
		The fan is blocked or damaged.	Clean the air filter or Replace the damaged fan.
		The AC drive module is abnormal.	Contact with technical service.
		Switch power supply is damaged.	Contact with technical service.
		The control board is abnormal.	Contact with technical service.
		The ambient temperature is too high.	Cool down environment.
Er16	IGBT saturation trip during constant speed	The input voltage is too low.	Adjust the voltage to normal range.
		Motor to ground is short circuit.	Check motor wiring.
		The fan is blocked or damaged.	Clean the air filter or Replace the damaged fan.
		The AC drive module is abnormal.	Contact with technical service.
		Switch power supply is damaged.	Contact with technical service.
		The control board is abnormal.	Contact with technical service.
		The ambient temperature is too high.	Cool down environment.
		The control board connection is loose.	Re-plug the connection line which on control board.

Display	Fault Name	Possible Causes	Solutions
Er17	Heatsink of rectifier overheat	The fan is blocked or damaged.	Clean the air filter or Replace the damaged fan.
		The ambient temperature is too high.	Cool down environment.
		The output phase to phase is short. The output circuited is short to the ground.	Rematch cable
		The cable connecting the control board and heatsink sensor is abnormal.	Check the cable connecting the control board and heatsink sensor.
		The Auxiliary power is damage or the drive power is under voltage	Contact with technical service.
		Drive overcurrent instantaneously.	Please see the overcurrent solutions.
Er18	Heatsink of inverter overheat	Same as Er17	Same as Er17
Er/AL19	Input phase loss	The input voltage of R, S and T have some losses.	Check the input voltage and the wiring.
Er/AL20	Output phase loss	The cable connecting the drive and the motor is abnormal.	Eliminate external faults.
		The output current of U, V, W are in unbalance status.	Check motor and cable.
		The parameters value about the SVC control are improper.	Set parameters value about the SVC control properly.
Er21	Soft startup relay fault	The contactor is abnormal.	Contact with technical service.
		The contactor feedback circuit is abnormal.	
		Buffer resistor is damaged.	
		Switch power supply is damaged.	Check the power supply.
The power supply is abnormal.			
Er22	Current detection fault	The control board is faulty.	Contact with technical service.
		Switch power supply is damaged.	
		The HALL device is abnormal.	
		Leakage current is too large.	

Display	Fault Name	Possible Causes	Solutions
Er23	CBC fault	The load is too heavy.	Reduce the load
		Motor is stalling.	Check the motor and mechanical condition.
		The selected drive power grade is too small.	Select drive power grade properly.
Er/AL24	VFD overload	The input voltage is too low.	Adjust the voltage to normal range.
		Start again quickly when motor in high speed rotating.	Start again when motor is stop.
		The load is too heavy and the holding time is too long.	Decrease the overload time and decrease the load.
		The acceleration/deceleration time is too short.	Increase the acceleration/deceleration time.
		The V/F curve ratio is too high when drive in V/F control.	Set the parameters of V/F curve and torque boost properly.
		The selected drive power grade is too small.	Select drive power grade properly.
Er/AL25	Motor overload	The input voltage is too low.	Adjust the voltage to normal range.
		The DC brake current is set to high.	Decrease the value of DC brake current.
		Motor is stalling or load changed too large.	Check the load and set the parameter of torque boost properly.
		The drive power grade is not matched with motor power grade.	Select the suitable motor.
		The V/F curve ratio is too high when drive in V/F control.	Set the parameters of V/F curve and torque boost properly.
		The common motor running with lower speed, heavy load and long time.	Change a Frequency conversion motor or Increase the aim frequency.
		Er/AL26	Motor under load
Set the parameter of F0.10 properly.			

Display	Fault Name	Possible Causes	Solutions
Er/AL27	Motor overheat	The cabling of the temperature sensor becomes loose.	Check the temperature sensor cabling and eliminate the cabling fault.
		The motor temperature is too high.	Lower the carrier frequency or adopt other heat radiation measures.
Er28	Motor short circuit to ground fault	The motor is short circuited to the ground.	Replace the cable or motor.
Er/AL29	External fault	External fault signal is input via DI.	Check the DI input signal.
Er30	Keypad communication fault	The communication of keypad with drive is abnormal.	Check the line connecting the control board and the keypad.
Er/AL31	RS485 communication fault	The communication of RS485 field with drive is abnormal.	Check the line and the communication device.
Er/AL32	Optional card communication fault	The communication of optional card with external device is abnormal.	Check the line and the optional card.
Er33	Optional card connection fault	The communication of optional card with control board is abnormal.	Check the line and the optional card.
Er34	Auto tune fault	The cable connection of the motor are abnormal.	Check the cable connecting the drive and the motor.
		Tune when motor is rotating.	Tune when motor is stops.
		The motor parameters are not set according to the nameplate.	Set the motor parameters according to the nameplate properly.
Er/AL35	PID feedback over range	The PID feedback is higher than the setting of E5.33 or lower than the setting of E5.34.	Check the PID feedback signal or set E5.33 and E5.34 to a proper value.
		The parameters of PID are set incorrectly.	Set the PID parameters properly.
Er36	EEPROM R/W fault	EEPROM is damage.	Contact with technical service.
Er37	Parameter setting fault	Parameter R/W fault.	Press STOP/RST to reset the drive or Contact with technical service.

Display	Fault Name	Possible Causes	Solutions
Er/AL38	Accumulative power-on time reached	The accumulative power-on time reaches the setting value.	Clear the record through the parameter initialization function.
Er/AL39	Accumulative running time reached	The accumulative running time reaches the setting value.	Clear the record through the parameter initialization function.
Er40	Motor switchover during running status	Change the selection of the motor via terminal during running of the drive.	Perform motor switchover after the drive stops.
Er/AL41	Too large speed deviation	The encoder parameters are set incorrectly.	Set the encoder parameters properly.
		The motor auto-tuning is not performed.	Perform the motor auto-tuning.
		The motor over speed check parameters are set incorrectly.	Set the motor over speed check parameters correctly based on the actual situation.
Er/AL42	Motor over speed	The encoder parameters are set incorrectly.	Set the encoder parameters properly.
		The motor auto-tuning is not performed.	Perform the motor auto-tuning.
		The motor over speed check parameters are set incorrectly.	Set the motor over speed check parameters correctly based on the actual situation.
Er/AL43	Flux pole detection fault	The encoder signal is incorrectly.	Check encoder status.
Er/AL44	UVW signal feedback fault	The encoder signal is incorrectly.	Check encoder status.
Er/AL45	Encoder fault	The encoder type is incorrect.	Set the encoder type correctly based on the actual situation.
		The cable connection of the encoder is incorrect.	Eliminate external faults.
		The encoder is damaged.	Replace the damaged encoder.
		The PG card is abnormal.	Replace the abnormal PG card.

Display	Fault Name	Possible Causes	Solutions
Er/AL46	User-defined fault 1	The user-defined fault 1 signal is input via DI.	Reset the operation.
		User-defined fault 1 signal is input via virtual I/O.	
Er/AL47	User-defined fault 2	The user-defined fault 2 signal is input via DI.	Reset the operation.
		User-defined fault 2 signal is input via virtual I/O.	
AL48	Motor in current stall status	Motor is in current stall control.	Check whether the load current is exceed the overcurrent stall protective current.
AL49	Motor in voltage stall status	Motor is in voltage stall control.	Check whether the dc-link is exceed the overvoltage stall protective current.
AL50	Motor in frequency drop status as dc-link voltage drop	The dc-link is under voltage and Motor is in frequency drop.	Check whether the dc-link is lower than the under-voltage drop frequency point.
Er51	System fault	Trial expired.	Contact with factory.
Er/AL52	Interlock warning during multi-pump operation mode	The multi-pump control system occur interlock.	Check the logic of multi-pump control.
Er53	Soft startup resistor overload	The output circuit to ground is short.	Check the output circuit.
AL54	Sleep status	The drive is sleeping.	Check whether the drive should in sleeping.

7.2 Common Faults and Solutions

You may come across the following faults during the use of the drive. Refer to the following methods for simple fault analysis.

There is no display at power-on:

- 1) Check whether the drive input power voltage is consistent with drive rated voltage.
- 2) Check whether the Three phase bridge rectifier is normal.

Power air switch tripping at power-on

- 1) Check whether the motor or the motor cable is short circuited to the ground.
- 2) Check whether rectifier bridge is damage.

Motor not rotate when drive is running.

- 1) Check whether the output current of U, V, W are in unbalance status.
- 2) Check whether the motor is damage or stalling.
- 3) Check whether the motor parameters set proper value.

The display is normally at power-on but the power air switch tripping when the drive run.

- 1) Check whether the output module is short circuited to the ground.
- 2) Check whether the motor is short circuited to the ground.
- 3) If the power air switch tripped occasionally and between the motor with drive have long distance, then add AC reactor please.

Note:

- ❖ Please deal with the fault carefully. You should confirm the fault reasons and deal with the fault according to solutions above.
 - ❖ If you can't solve the fault, please don't power on.
 - ❖ If the device damaged or some problem you can't solve, please contact with distributor or technical service.
-

Chapter 8 Communication Protocol

The AC drive provides RS485 communication interface, for the master-slave communication with international standard MODBUS-RTU protocol. The user can through the PC/PLC PC to read and modify the function code, set the control command and the reference frequency converter, working status monitoring and fault information, to realize the centralized control.

8.1 Protocol Comment

The MODBUS protocol of the AC drive defines the transmission frame content and format to be used, including: host polling and broadcast frames, slave response frame format; the host frame includes: the slave address (or broadcast address), the command code, data and CRC check. Slave response frame is the same. If the error occurs in the received frame from the host, or can't complete the host required action, the slave machine will organize a fault frame as a response to feedback to the host.

8.2 Networking Mode

There are two kinds of configuration mode of the AC drive: single host / multi slave mode and single host / single slave mode.

8.3 Bus Structure

1. Interface mode

RS485 interface, asynchronous, half duplex.

Default data formats: 8-N-1 (8 data bits, no parity, 1 stop bit), 9600bps.

2. Communication mode

From the set range is 1 ~ 247. 0, for broadcast communication.

Each network have unique slave address, this is the foundation and guarantee of MODBUS communication.

The frequency converter act as slave, point to point communication master-slave, host using the broadcast address to send frames, no response from the slave.

From the slave's keypad or the means of communication, can be provided to change the address, baud rate and data format.

8.4 Protocol Format

The MODBUS protocol of the AC drive is RTU mode.

Figure 8-1 shows the frame format of RTU.




Figure 8- 1 RTU frame format

In RTU mode, each character format is as follows: 8 bits, 8 bits in each frame domain, containing two of sixteen hexadecimal characters (0 ~ 9, A ~ F); in order to distinguish clearly, the following sixteen hexadecimal data end with "H".

In RTU mode, the idle time between frames to follow the MODBUS internal agreement. MODBUS internal least frame agreed between idle as follows:

- (1) The frame head and frame end is defined through the bus idle time is equal to or greater than 3.5 bytes of time.
- (2) The frame after the start, the interval between characters must be less than 1.5 bytes of time, otherwise the new to receive characters will be considered as a new frame.
- (3) Using CRC check mode, the high 8 bits and 8 bits low must swap before send.
- (4) At least 3.5 bytes of free time to maintain between frames.

The standard structure of RTU frame:

Table 8- 1 RTU frame format

START (Frame head)	T1-T2-T3-T4 (3.5 chars space time)
ADDR (slave address)	1~247 (0 is broadcast address)
CMD (function code)	03H: read register 06H: write register
(DATA) DATA (0) ... DATA (N-1)	2*N bytes data, this is the main comment of frame.
CRC LOW	CRC (16bits)
CRC HIGH	
END (Frame end)	T1-T2-T3-T4 (3.5 chars space time)

8.5 Functions of Protocol

The main function of the MODBUS protocol is to read, write the AC drive function code parameters and non functional code parameters, different parameters determine different operation request. The AC drive MODBUS protocol support command code as shown in table 2.

Table 8- 2 Function code illustration

Function code (HEX)	Description
03H	Read AC drive function code or status word
06H	Change AC drive function code or control word

The AC drive function code parameters and non functional code parameters are mapped to Modbus read write registers. The read and write attribute and the range of function code parameters (maximum, minimum) observe the instructions of AC drive using manual. Non functional code parameters including the run command, running state, run / stop parameters and fault information.

Communication Address of Function Parameters of the AC Drive

- The converter function code parameters, control parameters and monitor parameters are mapped to Modbus read write registers.
- The function code parameter attribute and range can reference the user manual instructions follow the frequency converter.
- The group code of the function code mapped to high byte of Modbus register, and the internal group index mapped to low byte of Modbus register.
- The control parameters and monitor parameters are also function code group.

Function code group number and the mapping register address high byte correspondence are listed in the following table:

Table 8- 3 Group code and register's high byte convert table

Function code group	Register ID high	Function code group	Register ID high
A0	0x10	E4	0x27
A1	0x11	E5	0x28
b0	0x12	E6	0x29
b1	0x13	E7	0x2A
b2	0x14	E8	0x2B
C0	0x15	E9	0x2C
C1	0x16	EA	0x2D
C2	0x17	EB	0x2E
C3	0x18	F0	0x2F
C4	0x19	F1	0x30
C5	0x1A	H0	0x31
C6	0x1B	H1	0x32
d0	0x1C	L0	0x33
d1	0x1D	L1	0x34
d2	0x1E	L2	0x35
d3	0x1F	L3	0x36
d4	0x20	L4	0x37
d5	0x21	L5	0x38
d6	0x22	L6	0x39
E0	0x23	L7	0x3A
E1	0x24	P0	0x3B
E2	0x25	P1	0x3C
E3	0x26	P2	0x3D

Example:

The function code b0.11 reference to Modbus register ID 0x120B, and E0.03 reference to Modbus register 0x2303.

Note:

Under communication mode, user can change password use function code 06H to change parameter H0.00. If the response value is 8888H, indicate the password set successfully.

Communication Address of Non-Function Parameters of the AC Drive

1.Communication set value (Wirte-only)

Communication set value includes frequency source,upper source of torque,PID source,PID feedback etc.

Communication set value address is 6400H. The upper machine set the address value, the data range is -10000 ~ 10000, correspond to the given value for -100.00% ~ 100%.

2.Run command (Wirte-only)

Run command address	Usage
6401H (b0.11=2)	0001: Run forward
	0002: Run reverse
	0003: JOG forward
	0004: JOG reverse
	0005: Coasting stop
	0006: Deceleration stop
	0007: Fault reset

3.Run status (Read-only)

Run status address	Usage
6402H	0001: Run forward
	0002: Run reverse
	0003: Stop

4.DO output control (Wirte-only)

Do output address	Usage
6403H	BIT0: Y1
	BIT1: Y2
	BIT2: Y3
	BIT3: T1
	BIT4: T2
	BIT5: T3
	BIT6: T4
	BIT7: T5
	BIT8: T6

5.Pulse output control: (Write-only)

Command address	Command comment
6404H	0x0~0x7FFF corresponding to 0%~100%

6.Analog output AO1 control: (Write-only)

Command address	Command comment
6405H	0x0~0x7FFF corresponding to 0%~100%

7.Analog output AO2 control: (Write-only)

Command address	Command comment
6406H	0x0~0x7FFF corresponding to 0%~100%

8.AC drive fault description (Read-only)

AC drive error address	AC drive error info
6407H	0: No error
	1: Hardware accelerate over voltage
	2: Hardware decelerate over voltage
	3: Hardware constant speed over voltage
	4: Software accelerate over voltage
	5: Software decelerate over voltage
	6: Software constant speed over voltage
	7: Under voltage
	8: Hardware accelerate over current
	9: Hardware decelerate over current
	10: Hardware constant speed over current
	11: Software accelerate over current
	12: Software decelerate over current
	13: Software constant speed over current
	14: Module accelerate error
	15: Module decelerate error
	16: Module constant speed error
	17: Rectifier bridge over temperature
	18: Inverter bridge over temperature
19: Input osting - phase	

AC drive error address	AC drive error info
6407H	20: Output oosting-phase
	21: Contactor error
	22: Current check error
	23: The cycle by cycle current limiting error
	24: AC drive overload
	25: Motor overload
	26: Motor offload
	27: Motor over temperature
	28: Short circuit to ground of motor
	29: External error
	30: Keypad communication error
	31: RS485 communication error
	32: Optional card communication error
	33: Optional card connection error
	34: Motor self-tuning error
	35: PID feedback out of range
	36: EEPROM read/write error
	37: Parameter set error
	38: Accumulative power up time error
	39: Accumulative run time error
	40: Switch motor error when run
	41: Speed offset too large
	42: Motor over speed
	43: Magnetic pole position check error
	44: UVW signal feedback error
	45: Encoder error
	46: Self define error 1
	47: Self define error 2
	48: Motor over current speed loss
	49: Motor over voltage speed loss
50: Motor under voltage frequency reduction	
51: System error	
52: Multi-pump interlock warning	
53: Buffer resistance overload	
54: Dormancy warning	

Communication Command Code

1. Communication read function code: 03H

Function code: 03H, read N word (Max value is 50)

Example: The slave address is 01H, start address is 2302H, read number is 2 word, the structure of the frame as following:

Master request frame:

ADR (Slave address)	01 H
CMD (Function code)	03 H
Register ID high	23 H
Register ID low	02 H
Register number high	00 H
Register number low	02 H
CRC low	6E H
CRC high	4F H

Slave response frame:

ADR (Slave address)	01 H
CMD (Function code)	03 H
Byte number	04 H
Register 0x2302H comment high byte	00 H
Register 0x2302H comment low byte	00 H
Register 0x2303H comment high byte	00 H
Register 0x2303H comment low byte	01 H
CRC low byte	3B H
CRC high byte	F3 H

Error response frame:

ADR (Slave address)	01 H
Error code(CMD+0x80)	83 H
Exception code	02 H: Invalid address 03 H: Read number over range 04 H: Parameter can't be read 05 H: Frame length error
CRC low byte	LCRC H
CRC high byte	HCRC H

2. Communication write command: 06H or 44H

Function code: 06H or 44H, write one word, the function code 44H and 06H has the same structure, but 44H doesn't change the EEPROM value.

Example: Set the value to register ID 2302H, the slave address is 01H, the frame structure shows as following:

Master request frame:

ADR (Slave address)	01 H
CMD (Function code)	06 H
Register ID high byte	23 H
Register ID low byte	02 H
Register comment high byte	13 H
Register comment low byte	88 H
CRC low byte	2E H
CRC high byte	D8 H

Slave response frame:

ADR (Slave address)	01 H
CMD (Function code)	06 H
Register ID high byte	23 H
Register ID low byte	02 H
Register comment high byte	13 H
Register comment low byte	88 H
CRC low byte	2E H
CRC high byte	D8 H

Error response frame:

ADR (Slave address)	01 H
Error code (CMD+0x80)	86 H
Exception code	02 H: Invalid address 03 H: Read number over range 04 H: Parameter can't be write or write value out of range 05 H: Length Error of the Data Frame
CRC low byte	LCRC H
CRC high byte	HCRC H

3. Communication error code

If there is a communication error occurs, the master should response an error code, the error code value is "request function code " + 0x80.

4. Communication error function code

When there is an error frame comes, the slave will give an exception code to indicate the error type. Such as error function code, or error value etc.

Error code	Function
01H	Invalid function code
02H	Invalid address
03H	Operate number over range
04H	Operation error
05H	Frame length error

5. CRC check

The RTU frame include a CRC check field. CRC used to check the correctness of the whole frame. It include two bytes filed. The master calculates the CRC and padding to the end of the frame, and the slave re-calculates it again. If the twice result isn't the same, it indicates a transmit error.

We adapt an international standard CRC check method, when user program the CRC algorithm, can reference the following C procedure.

```
unsigned int crc_check(Uint16 len)
{
    unsigned int crc_value=0xffff;
    unsigned int i,j;

    for(j=0;j<len;j++)
    {
        crc_value^=data_buf[j];
        for(i=0;i<8;i++)
        {
            if(crc_value &0x0001)
                crc_value=(crc_value>>1)^0xa001;
            else
                crc_value=crc_value>>1;
        }
    }
    return (crc_value);
}
```

Chapter 9 Maintenance

9.1 Routine Repair and Maintenance

It is necessary to carry out the maintenance for avoiding the fault of the AC drive, keeping devices running normally and prolonging the service life of the AC drive. The content of maintenance is as the following table:

Routine Maintenance	Periodic Inspection	Checking objects	Content	Requirements
√		Run monitor parameters	Output current	Within the rated value
			Output voltage	Within the rated value
			Temperature	The temperature rise does not exceed 35 °C.
√		Cooling and heat dissipation	Installation environment	The air duct is smooth and well-ventilated.
			Fans inside the AC drive	Normal operation and no abnormal noise.
√		Motor	Generate heat	Generating heat is normal.
			Noise	The noise is uniform.
	√	AC drive	Generate heat due to vibration	Stable vibration and rational temperature
			Noise	Normal noise
			Lead and terminals	Fixed screws without any sign of looseness.
√		Running environment	Temperature and humidity	-10°C~+40°C 40°C~50°C (Use by derating or forced cooling)
			Dust and dripping from water machine.	No dripping trace and no dust.
			Gas	No peculiar smell

Recommended instruments: electric voltage meter for input voltage; clamp ampere meter for current; rectifier voltage meter for output voltage.

9.2 The Inspection and Replacement of Vulnerable Components

Abrasion or degradation of performance will occur due to the long-time usage of components inside the AC drive. To ensure the stable and reliable operation of the AC drive, predictive maintenance of the AC drive must be employed periodically, if required, related parts must be replaced.

(1) Cooling Fans

The service life of cooling fans inside the AC drive is about 2 to 3 years. When bearings of cooling fans are abraded or fan blades are broken, replacement of fans must be considered.

(2) Electrolytic Capacitors

Under normal conditions, Electrolytic capacitors of the AC drive must be replaced once for every 4 to 5 years.

9.3 Storage and Warranty Agreement

Storage

For occasions which have high temperature,moisture,dust or metallic dust, the AC drive can not be stored. During storage, the ventilation must be guaranteed. The degradation of electrolytic capacitors will occur for long-time storage . The AC drive must be energized once for every two years and each lasting time must be no less than one hour. The input voltage must be increased slowly to the rated value by using the regulator.

Warranty Agreement

1. Free warranty only applies to the AC drive itself.
 2. Reasonable repair expenses will be charged for the damages due to following causes:
 - ✓ Improper usage or repairing the AC drive without permission.
 - ✓ Fire,flood,abnormal voltage,thunder,earthquake,salt corrosion,air corrosion or other natural disaster.
 - ✓ The damage due to artificial falling or transportation.
 - ✓ Improper operation without following the user manual
 - ✓ The damage due to faults outside the AC drive.
 3. If the AC drive has been used for more than the warranty life, reasonable repair fee will be charged.
 4. The maintenance fee is charged according to the uniform standard of our company. If there is an agreement, the agreement has priority.
-

Chapter 10 Optional Cards

10.1 Relay Card (IO1)

IO1 is an optional card for relay and digital output .It needs to be used together with the vector control AC drives which is produced by our company.

◆ **Functional overview**

- ❖ 4 relays outputs (T3~T6)
- ❖ 1 digital output (Y3)

◆ **Pin description**

Table 10-1 Optional card IO1

Terminal Symbol	Description
T3-A	Relay 3 common port
T3-C	Relay 3 normally open port
T4-A	Relay 4 common port
T4-C	Relay 4 normally open port
T5-A	Relay 5 common port
T5-C	Relay 5 normally open port
T6-A	Relay 6 common port
T6-C	Relay 6 normally open port
Y3	Digital output terminal 3(open collect output)
COM	Digital output common port

- Note:** 1) T3~T6 has only normally open port.
 2) T3~T6 and Y3 function is the same with Y/T terminal function of the control board.

◆ **Installation of the optional card**




Figure 10- 1 Schematic diagram of the optional card installation

10.2 Multi-function IO Card (IO2)

IO2 is an optional card for analog input, digital input and digital output. It needs to be used together with the vector control AC drives which is produced by our company.

◆ Functional overview

- ❖ 1 analog input (AI3)
- ❖ 1 digital output (Y3)
- ❖ 4 digital inputs (X7~X10)
- ❖ 10V reference supply
- ❖ 24V supply for external use

◆ Pin description

Table 10-2 Optional card IO2

Terminal Symbol	Description
AI3	Analog input 3
GND	Ground of AI3 and +10V
+10V	10V reference supply
Y3	Digital output 3
COM	Ground of Y terminal and 24V
X7	Digital input 7
X8	Digital input 8
X9	Digital input 9
X10	Digital input 10
CMX1	X7~X10 common port
+24V	24V supply
COM	Ground of Y terminal and 24V

Note:

- 1) AI3 function is the same with the AI function of control board.
- 2) Y3 function is the same with Y terminal function of control board.
- 3) X7~X10 function is the same with X terminal function of control board.
- 4) +10V is the same with +10V terminal of control board.
- 5) 24V is the same with 24V terminal of control board.

◆ Installation of the optional card

Please see the figure 10-1.

10.3 Multi-function IO Card (IO3)

IO3 is an optional card for digital input and relay output. It needs to be used together with the vector control AC drives which is produced by our company.

◆ **Functional overview**

- ❖ 4 digital inputs (X7~X10)
- ❖ 2 relay outputs (T3~T4)
- ❖ 24V supply for external use

◆ **Pin description**

Table 10-3 Optional card IO3

Terminal Symbol	Description
X7	Digital input 7
X8	Digital input 8
X9	Digital input 9
X10	Digital input 10
CMX1	X7~X10 common port
+24V	24V supply
COM	Ground of 24V
T3-A	Relay 3 common port
T3-C	Relay 3 normally open port
T4-A	Relay 4 common port
T4-C	Relay 4 normally open port

Note:

- 1) X7~X10 function is the same with X terminal function of control board.
- 2) T3~T4 function is the same with T terminal function of control board.
- 3) 24V is the same with 24V terminal of control board.

◆ **Installation of the optional card**

Please see the figure 10-1.

10.4 Temperature Sample Card (IO4)

IO4 is an optional card for PT100/PT1000 temperature sensor. It needs to be used together with the vector control AC drives which is produced by our company.

◆ Functional overview

- ❖ 3 groups wiring terminals for PT100/PT1000
- ❖ 1 digital input (X7)

◆ Pin description

Table 10-4 Optional card IO4

Terminal Symbol	Description
R1+	1st group wiring terminals for PT100/PT1000
Rm1	
R1-	
R2+	2nd group wiring terminals for PT100/PT1000
Rm2	
R2-	
R3+	3rd group wiring terminals for PT100/PT1000
Rm3	
R3-	
X7	Digital input 7 and its Ground
CMX1	

Note:

- 1) PT100/PT1000 needs to be connect between R+ and R- if it's two wire type. And another Rm needs to be connected when PT100/PT1000 is three wire type.
- 2) X7 function is the same with X terminal function of control board. Use external 24V source or 24V on control board to supply for X7.

◆ Installation of the optional card

Please see the figure 10-1.

10.5 Differential Encoder Card (PG1)

PG1 is an optional card for differential ABZ incremental encoder. It needs to be used together with the vector control AC drives which is produced by our company..

◆ Functional overview

- ❖ Input ports for A,B,Z differential signal
- ❖ Optional supply(5V, 12V and 15V) for encoder

◆ Pin description

Table 10-5 Optional card PG1

Terminal Symbol	Description
A+	Encoder output signal A Positive
A-	Encoder output signal A Negative
B+	Encoder output signal B Positive
B-	Encoder output signal B Negative
Z+	Encoder output signal Z Positive
Z-	Encoder output signal Z Negative
Vdd	Encoder supply
COM	Supply ground

◆ Installation of the optional card

Please see the figure 10-1.

10.6 OC type Encoder Card (PG2)

PG2 is an optional card for OC type ABZ incremental encoder. It needs to be used together with the vector control AC drives which is produced by our company.

◆ Functional overview

- ❖ Input ports for A,B,Z signal
- ❖ Optional supply(5V, 12V , 15V and 24V) for encoder

◆ Pin description

Table 10-6 Optional card PG2

Terminal Symbol	Description
A	Encoder output signal A
B	Encoder output signal B
Z	Encoder output signal Z
Vdd	Encoder supply
COM	Supply ground

◆ Installation of the optional card

Please see the figure 10-1.